

英文正面

Magnetic Power Bank

User Manual

HiMNO™

**Packing list**

Magnetic Mobile Power Bank\*1, Instruction manual\*1, Charging cable\*1

**Product Diagram**

①Type-C

②Switch button

③Wireless charging area

④Digital display

**Charging Function**

1. Use a Type-C cable to connect the mobile phone with the power bank for charging, and the charging icon will appear on the mobile phone screen.

2. Use the magnetic wireless charging area on the power bank to attach to the back of the mobile phone, and the charging icon will appear on the mobile phone screen.

3. When charging, double-click the power switch and the digital display will turn off, and charging will stop.

4. During the charging process, after the fast charging protocol is matched, the green lightning indicator light will light up; when wireless charging is output, the green lightning indicator light will light up.

**Product Parameters**

|                         |                                                                                                                       |
|-------------------------|-----------------------------------------------------------------------------------------------------------------------|
| Name/Model              | Magnetic Power Bank/PB002                                                                                             |
| Battery level indicator | Digital display                                                                                                       |
| Charging Instructions   | Lightning bolt                                                                                                        |
| Function                | Fast charging, wireless charging                                                                                      |
| Battery capacity        | 5000mAh                                                                                                               |
| Rated capacity          | 3000mAh                                                                                                               |
| Type-C input            | 5V=3A, 9V=2A, 12V=1.5A                                                                                                |
| Type-C output           | 5V=3A, 9V=2.2A, 10V=2.25A(SCP), 12V=1.67A                                                                             |
| Wireless output         | 15W (MAX)                                                                                                             |
| Product size            | 105mm*68mm*9.5mm (±0.5mm)                                                                                             |
| Main Materials          | PC+ABS, aluminum alloy, meets UL94V-0 flame retardant standard                                                        |
| Cell Type               | Lithium polymer battery                                                                                               |
| Protection function     | Support overcharge, over discharge, over current, over voltage, over temperature, short circuit and other protections |

**Warnings**

Please read the following instructions before use. Improper use will cause heating, fire, rupture, damage and product energy reduction.

1. Do not place the product in fire or heat it, and do not store it in a high temperature environment.

英文背面

HiMNO™

Manufacturer: DONGGUAN XINUO APOLLO ELECTRICAL TECHNOLOGY CO.LTD.  
Address: Room 101, Building 1, No.5, Huangyong Commercial road, Zhongtang, Dongguan City, Guangdong Province, China  
Customer Service Number: 400-966-2900  
Made in China (Guangdong)

2. Do not put the positive and negative poles of the product in the charger in reverse order.

3. Do not short-circuit the positive and negative poles of the product with metal wire or metal objects.

4. Do not disassemble or modify the external structure of the product.

5. Do not immerse the product in water or soak the product during storage.

6. Please use a qualified charger for charging/discharging, and operate correctly.

7. If the battery core is burned, discolored, deformed, leaking or any other deformation, it cannot be placed in the charger for charging.

8. If children use this product, they need to be told the correct method of use to ensure that children use it correctly.

9. If there is any abnormality or abnormal charges such as burning after purchase, please contact the manufacturer and return it.

10. Please use or store the product in the 1-9 environment, otherwise the battery core is prone to heating, damage or performance degradation.

11. When the power supply is left unused for a long time, it needs to be charged regularly (three months) to enhance the power supply's charge retention ability.

12. Do not place the battery or equipment near the heat source or exposed fire source, such as electric heaters, microwave ovens, water heaters, stoves, candles, or other places that may generate high temperatures, otherwise, it may lead to equipment failure, fire, or explosion.

13. Putting the battery pack into a fire or a heating furnace, or mechanically squeezing or cutting the battery pack, may cause an explosion.

14. If consumers use a power adapter to charge, they should purchase one that is certified by CCC and meets the standard requirements.

**Common Problems and Solutions**

⚠When you cannot charge the power bank:  
○Please check whether the power adapter is suitable, and whether the connecting cable and adapter are working.  
○It is recommended to use a power adapter of a suitable brand to charge it.  
⚠When the power bank cannot charge other devices:  
○The battery of the power bank is too low, please charge it.  
○The voltage of the device being charged is incompatible with the output voltage of the power bank. Please check the charging voltage requirements of the device being charged.  
○The charging method is incorrect, please check whether the cable or adapter are working.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

**Reminder: To ensure the normal operation and long-term use of the device, it is recommended to charge the device to 100% before using it for the first time.**

Please read this instruction manual carefully before using the product.

PB-002磁吸移动电源说明书、风琴折

印刷要求: CMYK四色+2专色 / 双面印刷  
材质:80克双胶  
成型尺寸: 90 x 62mm

