

说明书



X18A Manual

参数配置

产品型号:	X18A
产品材质:	TPU/ABS
喇叭:	Φ14 32Ω 铜环喇叭
耳机容量:	30mAh
充电仓容量:	200mAh
有效距离:	10M以上
耳机净重:	66g
充电时间:	1小时
播放时间:	8小时
充电接口:	TYPE-C

product parameters

product model:	X18A
product material:	TPU/ABS
speaker size:	Φ14 32Ω copper ring speaker
Headphone capacity:	30mAh
charging compartment:	200mAh
Effective distance:	10M Above
Net weight of headphones:	66g
charging time:	1Hour
playback time:	8Hour
charging connector:	TYPE-C

1

使用说明

1. 蓝牙名称: **X18A**
2. 配对连接: 首次开机: 两个蓝牙板同时开机, 对耳自动配对。配对成功后, 主耳白绿交替闪, 随即用手机连接对应的蓝牙配对名即可
3. 开机: 开盖取出耳机或长按3秒开机
4. 关机: 放回充电仓或长按3秒关机
5. 接听电话: 来电状态任意边按压1次
6. 挂断电话: 通话状态任意边按压1次
7. 暂停播放歌曲: 任意边按压1次
8. 上一曲: 左耳边按压2次
9. 下一曲: 右耳边按压2次

Instructions for use

1. Bluetooth **name: X18A**
2. First boot: Turn on both Bluetooth boards at the same time and the earphones will pair automatically. After the pairing is successful, the main earphone will flash alternately in white and green. Then you can use your mobile phone to connect to the corresponding Bluetooth pairing name.
3. power on: Take out the earphones after opening the lid or press and hold the button for 3 seconds to power on.
4. power of: put the earphones back into the charging case or press and hold the button for 3 seconds to power of.
5. Answering phone calls: press once on either side of the incoming call status
6. Hanging up the phone: press once on either side of the call status
7. pause playing the song: press any side once
8. previous song: press the left ear twice
9. Next song: press the right ear twice

2

单耳模式

	功能操作说明	LED状态
播放/暂停	单按	灯灭
SiRI开关	长按二秒	灯灭
下一曲	按2下	灯灭
音量加	-	-
来电接通/挂断	单按	灯灭
来电拒接	来电状态下, 长按2秒	灯灭
低电量报警	电量低于3.2V低电报警; 电量低于3.1V自动关机;	灯灭
充电中	■	LED灯常亮
充电完成	-	指示灯常亮
充电电流	5V/40mA充电, 开机充电耳机会自动关机复位。	

3

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

5 充电指示状态



充电仓充满电时 (**充电指示灯常亮**)

when the charging compartment is fully charged (**Charging indicator light is always on**)

4

6 使用注意事项

- 1、日常使用中耳机充电面会沾上灰尘等脏污的东西可以使用棉签清理耳机充电电接触面。

Use a cotton swab to clean the charging surface of the earphone, which will be stained with dirt.

- 2、耳机需按要求正确规范的使用, 注意使用环境对耳机的影响, 为保证连接顺畅, 建议手机和耳机之间的距离在8米范围内。

Earphone should be used correctly according to the requirement.

Pay attention to the influence of environment on earphone. In order to ensure smooth connection, it is suggested that the distance between the phone and earphone should be within 8 meters.

- 3、如耳机有连接不上或通讯不畅等其它问题, 请私自拆卸耳机本体及其配件, 否则不予保修。不要使用超过额定安数伏数的充电头给耳机充电。 If the headset does not connect or poor communication and other problems, please remove the headset itself and its accessories, otherwise not warranty do not use more than the rated ampere charging head to the headset.

- 4、为了保证你正常使用耳机, 请确保耳机的电量充足。

To make sure you're using your headphones properly, make sure they're fully charged.

5

7 保修

耳机基本功能

Basic function of earphone

- 1、产品如有任何功能问题, 均可享受有保修服务, 联系客服。

If the product has any functional problems, can enjoy the warranty service, contact customer service.

- 2、人为损坏、摔坏、人为刮花、进水、无保修卡者不在保修范围内。

Artificial damage, broken, artificial scratch, water, no warranty card is not within the scope of the warranty.

- 3、客户必须填写所有必要资料(客户姓名、地址、电话、购买日期等)

Customer must fill in all necessary information (customer name, address, telephone number, date of purchase, etc.).

- 4、保修服务需在保修卡并按要求操作即可保修, 否则不保修

Warranty service in the warranty card and according to the requirements of operation can be warranty, otherwise no warranty

产品型号: _____
Model
客户姓名: _____
Name of client
联系电话: _____
Contact number
客户地址: _____
Client address
购买日期: _____
Date of purchase

6

8 温馨提示

- 1、如果你的耳机充电中存在发热严重或烧坏的情况可以是不是使用大于5V2A功率的充电头, 大于的话需要更换小于5V2A的充电头。

- 2、当左右耳机出现只有一边有声音的时候请把两只耳机重新放入充电盒, 耳机自动关机, 打开手机找到配对名, 点击取消蓝牙配对, 打开充电盒, 取出耳机, 靠近民解锁的手机, 等待8秒左右打开手机蓝牙搜索蓝牙配对名点击连接。

- 3、耳机听不到声音

- (1) 确认耳机处于工作状态
- (2) 确认耳机的音量大小是否合适
- (3) 确认耳机是否与手机正常连接
- (4) 确认耳机在正常的工作范围

- 4、如果听到耳机有断续的情况: 有些地方信号干扰大, 蓝牙耳机会出现干扰蓝牙底噪的情况会出现断续情况走到别的地方断开重新连接即可解决。

- (1) 耳机离手机距离超出8米以上或中间有障碍物时, 会影响信号传输
- (2) 周边有大功率发射设备时, 会影响信号传输
- (3) 紧密空间也会影响信号传输(电子城等)

7

Warm Reminder

1. If your headphones are seriously overheated or damaged during charging, please check if you are using a charging with a power greater than 5V2A. If so, you need to replace it with a charging head less than 5V2A.

2. When only one side of the left and right headphones has sound, please put both headphones back into the charging box, turn off the headphones automatically, find the name on the phone, click cancel Bluetooth pairing, open the charging box, take out the headphones, close to the unlocked phone, wait for about 8 seconds to open the phone to search for Bluetooth pairing name, click to connect.

3. No sound can be heard from the headphones

- (1) Confirm that the headphones are working condition
- (2) Confirm whether the volume of the headphones is appropriate
- (3) Confirm whether the headphones are connected to the phone normally
- (4) Conf whether the headphones are within the normal working range

4. If you hear intermittent sound from the headphones: If the signal interference in the environment is too strong, the Bluetooth headphones will experience noise interference, resulting in intermittent. Change the location, disconnect and reconnect Bluetooth to solve the problem.

- (1) When the distance between the headphones the phone exceeds 8 meters or there are obstacles in between, it will affect the signal transmission
- (2) When there are high-power transmitting devices around, it will affect signal transmission
- (3) A confined space will also affect signal transmission (such as an electronics city)