




Video Doorbell and aosuBase Mini (Battery or Hardwired Doorbell)

Quick Start Guide




TABLE OF CONTENTS

01	What's Included	P01
02	Product Overview	P02-P03
03	How The System Works	P04
04	App Installation and System Setup	P05
05	Video Doorbell Installation	P06-P19
06	Notice	P20-P22
07	Customer Service	P23

Please download the "aosu"App and then add devices before installing doorbell.

What's Included



Video Doorbell



Mounting Bracket



Screw Hole
Positioning-Card



15° Mounting
Wedge (Optional)



aosuBase Mini



Phillips-Head
Screwdriver



USB-C Charging
Cable



Extension Wires and
Wire Nuts (Optional)



Screw Packs



aosuBase Mini
Power Pin




Quick Start Guide



Doorbell Detaching Pin


Product Overview

Video Doorbell (Battery or Hardwired)



- | | |
|---------------------------|--|
| 1 Motion Sensor | 6 USB-C Charging Port |
| 2 Camera Lens | 7 SYNC Button |
| 3 Microphone | 8 Power Terminals for Existing Doorbell Wire |
| 4 Doorbell Circular Light | 9 Detaching Mechanism |
| 5 Doorbell Button | 10 Speaker |

aosuBase Mini



Operation	How-to
Power on the doorbell	Press and release the SYNC button
Power off the doorbell	Press and hold the SYNC button for 3 seconds.
Reset the doorbell	Press and hold the SYNC button for 10 seconds.
Connect to Wi-Fi network	Press and hold the SYNC button until you hear a beep

How The System Works

What's Required for Installation

Phillips-Head Screwdriver

Power Drill with 1/4" (6.35mm) Drill Bit

How the System Works

The video doorbell system includes 2 parts.


One is the video doorbell at your door.

The other is the aosuBase Mini in your house.

The video doorbell detects motion at your porch and allows you to answer the door anytime and anywhere.

The aosuBase Mini stores video clips on its built-in storage.

When someone rings the doorbell, people in the house will be notified.



App Installation and Set up the System

1. Download the aosu App from the App Store (iOS devices) or Google Play (Android devices).
2. Scan the QR code below or search "aosu" in the App Store or Google Play.




Register or log into the App. Add Video Doorbell V8S and scan the QR code for later installation process.

Video Doorbell Installation

Choose The Power Option

Option 1 - Battery Powered

1. If you don't have existing doorbell wiring at the front door, please use the built-in battery. You are free to determine the doorbell position and the mounting is easy and quick.
2. When the doorbell battery level is low, you need to detach and charge it.



Warning: The battery life varies depending on usage. In most common cases, a doorbell may have up to 10 events per day and each recording lasts 20 seconds on average. Under this scenario, the doorbell battery life can last up to 6 months.

Option 1 - Battery Powered





Step 1 Find a Mounting Spot

Take the video doorbell to your front door and check the live view on the App at the same time. Find a location where you can get the desired field of view.

Consider the factors below:

1. Check if you can reuse the existing holes and anchors on the wall or door frame.
2. If you want to place the doorbell close to a side wall, make sure the wall doesn't show up in the field of view. Otherwise IR light will be reflected and night vision will become blurry.
3. If you drill the mounting holes for the first time, the recommended mounting height is 48" / 1.2 m from the ground.
4. Use the 15° mounting wedge as a supplementary mounting bracket if you wish to see more on a specific side.

Place the Screw Hole Positioning Card against the wall to mark the position.




Step 2 Mounting the Bracket

Mount the Doorbell on a Wooden Surface


If you mount the doorbell on a wooden surface, you don't need to pre-drill pilot holes. Use the provided screws to secure the Mounting Bracket on the wall. The Screw Hole Positioning Card indicates the position of the screw holes.

Without 15° Mounting Wedge



Mounting Bracket

With 15° Mounting Wedge



Mounting Wedge

Mounting Bracket

What is required:



Power Drill
(not provided)



Mounting Bracket
(Attached to 15° Mounting
Wedge)



15° Mounting
Wedge (Optional)




Screw Packs (Spare screws
and anchors are included.)

Step 3 Mounting the Doorbell

Mount the Doorbell

Align the doorbell on top and then snap it on the bottom.

Press it down until it clicks into place.




You're all set!

If you want to detach the doorbell or recharge it, please refer to the following sections.

Detach the Doorbell


1. Use the doorbell detaching pin provided if you wish to detach the doorbell from the Mounting Bracket.
2. Press and hold the hole on the bottom of the doorbell and then lift its bottom to take it off.



What is required:




Recharge the Doorbell



LED indication	Charging: The blue light flashes
	Fully charged: Solid blue
Charging time	6 hours from 0% to 100%


Option 2 - Doorbell Wire Powered

1. If you have existing and working doorbell wiring at the front door, the doorbell will be powered by the wires constantly. So you don't need to detach and charge it after installation.
2. Since the doorbell is connected to the wires, the mounting position is limited.
3. If you choose this option, please jump to Appendix 2 Powering the Doorbell with Doorbell Wires.



Step 1 Verify whether the doorbell wires are working

1. Ring the existing doorbell to check if it is working. If the doorbell doesn't ring, your doorbell wires may be defective. Power the doorbell on its own battery or consult an electrician to fix the wires.
2. Shut off power at the breaker. Turn the lights on / off in your home to make sure the electricity in your house is properly shut off.




Warning: Always be careful when handling electricity wiring. If you're not comfortable to do it yourself, do consult a qualified electrician.

Step 2 Detach the Existing Doorbell Button

If you already have existing doorbell wiring:

1. Remove the existing doorbell button with a Phillips-Head screwdriver.
2. Pull the two wires out carefully when removing the existing doorbell. Straighten the wire ends if necessary.



What is required:






Phillips-Head Screwdriver


Step 3 Find a Mounting Spot

1. Determine the mounting position of the doorbell. Consider the factors below:

- Check if you can reuse the existing holes and anchors on the wall or door frame.
- If you drill the mounting holes for the first time, the recommended mounting height is 48" / 1.2 m from the ground.
- Use the 15° mounting wedge as a supplementary mounting bracket if you wish to see more on a specific side.




2. Place the Screw Hole Positioning Card against the wall to mark the position.



Step 4 Mount the Bracket


If you mount the doorbell on a wooden surface, you don't need to pre-drill pilot holes. Use the provided screws to secure the Mounting Bracket on the wall. The Screw Hole Positioning Card indicates the position of the screw holes.

Without 15° Mounting Wedge



Mounting Bracket

With 15° Mounting Wedge



Mounting Wedge

Mounting Bracket

What is required:



Phillips-Head Screwdriver



Mounting Bracket
(Attached to 15°
Mounting Wedge)



15° Mounting
Wedge (Optional)





Screw Packs (Spare screws
and anchors are included.)

If you mount the doorbell on a surface made out of hard materials, like brick, concrete, stucco:


- Drill 2 holes through the Screw Hole Positioning Card with 15/64"(6mm) drill bit.
- Insert the provided anchors, and then use the provided long screws to secure the Mounting Bracket on the wall.

Without 15° Mounting Wedge



Mounting Bracket

With 15° Mounting Wedge



Mounting Wedge

Mounting Bracket

What is required:



Power Drill
(not provided)



15/64"(6mm) Drill Bit



Mounting Bracket
(Attached to 15°
Mounting Wedge)




15° Mounting
Wedge (Optional)



Screw Packs (Spare screws
and anchors are included.)

Step 5 Connect the Doorbell Wires to the Doorbell



Connect the wires to the terminals at the back of the doorbell, then tighten the terminal screws. Wire can connect to any terminal.



Note:


- To prevent short-circuit, make sure the wires are not touched each other after connecting them to the terminals.
- If the wires are too short, use the extension wires and wire nuts provided to make them longer. Use electrical wiring tape instead if there is no more space on the wall for wire nuts.

What is required:




Step 6 Mount the Doorbell on the Bracket

Align the doorbell on top and then snap it on the bottom.



Step 7 Restore Power

Switch the master circuit breaker back to ON.
You're all set!



Notice

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: (1) Reorient or relocate the receiving antenna. (2) Increase the separation between the equipment and receiver. (3) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. (4) Consult the dealer or an experienced radio/TV technician for help.

FCC Radio Frequency Exposure Statement

The device has been evaluated to meet general RF exposure requirements. The device can be used in fixed/mobile exposure condition. The min separation distance is 20cm.

IC Statement

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) L'appareil ne doit pas produire de brouillage; (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

IC RF Statement

This equipment complies with IC RSS - 102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.



This product complies with the radio interference requirements of the European Community.

Declaration of Conformity

Hereby, Glazero Limited declares that this device is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. For the declaration of conformity, visit the Web site:<https://www.aosulife.com/>. This product can be used across EU member states.

Do not use the Device in the environment at too high or too low temperature, never expose the Device under strong sunshine or too wet environment.

The suitable temperature for aosuBase Mini and accessories is -10°C-45°C.

The suitable temperature for Video Doorbell and accessories is -20°C - 40°C .

When charging, please place the device in an environment that has a normal room temperature and good ventilation.

It is recommended to charge the device in an environment with a temperature that ranges from 5°C~25°C.

RF exposure information: The Maximum Permissible Exposure (MPE) level has been calculated based on a distance of d=20 cm between the device and the human body. To maintain compliance with RF exposure requirement, use product that maintain a 20cm distance between the device and human body.



This product is designed and manufactured with high quality materials and components, which can be recycled and reused.



This symbol means the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment. For more information on disposal and recycling of this product, contact your local municipality, disposal service, or the shop where you bought this product



Battery warning

- Replacement of a battery with an incorrect type that can defeat a safeguard (for example, in the case of some lithium battery types).
- Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.
- Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.
- A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

Customer Service

Warranty

12-month limited warranty (The actual warranty period shall be implemented according to the requirements of local laws and regulations)

Email Us

Customer Support: support@aosulife.com

Call Us

US +1-866-905-9950 Mon-Fri 9AM-5PM (PST)

UK +44-20-3885-0830 Mon-Fri 9AM-5PM (GMT)

FR +33-980099094 Mon-Fri 8AM-4PM (CET)

DE +49-32-221094692 Mon-Fri 9AM-5PM (CET)

JP +81-50-5840-2601 Mon-Fri 9AM-5PM (JST)



Facebook: [@aosulife](#)



Twitter: [@aosulife](#)



YouTube: [@aosulife](#)

qosu