

# **EAR-HOOK WIRELESS EARBUDS**

---

## **User Manual & Warranty Card**

**AirBuds 300**

**EXCLUSIVE WARRANTY CERTIFICATE**

## Activate Your Warranty

Complete the registration in two minutes and enjoy the brand VIP benefits.

1. Activate and extend warranty: Register to activate your **2-year** warranty. Registering within 24 hours of receiving, you can get a **3-year** warranty.
2. **24-hour** technical service support.
3. Free return and exchange within **30-day**.



**serviceplus.linda@gmail.com**

**US English Support:** +1 (717) 896-6060

**CA English Support:** +1 (587) 841-0500

**UK English Support:** +44 7700 156388

**German Support:** +49 157 3598 0115



WhatsApp




Scan & Join VIP


In order to provide you with a more considerate service experience, we have a professional after-sales team to answer your questions about product use. If you have any questions about the product, please contact us through the above channels.

**Validity period: Within one week of order.**

## ■ PRODUCT INTRODUCTION



## ■ Connect




1. Open the lid and pick up the earbuds (they will turn on automatically)
2. After open the phone Bluetooth, Click the [AirBuds 300] to Pairing.

## ■ Reset

1. Delete the pairing data on your phone for the [AirBuds 300].
2. Put the earbuds back in the charging case, open the lid, and pick up the earbuds.
3. In pairing mode, double-tap and hold for 5 seconds to clear the pairing records.
4. Put the earbuds back in the charging case to start charging them, then wait for 20 seconds.
5. Open the cover and take out the earphones.


## ■ Operation



1)Play / Pause



2)Adjust Volume



3)Switch Song



4)Answer/Hang up




5)Reject Call



6)Voice Assistant



7)Switch Call




8)Answer/Hang up



9)Reject Call

**x 1:** Click Once      **x 2:** Click 2 Times      **x 3:** Click 3 Times

**2 s:** Press and hold for 2 seconds



The power delivered by the charger must be between min 0.5 Watts required by the radio equipment, and max 2.25 Watts in order to achieve the maximum charging speed.

## FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.