


Integrated Bluetooth Speaker

User Manual




SJY-8801

Copyright(c)2025(V1.0)

1.Package Contents

- SJY-8801 Speaker × 1
- Audio Cable × 1
- Power Adapter × 1
- User Manual & Warranty Card × 1

2.Function Introduction



1.Status Indicator Light

Bluetooth Mode: Blue Light
USB Mode: Yellow Light
AUX Mode: Green Light
Radio Mode: Cyan Light

2.“ ” Button

Long press: Power on / Power off
Short press: Bluetooth broadcasting

3.“MODE” Button

Click: Switch to Bluetooth mode/USB/AUX

4.“ ” Button


Single press: Play / Pause
Long press: Clear pairing information

5.“ - ” Button

Click: Volume Down
Long press: Previous song


6.“ + ” Button

Click: Volume Down
Long press: Next song



Note: All images in this manual are schematic diagrams. Due to technical and system upgrades, the marked information and parameters may differ from the actual product. Please refer to the actual product for accuracy.

3. Speaker Connection Diagram




4.Operation Instructions

Bluetooth Connection

When turned on for the first time, the speaker defaults to Bluetooth standby mode. You can pair and connect it with Bluetooth devices (such as mobile phones, computers, etc.);


A blinking blue light indicates that the speaker is in Bluetooth standby mode. In this state, you can find the device named "SJY-8801" via other Bluetooth devices, then pair and connect to use it.



Bluetooth Standby: Steady Blue Light
Bluetooth Connected: Blinking Blue Light

Bluetooth Disconnection

In the Bluetooth-connected state, long press the Bluetooth button for 2.5 seconds to force disconnect the connected device and enter Bluetooth standby mode (blinking blue light).



AUX Mode

- 1. In Bluetooth mode, connect an AUX audio source, and the speaker will automatically switch to AUX mode.*
- 2. In Bluetooth mode, short press the [MODE] Can switch to Bluetooth, USB, AUX modes*

USB Mode

- 1: In Bluetooth mode, inserting a USB will automatically switch to USB mode*
- 2: Click the MODE button to switch between Bluetooth, AUX, and USB modes*

Bluetooth Broadcast Mode

- 1: Prepare multiple speakers A, B, C, D, ...*
- 2: Click "Speaker A" for Bluetooth pairing and complete the pairing.*
- 3: Click the power button of Speaker A to enable Bluetooth Broadcast Mode. At the same time, turn on Bluetooth Broadcast Mode for B, C, and D as well. They can play music from the same input source simultaneously and can connect to N devices.*

Power Saving Mode

In the boot state, if there is no operation or playback for 15 consecutive minutes in Bluetooth/USB/AUX mode, the speaker will automatically shut down

Charging

- 1. When the speaker's battery is low, a low-battery alarm tone will sound, and the speaker needs to be charged.*
- 2. Use the adapter included in the package to charge the speaker.*
- 3. The charging indicator stays red when charging and turns off when fully charged.*
- 4. If the speaker is not used for a long time, it is recommended to charge it once every three months to extend the battery life.*

5. Specifications (Implementation Standard: SJ/T11540-2015)

Distortion-Limited Output Power: Tweeter (L/R): 10W+10W

Mid-Bass: 30W

Rated Frequency Response Range: 20Hz-20kHz

Noise Level: ≤ 90 dB(A)

Input: 18V-- 2A

6. Troubleshooting

Speaker Noise Issue?

Shunjiayu speakers feature low noise. However, some audio sources themselves may have noise several times higher than that of the speaker. To check, unplug the audio cable, turn up the volume, and you should barely hear any sound from the speaker at a distance of [XX] meters.

Unable to Power On?

This may be caused by low battery. Connect the adapter to turn on the speaker immediately.

Cannot Find Bluetooth Device "SJY8801" Under Bluetooth Input

1. Check if the speaker is turned on.
2. Check if the input mode is switched to Bluetooth.
3. Long press the [►||] button on the speaker to try disconnecting any potentially connected Bluetooth devices, then search for "SJY-8801" again.
4. Restart the speaker, switch to Bluetooth input, and search for "SJY-8801" again.

7. Maintenance and Care

To comply with the warranty terms and extend the product's service life, please read the following suggestions when using the product:

1. To reduce the risk of fire and electric shock, do not expose the product to rain or moisture.
2. Do not use the product near water, immerse it in liquid, or allow liquid to drip or splash onto it.
3. Do not install or use the product near any heat sources (such as radiators, heating equipment, stoves, or other heat-generating devices).
4. Do not place the product in direct sunlight or high-temperature environments. High temperatures can shorten the service life of electronic components, damage the battery, and deform some plastic parts.
5. Do not place the product in extremely cold environments, as this may damage the internal circuit board.
6. Do not attempt to disassemble the product. Non-professional disassembly may damage the product.
7. Do not drop, subject the product to strong vibration, or hit it with hard objects, as this may damage the internal circuit.
8. Do not clean the product with strong chemicals or detergents.
9. Do not scratch the product surface with sharp objects, as this may damage the casing and affect the appearance. If the product fails to work normally, please send it to a qualified maintenance institution, and the staff will help you solve the problem enthusiastically.

FCC Caution.

(1) § 15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

§ 15.21 Changes or modification warning

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

§ 15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the

instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of

the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning for Mobile device:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Shenzhen Shunjiayu Technology Co., Ltd

**201-203, 2nd Floor, Building 43, Zone 5, Huaide Cuigang Industrial Park,
Fuyong Street, Bao'an District, Shenzhen City, Guangdong Province**

Made in China

Model:S J Y -8 8 0 1