



型号：Q99 Max

头戴式双馈主动降噪蓝牙耳机

充电

- 将Type-C线插入左右边的Type-C充电接口，并另一端连接USB 5V 电源。
- 当耳机正在充电时，将显示实心红色LED灯。
- 充电完成后，LED指示灯变为蓝色。
- 充电时间约为2.5小时。

开机/关机

开机：按住耳机左和右侧的电源按钮约3秒，直到LED指示灯亮起。
关机：按住左边或右边（任意一边）电源按钮4秒，直到LED灯熄灭。

配对连接

- 打开蓝牙耳机（请参阅“开机/关机”）。
- 两边耳机开机后，指示LED灯亮起蓝色，两边耳机会自动配对，当一边为蓝LED灯常亮，一边变成红蓝LED灯闪烁表示已经准备好与您的设备配对。
- 在支持蓝牙功能的智能手机、平板电脑或媒体播放器上，找到蓝牙设置菜单，打开蓝牙功能，并搜索新设备，直到你看到配对名“Q99 Max”列出。
- 选择“Q99 Max”进行配对，配对完成后，蓝LED灯常亮。开始播放时，蓝LED灯慢闪。
- 当之前已经配对过的设备，蓝牙功能已打开并处于覆盖范围内时，耳机将自动重新连接到它连接的最后一个蓝牙设备。

注意：如果耳机开机后，在5分钟内没有与设备进行配对。耳机会自动关机以节省电量。

功能操作（请参阅“功能按键说明”）

- ①多功能键
来电时，按一下，接听电话，再按一下挂断电话；来电时，长按拒接来电。
播放时，按一下，暂停/播放；双击，下一曲；三击，上一曲；顺时针旋转，调大音量，逆时针旋转，调小音量。
- ②键
长按开机，再次长按关机。
按一下，通透模式；再次按下，降噪模式；再次按下，关闭降噪。
双击唤醒语音助手
- ③键
长按开机，再次长按关机。
按一下，游戏模式；再次按下，全景声模式；再次按下，头部追踪；再次按下，音乐模式。

注意：按下手势并触摸正确的区域会给你一个流畅的体验。

故障排除

- 没有电
-使用随机配送的Type-C电缆线为无线耳机充电。
- 音乐不能通过蓝牙播放
-确保您的蓝牙设备具有A2DP配置文件。检查两个设备是否配对并通过蓝牙连接。重新将耳机开机以重新连接您的蓝牙设备。
- 蓝牙设备将无法与耳机重新连接
-找到蓝牙设备上的蓝牙设置菜单，点击配对名“Q99 Max”，然后选择“取消配对”。
- 按照步骤再次配对您的设备。

功能按键说明



*兼容iOS和Android智能手机/平板等带蓝牙功能的电子产品

保修卡

产品名称: _____ 型号: _____

销售单位: _____ 销售日期: _____

姓名: _____ 电话: _____


地址及邮编: _____
(以上信息由使用者填写)

故障描述1: _____

处理方案1: _____

故障描述2: _____

处理方案2: _____



Item No.: Q99 Max

Over-Ear Hybrid Active Noise Cancelling Wireless Headphones

FCC Caution:
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.

Charge It

- Insert the Type - C cable into the Type - C charging port on either the left or right side, and connect the other end to a standard 5V USB power source.
- When the headphones are charging, a solid red LED light will be displayed.
- After charging is complete, the LED indicator turns blue.
- The charging time is approximately 2.5 hours.

Power On / Off

Power On: Press and hold the power buttons on both the left and right sides of the headphones for about 3 seconds until the LED indicator lights up.
Power Off: Press and hold the power button on either the left or right side (either one) for 4 seconds until the LED light goes out.

Pair & Connect With New Device

- Turn on the wireless headphones (refer to "Power On / Off").
- After both headphones are powered on, the indicator LED lights turn blue. The earcups will automatically pair with each other. When one earcup shows a steady blue LED and the other shows alternating red and blue flashing LEDs, it means they are ready to pair with your device.
- On smartphone, tablet, or media player with wireless capabilities, find the Wireless settings menu, turn on the Wireless function, and search for new devices until you see the pairing name "Q99 Max" listed.
- Select "Q99 Max" for pairing. After successful pairing, the blue LED light stays on steadily. When playback starts, the blue LED light flashes slowly.
- When a previously paired device has its wireless function turned on and is within the coverage area, the headphones will automatically reconnect to the last wireless device they were connected to.

Note: If the headphones are turned on and not paired with a device within 5 minutes, they will automatically power off to save battery.

Function Operations (refer to "Function Button Instructions")

① Multi - function Button
When there is an incoming call, press once to answer the call, and press again to hang up. When there is an incoming call, press and hold to reject the call.
During playback, press once to pause or resume playback. Double - press to skip to the next track. Triple - press to go back to the previous track. Rotate the dial clockwise to increase volume, and rotate counter - clockwise to decrease volume.

② Button
Press and hold to power on, press and hold again to power off.
Press once for transparency mode. Press again for noise - canceling mode. Press again to turn off noise - canceling.
Double - press to wake up the voice assistant.


③ Button
Press and hold to power on, press and hold again to power off.
Press once for gaming mode. Press again for surround sound. Press again for head-tracking mode. Press again for music mode.

Note: For optimal experience, ensure you press the buttons and touch the correct sensor areas as intended.

Troubleshooting

- No power
-Charge the wireless headphones using the included Type-C cable.
- Music is not playing over Wireless
-Ensure that your wireless device has the A2DP profile. Check if the two devices are paired and connected via Wireless. Power on the headphones again to reconnect to your Wireless device.
- Wireless device will not reconnect with the headphone
-Navigate to your Wireless settings menu on your Wireless device, tap Model: "Q99 Max", and select "Forget".
-Follow the steps to reconnect your device.

Function Button Instructions



*Compatible with iOS and Android smartphones/tablets and other electronic products with Bluetooth functionality

Warranty certificate

Product name: _____ Model: _____

Sales unit: _____ Sales date: _____

Name: _____ Tel: _____

Address and zip code: _____
(The above information is filled in by the user)

Fault description 1: _____

Solution 1: _____

Fault description 2: _____

Solution 2: _____