User Guide Video

How to Wirelessly Charge

How to Audiobook Playback

USB Power Adapter Plug Installation Guide

1.Insert the AC plug downwards in the angle as shown in the figure.
2.Turn right to lock.

KS10

QUICK START GUIDE

Audible Book Speaker with Wireless Charging Dock

English

PACKAGE CONTENTS


1X Audible Book Speaker with Wireless Charging Dock
1X Power adapter(9V/2A)
1X User's Manual

TECHNICAL INFORMATION


Output Power	Wireless Charging 7.5W/15W, Speaker 6W
Power Supply	DC9V INPUT TYPE-C PORT
Speaker Specification	20MM 4Ω / 3W X2
Wireless Charging Protocol	Qi
Dimension	155X146X17MM
Weight	279G
Distortion	1KHz 1W=/<1%
SNR	≥ 75dB


SAFETY INFORMATION

1.Avoid dropping.
2.Do not disassemble.
3.Do not expose to liquids.
4.For safest charge, use original or certified cables.
5.This product is suitable for moderate climates only.
6.The maximum ambient temperature during use of this product must not exceed 104°F
7.Open flame sources, such as candles, must not be placed on this product.
8.Only use a dry cloth to brush to clean this product.
9.The power adapter and power cord specifications of this product are 9V/2A. If used for other products, please carefully check if they are compatible to avoid damaging your device




LED INDICATOR	STATUS
Solid red for 3 seconds, then off	Connected to power
Flashing red or pink	Charging
Solid red	Charging
Flashing blue	Bluetooth speaker power on
Solid blue	Bluetooth connection successful
Solid pink	Bluetooth connection successful while charging





Button Instructions



How to use the wireless charger? (Important)

1.Connect the product to a power source.
2.Open your Kindle on the charging dock, ensuring that the back of the Kindle fits snugly with the charging panel, and the bottom of the device rests in the groove. Place the phone and make sure it is in the middle position. The KS10 will input 15W of power to your phone.
3. If you need to charge your smartphone, place the phone and make sure it is in the middle position. The KS10 will input 15W or power to your phone.

Follow the above steps, and the LED indicator will turn red, indicating that the device has started charging.

Note:When charging your phone, you need to ensure that the phone has been placed on the middle position of the KS10's groove!

How to use this audio book speaker? (Important)

1.Connect the product to a power source.
2.Resume the speaker is turned on; long press the power button until you hear a beep.
3.Turn on the Kindle's Bluetooth, find a Bluetooth device called "KS10" and connect it. If you hear a prompt sound, it means the connection is successful.
4.Turn up the volume of your Kindle device to maximum (level 8) so that you can get enough volume output on the speaker.

Follow the above steps, and the LED indicator will turn red, indicating that the device has started charging.

Note:When charging your phone, you need to ensure that the phone has been placed on the middle position of the KS10's groove!

(b)Operation - Double click:
(c)Start continuous playback - Touch the screen with one finger and move it continuously (drag) to the next page - Touch the screen with two fingers simultaneously and move left before leaving the screen.

Operate the Kindle according to the new operating mode to return to the e-book reading page. and the book will automatically start screen reading when opened.

- Using a thin-thick protective case or a case with a magnetic/ironplate is not recommended as it may affect the wireless charging function.
- Do not place any foreign objects between your Kindle and the wireless charger, such as: including metal pads on a car mount,credit cards, door keys, coins, metal, or NFC cards, as it may cause overheating.
- Do not connect the wireless charger to a 5V,2A wall charger or a USB port on a computer as it may affect the wireless charging function

Question/Answer

1.Question: Why is the maximum charging power of wireless charging for kindle only 7.5W?
Answer: The maximum wireless charging power of Kindle Paperwhite Signature Edition and Kindle Colorsoft Signature Edition is 7.5W, we promotion that the wireless charging power of Kindle exceeds 7.5W is fake.

2.Question: Why does my KINDLE Bluetooth disconnect when playing on KS10?
Answer:
a. Please check if the Bluetooth of KINDLE is turned on after disconnection.
b. In the closed state,
please turn on the Bluetooth of KINDLE and reconnect via Bluetooth. The malfunction was caused by the automatic shutdown of Bluetooth by KINDLE and we discovered this issue on Kindle during product testing.
c. In the open state,
please contact us to provide feedback on the issues you have encountered.

3. Question: Why does my wireless charger make noise while working?
Support Email: bzyafersale@outlook.com

Answer: It is normal for wireless charging devices to make faint sounds during operation. If you can hear noticeable sounds, please contact us.

4. Question: My KINDLE comes with a protective cover, will it affect its charging power?
Answer: It won't have a significant impact. The wireless charging function of KS10 can be completed with protective covers with a maximum thickness of 5mm, and you can use it with confidence within this range.

5. Question: Can the power adapter supplied with the KS10 be used to power other Type-C interface devices?
Answer: The power adapter supplied with the KS10 has a specification of 9V/2A. Please check if the device you intend to use is compatible.

6. Question: Can the KS10 be powered by other Type-C interface power adapters?
Answer: The KS10 should be powered by a Type-C adapter with specifications of 9V/2A. Using adapters with other specifications may cause device malfunctions.

Tips: How to use Kindle's screen reader feature (free e-book reading function)?

Step1.Turn on the Kindle Bluetooth and connect it to KS10.
Step2.Locate and open "Accessibility" in Kindle's settings, select "VoiceView Screen Reader."
Step3.After opening "VoiceView Screen Reader", the touch operation mode of the screen changes:
(a)Select - Click:
(b)Operation - Double click:
(c)Start continuous playback - Touch the screen with one finger and move it continuously (drag) to the next page - Touch the screen with two fingers simultaneously and move left before leaving the screen.

Operate the Kindle according to the new operating mode to return to the e-book reading page.

PRODUCT YOUR WARRANTY

365 day replacement warranty
60 days money back guarantee
Additional 6-Month Warranty
For addition warranty, please contact customer service by email.
Support Email: bzyafersale@outlook.com

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.
Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user's authority to operate the equipment.
To maintain compliance with FCC's RF exposure guidelines, the distance must be at least 20 cm between the radiator and your body. and fully supported by the operating and installation configurations of the transmitter and its antenna(s).
The device has been evaluated to meet general RF exposure requirement.

Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for anuncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator & your body.

Product Name: **Audible Book Speaker with Wireless Charging Dock**
Model:KS10
Manufacturer: **Shenzhen Yinlvmei Technology Co.,Ltd**
Address: **NO.77,Lijing south road,Shijing Street,Pingshan District,Shenzhen,China**

Deutsch

Lieferumfang

1x Hörbuch-Lautsprecher mit drahtloser Lade-Dock
1x Netzteil (9V/2A)
1x Benutzerhandbuch / Bedienungsanleitung


Technische Daten


Ausgangsleistung	Drahtlose Ladung 7.5 W / 15 W,Lautsprecher 6 W
Stromversorgung	Eingang DC 9V, Anschluss USB-C-Port
Lautsprecherspezifikation	20MM 4Ω / 3W X2
Drahtloses Lade-Protokoll	QI
Abmessungen (B x H x T)	155X146X17MM
Gewicht	279G
Klirrfaktor (THD)	1KHz 1W=/<1%
SNR	≥ 75dB

SICHERHEITSHINWEISE


1.Vor Stürzen schützen.
2.Nicht zerlegen oder öffnen.
3.Vor Feuchtigkeit und Flüssigkeiten schützen.
4.Für das sicherste und schnellste Laden verwenden Sie bitte das originalle oder zertifizierte Ladekabel.
5.Dieses Produkt ist nur für gemäßigtes Klima geeignet.
6.Die maximalle Umgebungstemperatur während des Betriebs darf 40 °C nicht überschreiten,
7.Offene Flammen (z. B. Kerzen) dürfen nicht auf oder in unmittelbarer Nähe des Produkts platziert werden.
8.Reinigen Sie das Produkt nur mit einem trockenen, weichen Tuch oder einer weichen Bürste.
9.Die Spezifikationen des Netzteils und des Netzsteckers für dieses Produkt betragen 9 V / 2 A. Wenn Sie sie für andere Produkte verwenden möchten, prüfen Sie bitte sorgfältig deren Kompatibilität, um Beschädigungen zu vermeiden

LED-Status	Bedeutung/Status
3 Sekunden festes Rot, dann aus	Mit Stromversorgung verbunden
Festes Rot	Wird geladen
Rot oder Pink blinkend	Metallgegenstand erkannt
Blau blinkend	Bluetooth-Lautsprecher eingeschaltet
Festes Blau	Bluetooth-Verbindung erfolgreich
Pink blinkend	Bluetooth-Lautsprecher eingeschaltet (während des Ladens)
Festes Pink	Bluetooth-Verbindung erfolgreich (während des Ladens)





Tastenfunktionen



Wie verwendet man den kabellosen Lader? (Wichtig)

1.Schließen Sie das Produkt an eine Stromquelle an.
2.Legen Sie Ihren Kindle auf das Ladedock, Stellen Sie dabei sicher, dass die Rückseite des Kindle fest auf der Ladefläche aufliegt und der untere Rand des Kindle in die dafür vorgesehene Vertiefung des Ladeständers passt.
3.Möchten Sie ein Smartphone laden, platzieren Sie es bitte in der mittigen Position. Der KS10 liefert dann eine Leistung von bis zu 15 W an Ihr Telefon.

Folgen Sie den obigen Schritten, Die LED-Anzeige leuchtet dann rot, was anzeigt, dass das Gerät mit dem Laden begonnen hat.
Hinweis: Beim Laden Ihres Telefons müssen Sie sicherstellen, dass das Telefon in der mittigen Position der Vertiefung des KS10 platziert ist!

Wie verwendet man diesen Hörbuch-Lautsprecher? (Wichtig)

1.Schließen Sie das Produkt an eine Stromquelle an,
2.Stellen Sie sicher, dass der Lautsprecher eingeschaltet ist: Drücken Sie die Ein-/Aus-Taste lange, bis Sie einen Signalton hören,
3.Schalten Sie Bluetooth auf Ihrem Kindle ein, suchen Sie das Gerät mit dem Namen "KS10" und stellen Sie die Verbindung her. Ein Bestätigungston signalisiert eine erfolgreiche Verbindung.
4.Stellen Sie die Lautstärke auf Ihrem Kindle auf das Maximum (Stufe 8), So erreichen Sie eine ausreichende Lautstärke am Lautsprecher.

Fragen & Antworten

1.Frage:Warum beträgt die maximale Ladeleistung beim kabellosen Laden für den Kindle nur 7,5 W?
Antwort: Die maximale kabellose Ladeleistung der Geräte Kindle Paperwhite Signature Edition und Kindle Colorsoft Signature Edition beträgt 7,5 W. Jegliche Werbeaussage, dass die kabellose Ladeleistung des Kindle 7,5 W überschreitet, ist unzutreffend.
2.Frage: Warum wird die Bluetooth-Verbindung meines Kindle beim Abspielen über den KS10 getrennt?
Antwort: a, Bitte prüfen Sie, ob die Bluetooth-Funktion des Kindle nach der Trennung noch eingeschaltet ist;
b. Wenn sie ausgeschaltet ist: Schalten Sie Bluetooth auf dem Kindle ein und stellen Sie die Verbindung neu her. Dieses Problem wird durch die automatische Bluetooth-Abschaltfunktion des Kindle verursacht, die wir während der Produkttests festgestellt haben.
c. Wenn sie eingeschaltet ist: Bitte kontaktieren Sie uns, um die von Ihnen festgestellten Probleme zu melden,Support-E-Mail: bzyaftersale@outlook.com
3. Frage: Warum erzeugt mein kabelloses Ladegerät während des Betriebs Geräusche?
Antwort: Es ist normal, dass kabellose Ladegeräte während des Betriebs leise Geräusche von sich geben. Wenn Sie jedoch deutlich hörbare Geräusche wahrnehmen, wenden Sie sich bitte an uns.
4. Frage: Mein Kindle hat eine Schutzhülle. Beeinträchtigt diese die Ladeleistung?
Antwort: Nein, die Auswirkungen sind nicht signifikant, Die kabellose Ladefunktion des KS10 ist mit Schutzhüllen bis zu einer maximalen Dicke von 5 mm kompatibel. Innerhalb dieses Bereichs können Sie das Produkt bedenkenlos verwenden,
5. Frage: Kann das mit dem KS10 gelieferte Netzteil auch zum Betrieb anderer Geräte mit Typ-C-Anschluss verwendet werden?
Antwort: Das mit dem KS10 gelieferte Netzteil hat die Spezifikation 9 V / 2 A. Bitte prüfen Sie, ob das von Ihnen verwendete Gerät damit kompatibel ist.
6. Frage: Kann der KS10 auch mit anderen Netzteiladaptern mit Typ-C-Anschluss betrieben werden?
Antwort: Der KS10 sollte mit einem Typ-C-Adapter mit der Spezifikation 9 V / 2 A betrieben werden. Die Verwendung von Adaptern mit abweichenden Spezifikationen kann zu Gerätestörungen führen.

Tipps: So nutzen Sie die Bildschirmlesefunktion Ihres Kindle (kostenlose Hörbuchfunktion):

Schritt 1: Schalten Sie Bluetooth auf Ihrem Kindle ein und verbinden Sie ihn mit dem KS10.
Schritt 2: Navigieren Sie in den Einstellungen Ihres Kindle zu "Bedienungshilfen", wählen Sie "VoiceView-Bildschirmleser" aus und tippen Sie dann auf die Schaltfläche "Aktivieren".
Schritt 3: Nach dem Aktivieren des "VoiceView-Bildschirmlesers" ändert sich die Bedienung per Touchscreen wie folgt:
(a) Auswählen – Einfach antippen (Klick), (b) Ausfü hren/Best?tigen – Zweifach antippen (Doppelklick), (c) Fortlaufende Wiedergabe starten – Legen Sie einen Finger auf den Bildschirm und ziehe n Sie ihn in einer durchgehenden Bewegung erst nach unten, dann nach rechts, (d) Zur nächsten Seite blättern – Legen Sie zwei Finger gleichzeitig auf den Bildschirm und ziehen Sie sie nach links, bevor Sie den Kontakt lösen,
Bedienen Sie Ihren Kindle gemäß dieser neuen Bedienungsart, um zur E-Book-Leseansicht zurückzukehren, Das Buch beginnt automatisch mit der Vorlesefunktion, sobald es geoffnet wird.

- Verwenden Sie keine besonders dicke Schutzhülle oder eine Hülle mit magnetischen bzw, Metall-/Eisenplatten, da dies die Funktion des kabellosen Ladens beeinträchtigen kann,
- Legen Sie keine Fremdkörper zwischen Ihren Kindle und die Oberfläche des kabellosen Ladegeräts, einschließlich Metallauflagen von Autohaltern, Kreditkarten, Metallteilen, Schlüsseln, Münzen oder NFC-Karten, da dies zu Überhitzung führen kann,
- Verbinden Sie das kabellose Ladegerät nicht mit einem 5V/1A-Wandladegerät oder einem USB-Anschluss am Computer, da dies die kabellose Ladefunktion beeinträchtigen kann,

IHR PRODUKT & GARANTIE

365 Tage Umtausch-Garantie.
60 Tage Geld-zurü ck-Garantie.
Zusätzliche 6-Monats-Garantie.
Für eine zusätzliche Garantieverlängerung kontaktieren Sie bitte unseren Kundenservice per E-Mail.
Support-E-Mail: bzyaftersale@outlook.com.

Produktname:**Audible Book Speaker with Wireless Charging Dock**
Modell: KS10
Hersteller:**Shenzhen Yinlvmei Technology Co.,Ltd**
Adresse:**NO.77,Lijing south road,Shijing Street,Pingshan District,Shenzhen,China**

CMYK
20251227 KS10说明书20250902 英文德文 拼版630x296mm
咬合日