

TV BOX Remote Learning Function:



How to register(pair)the TV BOX Remote

Pairing a New Remote Method:

- (1) Press < **POWER** > key to turn on the TV box
- (2) Press and Hold < **OK** > key and < **VOL-** > key together for 3-5 seconds, the indicator light flashes and enters the pairing status after the pairing is successful, the indicator light will go out.

Connected New Remote with A Paired Remote

- (1) Press () key, then select **SETTING-Remotes & Accessories**.
- (2) Select Add accessory then Press OK key to confirm to pair.
- (3) Press and Hold < **OK** > key and < **VOL-** > key together for **3-5 seconds**, the indicator light flashes and enters the pairing status, after the pairing is successful, the indicator light will go out.



You can't pair until you will unpair previous remote!

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could avoid the user's authority to operate the equipment.

FCC STATEMENT

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.