



# Manual

## AIRPOWER17


MAGNETIC CHARGING POWER BANK 5000mAh



### Introduction to Regional Functions




wireless charging  
**15W**(max.)



Mobile phone charging display



Watch Charging Display



Headphone Charging Display

### INTRUCTION FOR USE

1.To charge your device, put your phone on the AIRPOWER17 Wireless Charger to automatically charge your phone (only for wireless charging devices)  
2. To charge AIRPOWER17: connect the USB-C port to the power adapter.  
The LED will gradually flash white to indicate that charging is in progress. When the 4 LEDs are all white, it means charging is completed. Please disconnect the AIRPOWER17 from the power adaptor.  
3. AIRPOWER17discharging: plug the cable into USB-C port then automatically wake up and turn on the output.  
The white LED is always on, indicating that the discharging is in progress. When 1 LED flashes, it means the battery is low.

| Indicator        | Status                       |
|------------------|------------------------------|
| 1 LED ON in blue | Wireless Charging Mode is ON |
| 4 LED ON         | Battery Level >75%           |
| 3 LED ON         | Battery Level >50%           |
| 2 LED ON         | Battery Level >25%           |
| 1 LED ON         | Battery Level >10%           |
| 1 LED Flashing   | Battery Level <10%           |

Packing Content:  
1.AIRPOWER17 Magnetic Wiresee Power Bank  
2.Manual and warranty card

O: Indicates that the harmful and toxic substance is contained in all the parts X: Indicates that the content of the harmful and toxic substance in at least the material of the part is in a homogeneous material specified in GB/T 26572, and the content exceeds the standard specified in GB/T Limit requirements The following limit requirements stipulated in the

X: Indicates that the content of the harmful and toxic substance in at least the material of the part is in a homogeneous material specified in GB/T 26572, and the content exceeds the standard specified in GB/T Limit requirements stipulated in the 26572 standard

### WARNNING

1.Do not disassemble or modify this product by yourself;  
2.Do not store this product in a humid environment;  
3.Do not place the product near a heat source or charge it near a heat source  
4. Do not allow water or other liquids to flow into the interface of this product, which may cause damage to the product; Do not use the portable power bank after it has been soaked in water.  
5.If the battery of this product swells, please stop charging or use  
6.When charging, please be sure to remove metal, magnetic protective casings or cards (such as bank cards, etc.) from your device  
7.When charging, heat may be generated, which is normal and will not affect product performance. However, if you feel that the phone or product is overheated, please disconnect the power supply, wait for it to cool down, and try to charge again  
8.Avoid to use curved or damaged USB cable;  
9.If consumers use power adapters for power supply, they should purchase matching power adapters that have obtained CCC certification and meet standard requirements.

### WARRANTY TERMS

1.Within 18 months from the date of purchase, if the product is damaged or faulty, it is confirmed by the company's technician that it has occurred under normal use, and the company will provide free maintenance services  
2.The warranty card and the original invoice must be presented during maintenance. If the user cannot provide it, the company has the right not to provide maintenance services. Users may need to pay for related maintenance costs  
3.During the warranty period, the product warranty will be automatically invalidated if the following terms appear: (a) any part of the product is deliberately disassembled or repaired by our company; (b) wrong operations such as: illegal power supply connection and water, dirt Penetrate into the product and cause damage to the product; (c) Product damage caused by irresistible accidents or natural disasters:  
4.If the warranty card is altered, the warranty card will automatically become invalid  
5. The company reserves the right to add or delete any maintenance and warranty terms without notice  
6. The company will not be responsible for any damage to mobile phones or other electronic products caused by the wrong use of the

company's product  
7.Regarding the compatibility between the original product and your mobile phone or electronic device, Please confirm with the dealer when purchasing. The specifications of this product may change at any time Furthermore, no further notice will be given;

### Schedule of Toxic and Hazardous Substances or Elements

| Part Name   | Toxic and Hazardous Substances or Elements      | ⑤ |
|-------------|-------------------------------------------------|---|
| Host        | (Pb) (Hg) (Cd) (Cr <sup>6+</sup> ) (PBB) (PBDE) |   |
| Accessories | X O O O O O O                                   | O |

Note: The reason why this product is marked with an "X" is that there are no alternative technologies or components available at this stage

FCC STATEMENT:  
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and  
(2) This device must accept any interference received, including interference that may cause undesired operation.  
Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
Reorient or relocate the receiving antenna.  
Increase the separation between the equipment and receiver.  
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement  
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

### Situations that do not fall within the scope of warranty services

- The product has exceeded the warranty period;
- Without proof of three guarantees and valid invoices, and unable to prove that the purchased product is within the validity period of the three guarantees;
- The warranty certificate does not match the product model identification or has been altered;
- Damage caused by failure to use, maintain, or maintain according to the requirements of the user manual, or the use of non original parts;
- Unauthorized repairs, modifications, misuse, collisions, drops, squeezing, liquid ingress, corrosion;
- Tearing, altering, or making it impossible to recognize product labels, seals, and serial numbers (SN);
- Damage caused by force majeure such as floods, fires, lightning strikes, etc.;
- Defects caused by normal wear and tear or aging of the product;
- Products not sold in Chinese Mainland.

**Paid service guarantee**  
If the product does not meet the warranty conditions and requires a fee, will calculate the appropriate repair fee based on the cost of parts and labor, and provide you with a repair quotation. After obtaining your consent and paying the fee, will provide repair services for your product.  
This policy is formulated strictly in accordance with the Consumer Rights Protection Law and the Product Quality Law of the People's Republic of China.

### Warranty Card

| Product Name and Model:                     | Serial number:  |
|---------------------------------------------|-----------------|
| User Name:                                  | Purchase date:  |
| Contact phone number:                       | Received on:    |
| Contact address (including postal code):    | Invoice number: |
| Sales unit name:                            |                 |
| Sales unit address (including postal code): |                 |
| Sales Unit Phone:                           |                 |

**不属于保修服务范围的情形**

- 产品超过三包有效期;
- 无三包凭证及有效发票,也无法证明所购产品在三包有效期内的;
- 保修凭证与产品型号标识不符或保修凭证被涂改的;
- 未按《使用说明书》要求使用、维护、保养,或使用非原厂配件造成的损坏;
- 非授权的维修、改动、误用、碰撞、跌落、挤压、进液、腐蚀;
- 撕毁、涂改或不能辨认产品标贴、封条及序列号(SN);
- 因火灾、火灾、雷击等不可抗力造成的损坏;
- 因产品正常磨损或正常老化导致的缺陷;
- 非中国大陆销售的产品。

**有偿服务保障**  
因产品不符合保修条件需收取费用的, 将按零部件和人工成本计算合适的维修费用, 并向您提出维修报价, 在征得您的同意并支付费用后为您的产品提供维修服务。  
本政策根据《消费者权益保护法》和《中华人民共和国产品质量法》指定。

**保修卡**

| 产品名称和型号:     | 序列号:  |
|--------------|-------|
| 用户姓名:        | 购买日期: |
| 联系电话:        | 收货日期: |
| 联系地址(含邮编):   | 发票号码: |
| 销售单位名称:      |       |
| 销售单位地址(含邮编): |       |
| 销售单位电话:      |       |

**保修政策**

感谢您选购产品, 当您在产品使用过程中,出现任何非人为损坏性能故障时, 享有的“包修、包退、包换”(简称三包)的服务承诺。为了保障您的权益, 请您在购买产品后, 妥善保管三包凭证和开具发票, 产品的三包有效期将从您收到产品(以下简称“收货”)之日起开始计算, 产品的三包有效期为18个月。

**三包服务内容**

1.自收货之日起7日内确保所收商品完好, 产品包装和配件等齐全, 无人为损坏的性能故障, 可按发票价格一次性退清货款, 或更换同型号同规格的产品, 或免费修理。  
2.自收货之日起第8日至15日内, 产品出现无人为损坏的性能故障, 可更换同型号同规格的产品, 产品更换由销售商负责。  
3.在三包有效期内, 经过两次产品更换任不能正常使用的, 经检测确认, 您可凭三包凭证中销售商提供的有效更换记录, 可选择修理或更换同型号同规格的产品。产品更换由销售商负责。

**如何获得三包服务**

为了保障您的合法权益, 需到销售商处享受三包服务。当您提出三包服务时, 您需提供:

1.所购产品原件,  
2.购买产品时的发票原件或销售商处的购买记录证明;  
3.有效三包凭证。

**有毒有害物质或元素附表**

| 部件名称 | 有毒有害物质或元素附表 |        |        |                         |            |              | ⑤ |
|------|-------------|--------|--------|-------------------------|------------|--------------|---|
|      | 铅 (Pb)      | 汞 (Hg) | 镉 (Cd) | 六价铬 (Cr <sup>6+</sup> ) | 多溴联苯 (PBB) | 多溴二苯醚 (PBDE) |   |
| 主机   | X           | O      | O      | O                       | O          | O            |   |
| 配件   | X           | O      | O      | O                       | O          | O            |   |

O: 表示该有害物质或元素在部件中所含均符合《有害物质含量限制标准GB/T 26572》的要求  
X: 表示该有害物质或元素在部件中所含均不符合《有害物质含量限制标准GB/T 26572》的要求

注: 本产品标有“X”的原因是: 现阶段没有可供选择的替代技术或部件

⑤

FCC 声明  
本设备符合 FCC 规则第 15 部分要求。设备运行需遵守以下两项条件:  
本设备不得产生有害干扰。  
本设备必须接受接收到的任何干扰, 包括可能导致非预期运行的干扰。  
警告: 未经授权合性的相关方明确批准, 对设备进行更改或改装, 可能会影响用户操作该设备的权利。  
注: 本设备已通过测试, 确认符合 FCC 规则第 15 部分中 8 类数字设备的限值要求。这些限值旨在为住宅环境中的设备提供合理防护, 避免遭受有害干扰。本设备会产生、使用并辐射射频能量。若未按照说明书要求安装和使用, 可能会对无线电通信造成有害干扰。但无法保证在特定安装环境下不会发生干扰。若本设备确实对无线电或电视接收产生有害干扰(可通过关闭并启动设备确认), 建议用户尝试通过以下一项或多项措施消除干扰:  
调整或重新放置接收天线;  
增大设备与接收器之间的距离;  
将设备连接至与接收器不同电路的电源插座;  
咨询经销商或经验丰富的无线电 / 电视技术人员寻求帮助。  
FCC 辐射暴露声明  
本设备符合 FCC 针对非受限环境设定的辐射暴露限值要求。设备安装和运行时, 辐射源与人体之间应保持至少 20 厘米的最小距离。本发射器不得与其他任何天线或发射器共置一处或协同工作。

**保修条款**

1.由购买日期起18个月内, 如产品有损坏或故障, 经本公司技术人员证实为在正常使用之情况下发生, 本公司将提供免费维修服务;  
2.维修时必须出示本保用证及购买商号之发票正本, 如果用户不能提供, 本公司有权不提供维修服务。用户可能需要支付相关维修费用;  
3.保用期内出现以下条款产品保用证自动失效: (a) 非本公司人员善意拆解或维修产品之任何部分; (b) 错误的操作如: 非法接驳电源以及水、污秽物渗入产品内导致产品损坏; (c)不可抗拒意外事件或自然灾害导致产品损坏;  
4.此保用证如经涂改,保用证自动失效;  
5.本公司有权删减任何维修及保用条款而不作通知;  
6. 如因错误使用本公司产品而导致手提电话或其他电子产品有任何损坏, 本公司不会承担任何责任;  
7.有关原装产品和您的手机或电子产品的相容性, 请在购买前向经销商确认。此产品规格随时可能变更, 恕不另行通告;

**警告**

1.请勿自行拆开或改装本产品;  
2.请勿将本产品存放在潮湿环境中;  
3.请勿将产品靠近热源或于热源附近充电;  
4.请勿将水或其它液体流入本产品介面内部, 导致本产品损坏; 移动电源浸水后, 禁止使用;  
5.如果本产品电池膨胀, 请停止充电或使用;  
6.充电时请务必从你的设备上取下金属、磁性保护外壳或卡(如银行卡等);  
7.充电时, 有可能产生热力, 此乃正常现象, 并不会影响产品表现。但如果感到手机或产品过热, 请断开电源供应, 待冷却后, 再尝试充电;  
8.避免使用屈曲或损坏的USB线材;  
9.消费者若使用电源适配器供电, 则应购买配套使用获得CCC认证并满足标准要求的电源适配器。

**如何处理废弃电子产品**

1.请勿将电子产品当成家庭废弃物丢弃;  
2.请依当地的法规规定处理废弃的电子产品;  
3.鼓励您积极参与电子产品回收计划。

**显示灯**

| 显示灯      | 状态          |
|----------|-------------|
| 1LED闪烁蓝色 | 异物侦测(请移除异物) |
| 1LED绿色亮  | 快速充电/放电     |

**产品规格**

容量: 5000mAh(19.35Wh)  
额定容量: 2800mAh  
USB-C 输入: 5V~3A/9V~2A  
USB-C 输出: 5V~3A/9V~2.2A  
手表: 2.5W/5W  
无线输出: 5W/7.5W/10W/15W  
能量转换率: > 60%  
尺寸: 103\*58.4\*8mm

温度保护:  
内置NTC温度传感器;  
当电芯温度>45℃时自动降低输出功率。

包装内容:  
1. AIRPOWER17 磁吸无线充电移动电源  
2. 说明书及保修卡


**操作**

1.为您的设备充电, 把手机放到AIRPOWER17无线充电上自动为手机充电(仅适用于兼容无线充电的设备)  
2.要给AIRPOWER17充电: 请连接USB-C插口到电源适配器。LED会逐步闪烁白色, 表示充电进行中。当4个LED均亮白色, 代表充电完成。请将 POWER17 断开电源连接。  
3. AIRPOWER17 放电: 将输出线插入USB-C自动唤醒打开输出LED白色常亮, 表示放电进行中。当1个LED闪烁, 代表电量低。

**手表充电展示**

**耳机充电展示**

**区域功能简介**



wireless charging  
**15W**(最大)

**手机充电展示**

# 使用说明书

## AIRPOWER17

磁吸 移动电源 5000mAh

