

Sports intelligent lighter
user manual

Thank you for choosing our company's smart lighter. You can comprehensively understand the usage and operation methods of the device by reading this manual.

Our company reserves the right to modify the contents of this manual without any prior notice.

The product includes: one packaging box, one instruction manual, one main unit, and one charging cable.

1. Function Description of the Button InstructionsLighter



1) When the lighter is in the screen - off state, briefly press the knob button to turn on the screen. Briefly press the knob button again to turn off the screen.

2) When the lighter is on the dial interface, double - click the knob button to enter the menu page. Continue to double - click to switch the menu style. Rotate the knob to preview the built - in dials. Long - press the long bar to quickly dial the emergency phone number (an SOS phone needs to be set and the mobile phone call Bluetooth needs to be connected for use).

- 3) .In the menu interface, rotate the rotary button to turn the page; short press any buttons to get back to the dial interface;
- 4) .In any interface, long press the rotary button for 15 seconds to force a factory reset;
- 5) .When in the second-level interface or the third-level interface, short press any buttons to return to the dial interface;
- 6) .Long - press the knob button to control the on - off of the lighter.

Charging instructions:

Magnetic charging, as shown in the following.



1.1 Shortcut Functions:

- 1)Swipe up on the dial page to display the time/date/week, current weather. You can also view the latest blood oxygen measurement value, as well as shortcut icons for music/calls/messages.
- 2)Swipe down on the dial page to enter the message page. Swipe up and down and click to view the message content.
- 3)Swipe to the right to display, time/date/week, the latest message (enter to view multiple messages)/turn on or off Bluetooth for calls and display some of the recently used menu functions.

4) Scroll up to enter the menu interface, and scroll up and down to find the corresponding function.

5) Long press the watch face to switch the watch face, select one and tap it to set it successfully.

1.2 Push message

1).When the lighter is bound to the APP and notification permissions are enabled, new messages received in the phone's notification bar will be pushed to the lighter. A total of 10 messages can be saved. Once 10 messages are stored, newly received messages will overwrite the previous ones one by one.

2) Scroll to the bottom and press the delete icon to clear all message records.

1.3 Control Center

1)On the dial page, double - click the knob button to enter the shortcut functions.

2)Swipe down to display functions such as Bluetooth connection status, menu switching, battery level, brightness adjustment, menu switching, QR code, settings, find phone, flashlight, do not disturb, and water drainage.

1.4 Phone

1)Enter the phone function and click "Turn On" to enable the call Bluetooth. Then you can see the name of the audio/call Bluetooth. Find this Bluetooth name in the phone's Bluetooth list and bind it. After the call Bluetooth is successfully connected, you can use the lighter to answer/hang up Bluetooth calls.

2)Call records: Can save the records of placed calls.

3)Dial pad: Can input phone numbers to make calls.

1.5 Message

Once the lighter is successfully bound to the APP and the corresponding notification permissions in the mobile phone system are enabled, mobile phone messages can be synchronized with the lighter.

1.5.1. Incoming call notification:

Turn on the call reminder in the APP. When the phone receives a call the lighter will ring or vibrate.

1.5.2. SMS notification:

The SMS notification can be enabled in the APP. When one or more SMS messages are received on the mobile phone, the lighter will receive one or more SMS reminders at the same time.

1.5.3. Other applications' notification:

Turn on the corresponding application notification switch in the APP, such as WeChat, QQ, Outlook, Facebook and other applications. When the mobile phone receives one/multiple application notifications, the lighter will receive one/multiple corresponding message reminders at the same time.

1.6 Frequently - Used Contacts

Can connect to the APP. In the APP, go to Device » Select Frequently - Used Contacts » Add contacts (up to 256 contacts can be added), and they can be synchronized to the lighter. The lighter can display a maximum of 256 contacts.

1.7 APP Sports Modes (Running (Outdoor Run/Indoor Run), Walking, Cycling, Mountain Climbing)

Note: This function requires connecting to the lighter.

1.7.1 Select the corresponding sports mode , and click the start button on the phone screen to enter the corresponding sports mode: After clicking the start button that is calculating the start of the sport , you can pause the sport . Long - press the end button to end the sport and save the data.

1.7.4 GPS Track. When the APP enters the sports function, the lighter will enter the GPS sports mode at the same time; after the sport ends, the GPS sports track (and other data) of the phone APP will be synchronized to the lighter for the user to view conveniently.

1.8 Heart Rate

Properly wear the lighter on the wrist, enter the heart rate menu, and you can measure the heart rate value once (please ensure it is worn firmly during measurement).

1.9 Blood Oxygen

Properly wear the lighter on the wrist, enter the blood oxygen menu, and you can measure the blood oxygen value once (please ensure it is worn firmly during measurement).

1.10 Remote Music

Connect to the APP, and you can control the phone's music to play/start/pause/previous track/next track, and the speaker sound will come from the phone. Connect to the call Bluetooth, and you can control the phone's music to play/start/pause/previous track/next track, and the speaker sound will come from the lighter.

2.0 Stopwatch

Click the stopwatch to enter the timing interface, and you can record the time once.

2.1 Weather

After the lighter is connected to the app and the data is synchronized, click "Weather" on the lighter side, and then the weather information of the day will be displayed.

Note: This function requires enabling the location permission.

2.2 Voice Assistant

After connecting to the audio Bluetooth, you can wake up the mobile phone's voice assistant (for example, it is Siri for Apple phones and the Voice Assistant for Android phones).

2.3 Calculator

Enter to perform simple calculations.

2.4 Alarm Clock

In the APP, go to Device » More, set the start and end time. The alarm clock can be set to be only once or repeat the date (week) setting. You can turn on/off the alarm clock.

2.5 Find Phone

After the lighter is bound to the app, click "Find Phone" on the lighter side, and the mobile phone will vibrate and give a ringtone prompt.

2.6 Time Zone

Can perform the countdown function, for 1 minute, 5 minutes, 10 minutes, and you can also customize the countdown time.

2.7 Countdown

Can perform the countdown function, for 1 minute, 5 minutes, 10 minutes, and you can also customize the countdown time.

2.8 Breathing Mode

There are three breathing modes: Slow, Medium, and Fast. Users can perform breathing exercises according to the selected mode.

2.9 GPS Movement Track

After entering the GPS movement track, you can view the movement data in the APP after the exercise.

2.10 Calendar

Enter the calendar function to view the current calendar.

3.1 Settings

1. Personal Information

You can view personal information.

2. Notifications

The on/off switch for notifications and the notification audio.

3. General

3.1 About This Device

Enter to view the device name, model, and MAC address.

3.2 Language

Enter to select the lighter language. Connect to the APP, sync data, and make the watch language consistent with the mobile phone language.

3.3 Date and Time

Can view the time and date. Independent of the mobile app, there is a time - setting function solely on the lighter.

3.4 QR Code

Scan the code to connect to the lighter.

3.5 Factory Reset

Click ✓ to enable the factory reset setting, and click X to cancel the factory reset setting.

3.6 Restart

Click ✓ to enable the restart setting, and click X to cancel the restart setting.

3.7 Shut Down

Click ✓ to enable the shutdown setting, and click X to cancel the shutdown setting.

3.8 Focus Mode

In the app, go to Device » More, and set the start and end time.

For example: From 12:00 noon to 14:00 is Do Not Disturb mode. During this period, the lighter terminal will not have call and message sound reminders.

3.9 Display and Brightness

Can choose multiple screen - on durations.

Can adjust the screen brightness.

4.1 App Visual Style

There are multiple styles to choose from. After setting, the menu style of the lighter will change accordingly.

4.2 Sound Feedback and Vibration Feedback

Adjust the volume level. For example, the ringtone for incoming calls and the ringtone for messages.

Silent mode is enabled by default, so only vibration will alert for incoming messages.

4.3 Password

A 4 - digit password can be set (if you forget the password, please enter 8773 to unlock).

4.4 Sps

Set the SOS emergency password. On the dial page, long - press and slide SOS to enter. Emergency calls can be made (this function requires connecting to the mobile phone audio).

4.5 Battery

You can check the battery power level and the battery power consumption situation.

4.6 Heart Rate

You can set reminders for too high or too low heart rate.

4.7 Camera Remote Control

Click the camera to wake up the lighter device's photo - taking mode. Click the photo - taking button to take a photo, and the picture will be automatically saved to the mobile phone system's photo album.



1.2 For Android users:

Search "weipofit" in Google Play or any customized Android Stores to download, pay attention to the phone pop-up box and tap "Agree" to give the permissions to the APP when installing;

1.3 For iOS users:

Search "weipofit" in APP Store to download, pay attention to the phone pop-up box and tap "Agree" to give the permissions to the APP when installing;

After weipofit is installed, the application icon is shown as:



2. Connect APP through mobile phone Bluetooth

2.1 Search for Bluetooth name to connect/pair

Search for Bluetooth connection, enter the Settings - General - About device page, swipe down, find the "Mac" address, and remember the Bluetooth name of the lighter. Then, open the weipofit APP on the mobile phone side, click the "Device" bar, click "Search to bind device" to start

searching. Find the Bluetooth name of your lighter and pair it. If the connection is successful, the Bluetooth icon of the watch will light up green (in the middle of the icon);

2.2 Scan QR code to connect/pair

Scroll down the lighter face, find the icon "About (i)" and click it, you can see a QR code for connection, then open the APP **weipofit**, click on "Device" at the bottom bar, select "Scan to bind device", the pairing box will pop up after scanning the QR code. Click "Pair" to bind the APP to the lighter. Remember to agree to the app's notification permissions on the lighter;

2.3 Connection Precautions

- 1) If you can't connect to the Bluetooth, see if you can find the Bluetooth name of the lighter in the mobile phone settings;
- 2) Check whether the permission of your mobile phone location (GPS) is enabled;
- 3) Whether the lighter has been bound by other mobile phones;
- 4) Turn off the Bluetooth on the phone and turn it on again;
- 5) Restart the phone;
- 6) Go to the Bluetooth settings on your mobile phone, find the Bluetooth name of the lighter, disconnect with the watch by forgetting the device, then go to the APP to rebind.
- 7) Too many devices connected to the mobile phone can lead to the Bluetooth connection failure of the lighter. The number of devices that can connect to a mobile phone is limited, please stay no more than 3 frequently use devices connected to the Bluetooth of a mobile phone.

3. Connect to the audio/calling Bluetooth of the lighter:

Open the Bluetooth settings of your mobile phone, swipe to the right when the lighter is on the dial interface, click the "BT call" icon, then click "Open" to see the name of the audio/calling Bluetooth. Find the Bluetooth name in the Bluetooth list of the phone and pair; after the audio/calling Bluetooth is connected, the Bluetooth icon of the lighter is displayed as (the outer periphery) lights up in blue;

Tip: Based on this connection, make sure to tap on various APP notification synchronization permissions in weipofit settings, to realize synchronously viewing of various messages from mobile phone on the lighter; to realize all connection functions (like making a phone call through watch), make sure that the lighter is connected to both the APP and the audio Bluetooth of the phone.

4. Unbind Bluetooth connection from the APP

4.1 Android system unbindBluetooth from the APP

In the "Device" column of weipofit, scroll down to the "Unbind" and click to unbind the App;

4.2 IOS system unbind Bluetooth from the APP

In the "Device" column of weipofit, scroll down to "Unbind" and click to unbind the App; then go to the Bluetooth settings of the phone, select the Bluetooth name of the smart lighter, and click "Forget this device".

5. Unbind audio Bluetooth connection

To disable the audio Bluetooth connection, find the name of the audio Bluetooth in the Bluetooth settings of the mobile phone, and click "Ignore this device" to unbind all Bluetooth connections with the lighter.

6. Find the device

The watch is successfully bound to the app. Click to find the watch on the APP, and the watch will vibrate once when the screen is on.

7. Take a photo

Tap "Take a photo" in the column of "Device" in the app to enable the camera remote control feature on the lighter. Tap the camera icon on the watch to control the phone to take a photo, and photos you take will save in the album of the mobile phone.

8. Data synchronization

The lighter is successfully bound to the APP, and the data from the lighter can be synchronized to the app.

9. Tilt your hand to wake the screen

Wear the lighter correctly on your wrist (left/right hand). When you turn on "Tilt to wake" feature on the APP, the lighter will light up automatically when you tilt your hand to look at the lighter.

10. Do not disturb mode

In the APP, tap "Device">"More">"Do not disturb mode", set the start to end time, such as 12:00 to 14:00, then you won't receive phone calls and apps notifications on the lighter during this period.

11. Daily alarm clock

In the APP, tap "Device">"More">"Alarm setting">"+", set the alarm time, and the days weekly it will repeat.

12. Sedentary reminder

Set the time period, reminder frequency, and repeat mode to decide how you would like to have sedentary reminders.

13. Drink water reminder

Set the time period, reminder frequency, and repeat mode to decide how you would like to have the drink water reminders.

14. Watch face push

14.1 Push an existing watch face

Bind the lighter and the app, open the app, tap Device> Watch face push, the watch will restart and bind the APP automatically after the synchronization of the watch face.

14.2. Customize the watch face

Bind the lighter and the app, open the app, tap Device> Watch face push, the first several watch faces marked with “custom watch faces” are customizable. The lighter will restart and bind the APP automatically after the synchronization of the watch face.

15. Firmware version

The version of the lighter is displayed “Firmware upgrade” in the column of “Device”, and users can decide to whether upgrade the firmware version.

16. QR code of Alipay payment

The lighter has the feature of Alipay, which requires the phone to scan the code to verify binding. Follow the steps below:

Click the Alipay icon on the main interface(scroll down screen) of the lighter, and complete the binding with your personal Alipay account.

●Use and maintenance advice

1. Keep the device clean;
2. Keep the device dry;
3. **Wear the lighter correctly, do not wear the device too tightly;**
4. **Avoid prolonged exposure to extreme temperatures that are too cold or too hot, which may cause permanent damage to the device.**

●Frequently asked questions and answers

***Why can't I wear the lighter to take a hot bath?**

The temperature of the bathwater is relatively high, which will produce a lot of water vapor, and the molecular radius of water vapor is small, so it is easy to **penetrate through the gap of the lighter case. When the temperature is cooling down, water vapor will turn back to the water, causing the short-circuit of the lighter possibly.**

***Unable to turn on and charge**

If the lighter does not turn on when you receive it, it may be that a collision during the transportation leads to the protection of the battery board. Charge the lighter to activate it.

If the lighter battery is too low, or can not turn on for being not used for a long time, please charge it for more than half an hour to activate it.

Warranty description:

1.If there are any quality problems caused by manufacturing, materials, design, etc. in normal use, **the motherboard of the lighter is guaranteed for repair** for free within one year, while the battery and charger within half a year from the date of purchase.

2. No warranty is provided for failures caused by the user's personal reasons, as follows:

1). Failure caused by unauthorized disassembly or **modification of the lighter.**

2). Failure caused by accidental fall during use.

3). All man-made damages or the third party's fault, or misuses (such as: water in the device, cracking by external force, scratches on the case, damage, etc.) are not covered in the warranty.

3. When requesting the warranty service, please provide a warranty card with the date of purchase and the stamp of the place of purchase on it.

4. When the user needs the device repaired, please take the device to our company or our company's dealership.

5. All functions of the device please refer to the actual product.

Purchase date:

IMEI code:

Where to buy:

Customer Signature:

Signature of Store Clerk:

Stamp of Store:

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is

subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority

NOTE: This equipment has been tested and found to comply with

the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the

interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure