无线便携式显示器
用户手册

感谢您购买此产品。
请仔细阅读本说明书，正确使用产品。

请确保将本说明书放在方便的地方，以备将来使用。

目录

1.关于你的显示器
1.1 显示器规格 02
1.2 产品清单 02
1.3 与电脑/笔记本的介绍 03

2. 连接您的显示器
2.1 连接你的显示器 04
2.2 连接操作指南 04
2.3 使用面板/多“显/现”屏幕 06
2.4 使用Win/Mac横/竖模式 07
2.5 支持的设备和型号 08

3、故障排除
故障排除 09

1、关于你的显示器

1.1 显示器规格

CPU	1.2GHz
内存RAM	Intel,DDR4,4G（512Mbps）
存储ROM	EMMC,32G
显示屏尺寸/类型	13.3英寸
显示屏比例	16:9
屏幕分辨率	1920*1080
屏幕亮度	300 cd/m²
对比度	800:1
色域	45%NTSC
显示屏技术	IPS,10点电容触摸
扬声器	2W*2
麦克风	内置
电池容量	10000mAh
电池类型	Rechargeable Li-ion/Li-Po 3.7V
摄像头	前+后
前摄像头	5M
HDR 支持度	Yes
自动旋转	Yes
认证	Yes
显示器接口	Mini HDMI,2.0mm,Audio Type-C port,*1
充电接口	Type-C port,*1

1.2 产品清单

便携式显示器

Mini HDMI to HDMI 转接线

Type-C数据线

1.3 与电脑/笔记本的介绍

型号 13.3in

- 类C口电源
- 类C口（支持OTG）
- 耳机孔
- 迷你HDMI
- 类C口（数据）
- 类C口（电源）

型号 15.6in

- 类C口电源
- 迷你HDMI
- 类C口（数据）
- 类C口（电源）

2.连接您的显示器

2.1 连接您的显示器

2.1.1 有线连接

2.1.2 笔记本电脑/台式机的连接

①将Mini HDMI连接到笔记本电脑

②将Type-C连接到笔记本电脑

③将Type-C连接到笔记本电脑

④为Mini HDMI供电

⑤将Type-C连接到笔记本电脑

⑥为Mini HDMI供电

⑦为Type-C供电

2.2 连接操作指南

2.2.1 使用 Type-C 转 USB Type-A 或 Type-C 线连接电脑和便携显示器时，请下载并安装以下应用程序：

2.2.2 将显示器连接到台式机或电脑

2.2.3 Phone/Android 手机连接到电脑或电脑

2.2.4 对于带有三个电脑/台式机的电脑，按 “Windows” + “P” 键，以便将此显示器设置为一个单独的、单独的显示器或镜像。

2.3 使用面板/多“显/现”屏幕

Windows

1.扩展显示器 选择 “扩展这些”

2.复制显示器 选择 “复制这些”

选择 “断开此显示器” 或 “扩展此显示器” 或 “仅将 2 上显示” 用于不同的模式。

如何在多个屏幕间工作窗口

- 在屏幕之间移动：选择 “显示设置”
- 在当前 1或2显示，您将看到两个小窗口表示屏幕 1 和 2。
- 单击并拖动窗口，使其移动到您想要的屏幕。

2.3.1 在不同显示屏幕间移动窗口时，请使用键盘快捷键。

2.4 使用Win/Mac横/竖模式

Mac OS

1. 系统 Logo 菜单 ，点击显示器。
2. 点击 “显示器设置...”，然后点击 “显示器”。
3. 单击横向或纵向 “旋转”，然后单击。

Windows

1. 右键单击桌面，选择 “显示设置”。
2. 在 “显示方向” 下，选择 “横向”。
3. 选择 “保存更改” 或 “还原”。

2.5 支持的设备和型号

手机（当前型号）

Wireless screen projection capability issue of the smartphones on the market, including Apple, SAMSUNG, HUAWEI, XIAOMI, OPPO, VIVO, HONOR, Nova7, etc, and which do not log in the cloud service has the same screen projection function.

笔记本（当前/未来型号）

平板、记录、录音、通话、通话、通话、通话、通话、平台、微软等更多品牌

台式电脑（无线/HDMI 连接/电缆）

无线投屏功能可用于以上所有型号的电脑，并确保您可以无线 5G 下...5+ 确定。

台式机支持有线连接（以前），有线连接可提供下述特点。

2.5.1 以前所有电脑或型号的 HDMI 端口和 Type-C 端口。

- 通过 Type-C 或 HDMI 为 Type-C 端口供电
- 通过 Type-C 或 HDMI 输出视频

2.5.2 Windows 10 或 11 操作系统

2.5.3 Mac OS 10.14 或更高版本

2.5.4 Chrome OS 88 或更高版本

2.5.5 Android 10 或更高版本

2.5.6 Linux Ubuntu 20.04 或更高版本

2.5.7 Raspberry Pi OS（基于 Debian Bullseye）或更高版本

2.5.8 Windows 10 IoT Enterprise 2021 LTSC 或更高版本

2.5.9 Windows 11 IoT Enterprise 2022 或更高版本

2.5.10 Windows Server 2022 或更高版本

2.5.11 Windows Server 2019 或更高版本

2.5.12 Windows Server 2016 或更高版本

2.5.13 Windows Server 2012 R2 或更高版本

2.5.14 Windows Server 2012 或更高版本

2.5.15 Windows Server 2008 R2 或更高版本

2.5.16 Windows Server 2008 或更高版本

2.5.17 Windows Server 2003 R2 或更高版本

2.5.18 Windows Server 2003 或更高版本

2.5.19 Windows Server 2000 或更高版本

2.5.20 Windows Server 2000 或更高版本

3、故障排除

故障排除

没有图像	检查电源是否已打开。检查电缆连接是否正确。
图像模糊	调整对比度和亮度控制。
图像抖动	检查电缆连接是否正确。
屏幕上有像素点	液晶屏幕是由数百万个像素点组成的，这是正常现象。
没有声音	检查音频电缆连接是否正确。检查音量设置。
触摸屏不工作	检查触摸屏电缆连接是否正确。

Wireless Portable Monitor
User Manual

Thank you for purchasing this product.
Please read this instruction manual carefully and use the product correctly.

Make sure to keep this instruction manual in a convenient place for future.

Contents

1. About Your Monitor
1.1 Monitor Specifications 02
1.2 Product list 02
1.3 Identifying Parts and Controls 03

2. Connecting your Monitor
2.1 Connecting your Monitor 04
2.2 Connection operation guidance 05
2.3 Using the Duplicate / Extend / Second Screen 06
2.4 Using the Portrait/Landscape Mode 07
2.5 Supported Devices and Models 08

3. Troubleshooting
Troubleshooting 09

1. About Your Monitor

1.1 Monitor Specifications

CPU	1.2GHz
RAM	Intel,DDR4,4G（512Mbps）
ROM	EMMC,32G
Display Screen Size/Type	13.3Inch
Screen Ratio	16:9
Resolution	1920*1080
Screen Brightness	300 cd/m²
Color Gamut	45%NTSC
Contrast Ratio	800:1
Touch Technology	IPS,10 Points Capacitive
Speaker	2W*2
Camera	Front+Rear
Front Camera	5M
Battery Capacity	10000mAh
Battery Type	Rechargeable Li-ion/Li-Po 3.7V
HDR Support	Yes
Auto-rotation	Yes
Certification	Yes
Monitor Interface	Mini HDMI,2.0mm,Audio Type-C port,*1
Charging Port	Type-C port,*1

1.2 Product List

Portable Monitor

Mini HDMI to HDMI Cable
For video signal transmission
Support 4K@30Hz

USB-A to Type-C Cable
For power

1.3 Identifying Parts and Controls

Model 13.3in

- Mini HDMI Port
- Type-C Port（Data）
- Type-C Port（Power）

Model 15.6in

- Mini HDMI Port
- Type-C Port（Data）
- Type-C Port（Power）

Model 17.3in

- 3.5mm Headphone Jack
- Mini HDMI Port
- Type-C Port（Power）
- Type-C Port（Data）For engineer log testing
- Mini HDMI

2.Connecting your Monitor

2.1 Connecting your Monitor

2.1.1 Wired Connection

2.1.2 Laptop/PC Connection

①Connect Mini HDMI to Laptop

②Connect Type-C to Laptop for Power

③Connect Type-C to Laptop

④Supply Mini HDMI port

⑤Connect Type-C to Laptop

⑥Supply Mini HDMI port

⑦Supply Type-C to Laptop

2.2 Connection operation guidance

2.2.1 Use Type-C to USB Type-A or Type-C cable for Power , Keep the power button is switch to on position mode.

2.2.2 Phone/Android or other pc/laptop connection

2.2.3 For wireless connection of laptop/desktop, press the "Windows" + "P" keys . Then a pop-up window will appear on the lower right corner of the computer. Click on the Wireless Display.

Note: Desktop computers need to support wifi connection function to use wireless connection.

2.3 Using the Duplicate/Extend/Second Screen

Windows

1.Right click on the desktop and select "Display settings"

2.Select "Duplicate these displays" or "Extend these displays"

Select "Duplicate these displays" or "Extend these displays" or "Show only on 2" for different Modes.

How to extend a second screen on the left side

1.Right click on the desktop and select "Display settings".

2.You will see two small windows that represent screens 1 and 2.

3.Click and drag the windows to the screen you want.

2.3.1 When moving windows between screens, use keyboard shortcuts.

2.4 Using the Portrait/Landscape Mode

Mac OS

1.Choose Apple menu > System Preferences.

2.Click Displays, then click Display. Or click "Displays".

3.Click the Rotate button. Rotation may also be automatic.

Windows

1.Right click on the desktop and select Display settings.

2.Select either the "Display orientation" options.

Selecting "Landscape" or "Portrait".

2.5 Supported Devices and Models

Phone

Wireless screen projection capability issue of the smartphones on the market, including Apple, SAMSUNG, HUAWEI, XIAOMI, OPPO, VIVO, HONOR, Nova7, etc, and which do not log in the cloud service has the same screen projection function.

Laptop

Tablet、Recording、Sound recorder、Phone、Tablet、Tablet、Tablet、Tablet、Tablet、Tablet and other brands

Desktop

Wireless screen projection for desktop computers

Supports most desktops computers on the market. Wireless connection requires that the desktop computer has Wifi functionality.

3、Troubleshooting

3.1 Check connect at the signal

1.Please use the charging cable can provide and ensure that the charging head supports 5V and 2A output.

2.Try projecting on other devices, some devices may not support it.

3.2 How to connect the monitor to laptop without HDMI port that

1.Use the wireless screen projection function.

2.Most newer laptops, such as Apple MacBook Pro, Surface Book, XPS13notebook, etc.

Most of the HDMI adapter is required to connect the monitor to your device.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. such modifications could void the user's authority to operate the equipment.

The end-user has been evaluated to meet general RF exposure requirement.

To maintain compliance with FCC's RF exposure guidelines, the distance must be at least 20 cm between the radiator and your body, and fully supported by the operating and installation configurations of the transmitter and its antenna(s).