



Usage Tip

Turn On and Off:

Turn on: Insert the cable into the USB port labeled POWER and press and hold the power button until the screen lights up.

Turn off: Press the power button until the shutdown menu appears. Follow the on-screen instructions.

USB - C Port: USB Type-C peripheral port.

NFC (Contactless Payment): When using contactless payment, place the card on the top of the device where the contactless symbol is located 

Chip card reader: Gently insert the card into the indicated slot with the chip facing upwards, following the marking on the plastic.

Specifications

Operating System: Android 13

Peripheral Port: USB C type

Usage Environment: 0 to 50 degrees

Charge: 5V-2A

Communication: 4G | Wifi | Bluetooth

FCC Regulatory Conformance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

RF Exposure

The SAR limit adopted by FCC is 1.6 W/kg averaged over one gram of tissue. The highest SAR value reported to the FCC for this device type complies with this limit.

Battery Usage Tip

1. This equipment must be connected to a grounded (three-prong) electrical outlet, in accordance with the ABNT NBR 5410 standard for electrical installations, to ensure user safety against electric shocks.
2. If you notice that the terminal battery "is not holding a charge," contact the supplier for a replacement. Only batteries purchased from official channels are recommended.
3. To replace the battery: Remove the back cover, remove the old battery by lifting the bottom first. Fit the new battery, observing the position of the pins. Dispose of the old battery in appropriate locations.
4. Do not expose the device to excessive sunlight, heat, humidity, or dust.
5. Keep the device away from liquids.
6. Do not connect any unknown material to any port on the terminal, as this may cause serious damage.
7. If the terminal is not working correctly, contact your supplier.
8. When changing the paper roll, be careful not to cut yourself on the paper cutter of the terminal (if there is a printer).
9. Use standard thermal paper to protect the printer and prevent jamming (when a printer is present)..
10. Do not expose the terminal to areas with a risk of explosion.
11. Due to exposure to radiofrequency electric, magnetic, and electromagnetic fields, this product should not be used or carried near the torso (pockets in shirts and jackets, for example).

Product: **K8**

Model: **K8**

TENG

TENG INTERNACIONAL TRADING LIMITED
4/f 299 QRC NOS 287-299 QUEEN ´S RD CENTRAL
HONG KONG

