



CPL-6682R

Neck and Shoulder Massager with Remote

Safety Instructions



Please read the following instructions carefully before massaging to ensure trouble-free operation and optimum efficiency. Please retain these operating instructions for further use!

- The massage device conforms to recognized technical principles and the latest safety regulations.
- Do not wet the device, do not use pins on it.
- The massage device is **NOT A TOY**. Close supervision is necessary when the massage device is used by , on, or near children or disabled persons.
- The massage device should never be left unattended when plugged in.
- Never use any power sources other than a standard 110V wall outlet or the 12V car adaptor provided as original equipment with this unit.
- Any possible repairs may only be carried out by authorized expert staff. Improper use and unauthorized repairs are not permitted for safety reasons and lead to loss of warranty.
- Never touch the power plug with wet hands.
- Please avoid contact of the device massage with water, high temperatures and direct sunlight.
- Do not use any damaged cables, plugs or loose sockets.
- Never operate under blankets where the air opening may be blocked.
- If plugs or cords are damaged, they must be replaced by the manufacturer, a service representative or by qualified personnel.
- In case of malfunction, disconnect immediately from the mains.
- Do not use if you have skin disorders, open wounds, or swollen or inflamed areas.
- Misuse or incorrect use excludes any liability for damage.
- Do not use this device while driving. Do not use while you sleep.
- In order to avoid excessively stimulating the muscles and nerves, the recommended massage time should not be exceeded 10 minutes at a time.
- Each massage – even a hand massage – must be refrained from during pregnancy or if one or more of the following complaints are present in the massage area: recent injuries, thrombotic diseases, all kinds of inflammations and swellings, and cancer. It is recommended to consult a doctor before having a massage for the treatment of ailments and illnesses.
- If you are dependent on electrical aids e.g. pacemakers, please be sure to consult your doctor for medical advice before taking a massage.
- The packaging material supplied should not be used as a toy.
- The device is not to be used for commercial use or medical purposes.

Have question ?



Tel: (248) 819-2623

Monday-Friday 9:00AM-4:30PM



Email: service@mycupilo.com

Instruction

Thank you for purchasing Cupilo Neck and shoulder massager with remote.
With normal care and proper treatment, it will provide years of reliable service.
Please read all instructions carefully before using this product.
Please retain this manual for future reference.


FEATURES




TECHNICAL DATA

Measurements: 43.3x7.9x5.9 inches
Weight: 2.3 lbs
Power Supply: 5V $\equiv$ 2A
Battery Capacity: 2500mAh
Timer: 10 minutes
Battery Max.runtime : $\geq$ 80 minutes
Battery Full Charging : $\leq$ 3 hours

Operation and controller instructions



Control Panel



Remote Control



①Power/OFF Button

Long press 'power' button on the control panel for 2s to turn on the massager.

Short press the 'power' button on the control panel or the 'OFF' button on the remote control to turn off the massager.

Note:The 'OFF' button on the remote control can only turn off the unit; it cannot turn on the unit.



②Mode Button

Press 'mode' button to select mode 1/2/3.

Defaults to mode 1 at startup.

Mode 1:Buzzer beeps once.

Mode 2:Buzzer beeps twice.

Mode 3:Buzzer beeps three times.



③Heat Button

Press the 'heat' button to select heat level 1/2 or to turn off the heating. The default is heat Level 1 at startup.

Level 1:The buzzer beeps once and the pink indicator lights up steadily.

Level 2:The buzzer beeps twice and the red indicator lights up steadily.

Off:One long beep, the white indicator light is steady on.



④Speed Button

Press the 'speed' button to select speed level 1/2/3.

The default is speed Level 1 at startup.

Level 1:Buzzer beeps once.

Level 2:Buzzer beeps twice.


Level 3:Buzzer beeps three times.

Battery Charging


- 1.Connect the USB cable to the appropriate port on the device.
- 2.It normally takes 3 hours to fully charge the battery.
- 3.While charging, the white indicator light on the control panel will flash, when the battery is fully charged, the white indicator light on the control panel will light up steadily.
- 4.When the battery is full, the massager can work continuously for around 80 minutes.
- 5.The device will not turn on during charging.

How to use your massager


Please use in the manner shown below



Neck&Shoulder



Waist



Neck

- 1.Remove the necklace before using it to avoid discomfort.
- 2.Don't use it when lying flat or half-lying.
- 3.Use the control panel or remote control to operate the device.
(See page 4 for control panel details).
- 4.Charge after use for next time's convenience.



- This device will switch off automatically after 10 minutes timer run out.
- Likewise, you should allow your body some rest periods. To avoid straining your muscles too much, we recommend not exceed a continuous massage of 10 minutes.
- If the massage head gets stuck, the device's buzzer will emit a prolonged beep once, then automatically turn off for safety reasons.
- When the device is turned off, long-pressing the 'OFF' button on the remote control does not turn it on; you must long-press the 'Power' button on the control panel to turn on the device.

Care and Cleaning Instructions

CARE AND MAINTENANCE

Always unplug the unit before cleaning it. Never touch the power plug with wet hands. Before cleaning, allow unit to cool.

Wipe the unit with a soft, dry cloth. Do not use cloths containing any kind of chemical or alcohol and solvent liquids.

Never submerge any part of the unit in liquid.

If the unit is particularly dirty, use the following instructions:

1. Dampen a cloth in water or a 3%–5% mild detergent solution.
2. Wipe the dirty areas with the wet cloth.
3. Clean the cloth in water and wring it out, then wipe away any remaining detergent off the surface of the unit.
4. Wipe the areas with a soft, dry cloth to dry.
5. Wait for the unit to become fully dry before use.

Place massager in a safe, dry, and cool place. Avoid contact with sharp edges or pointed objects which might cut or puncture the surface.

Removable Sleeve

- The sleeve covers the massage heads and is secured with a zipper.
- Wash in cold water with mild detergent. Allow to air dry.
- Install sleeve back onto the massage heads after it's completely dry

TROUBLESHOOTING

Problem	Solution
Massage heads rotating at reduced speed	The load on the massage heads is excessive. Reduce pressure and try again.
Device switches off suddenly.	Device may have been in use for 10 minutes. Auto-turn off function activated. Continue using by pressing the 'Power' button after resting the unit for 15 minutes.
	Over-heat protection function activated. Device is switched off for your safety. Please rest device for 15-30 minutes before restarting
	The massage head gets stuck, please unstuck the device before attempting to turn it on again.
	The battery is low, please charge in time.
Device fails to start.	Check if device has been used for more than 10 minutes. If so, let device rest for 15 minutes before continuing. Device may require longer time to cool in warmer environments
	Long-pressing the 'OFF' button on the remote controller won't turn on; long-press the 'Power' button on the control panel to turn on the device.

Safety Instructions

Remote control contains a battery, please follow below warning notice to dispose:

 WARNING	
• INGESTION HAZARD: This product contains a button cell or coin battery. • DEATH or serious injury can occur if ingested. • A swallowed button cell or coin battery can cause Internal Chemical Burns in as little as 2 hours. • KEEP new and used batteries OUT OF REACH of CHILDREN • Seek immediate medical attention if a battery is suspected to be swallowed or inserted inside any part of the body.	

- a) Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.
- b) Even used batteries may cause severe injury or death.
- c) Call a local poison control center for treatment information.
- d) Battery type: CR2025
- e) Nominal battery voltage: 3V
- f) Non-rechargeable batteries are not to be recharged.
- g) Do not force discharge, recharge, disassemble, heat above (manufacturer's specified temperature rating) or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.
- h) Ensure the batteries are installed correctly according to polarity (+ and -).
- i) Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.
- j) Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.
- k) Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.

Disposal



WARRANTY

If the product(s) is damaged or defective within a reasonable time, CUPILO offers the warranty as below.

Period	Return for refund	Return for replacement	Who paid shipping?
Within 30 Days	Yes	Yes if undamaged	Cupilo
31- 90 Days	Yes after being justified	Yes after being justified	Cupilo
91 Days - 1 Year	No	Yes after being justified	Buyer
1 Year - 3 Years	No	Only to buyers who have received extended warranty	Buyer

Cupilo warrants the product to be free from defects in workmanship and materials, under normal use, for a period of 12 months from the original invoice date, except as noted below. Cupilo products can be repaired or replaced within warranty period or returned for refund within 90 days if the products break down in the period of proper use.

The warranty extends only to consumers, NOT to any retailers or resellers. This warranty is effective only if the product is purchased and operated in the country in which the product is purchased. Warranty claims for product defects, unless extended warranty is registered, expire 12 months from the purchase day. Warranty claims CANNOT be processed for items that have exceeded the warranty period. The warranty does NOT cover the replaced, refurbished product. The warranty does have other limitations as below "Warranty Limitations". To obtain warranty service on Cupilo products, follow "Warranty Claim Procedures" below.

Warranty Claim Procedures:

1. Any product the customer believes is defective and seeks for warranty, the customer must provide to Customer Support:
 - a) Valid proof of purchase (see below the definition of valid proof of purchase);
 - b) Pictures and/or description are required to claim defective merchandise;
 - c) Model number and Series Number label attached to each product
2. If the warranty claim is justified by Cupilo Customer Support, customer(s) will obtain from Cupilo a Warranty/Return Authorization Number (RMA Number)
3. Cupilo reserves the right to specify that items be returned to the designated warehouse for inspection or be inspected by our representative in the field or be retained by customer.
4. Any claim for defective merchandise returns must be packed in original packaging
5. The item(s) will be repaired or replaced or a refund credit will be issued once the item(s) are delivered. When returning items with RMA# and a prepaid shipping label provided by Cupilo, Cupilo takes responsibility for any damage or loss incurred in transit.

Valid proof of purchase under this Warranty:

Cupilo's direct-authorized resellers, currently only at Amazon/eBay/Walmart. For product(s) obtained from other Channels, please contact the customer service of the Channel directly for appropriate solution.

WARRANTY

Warranty Limitations(this warranty does not include):

Normal wear and tear; Any condition resulting from other than ordinary residential wear or any use for which the product was not intended, such as use in rental or contract trade or commercial use; Any condition resulting from incorrect or inadequate maintenance or care; Damage resulting from misuse, abuse, negligence, accidents or shipping damage, exposed to environmental conditions temperatures, water, improper operation,improper installation, improper use of electrical supply; transportation damage; theft,vandalism or;Damage resulting from the attachment or modification of any unauthorized accessories;Fail to show the valid proof of purchase;Lost or stolen products;Items that have expired their warranty period; No quality-related issues (after 30 days of purchase);Free product/ Gift offer by Cupilo; unauthorized repairs or modification; Replaced or refurbished product.Dissatisfaction due to buyer's remorse (after 30 days of purchase).

Refund Procedures:

(Refer to <https://www.mycupilo.com>)

Warranty Disclaimer

THE WARRANTY PROVIDED HEREIN SHALL BE THE SOLE AND EXCLUSIVE WARRANTY. CUPILO SHALL HAVE NO LIABILITY FOR, AND EXPRESSLY DISCLAIMS ANY WARRANTY OR AFFIRMATION OF FACT, EXPRESS OR IMPLIED, OTHER THAN AS SET FORTH IN THIS WARRANTY STATEMENT, INCLUDING, WITHOUT LIMITATION

- (1) THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE;
- (2) ANY WARRANTY OR AFFIRMATION OF FACT RELATED TO MISUSE, IMPROPER SELECTION, RECOMMENDATION, OR MISAPPLICATION OF ANY PRODUCT; AND
- (3) ANY WARRANTY OR AFFIRMATION OF FACT THAT THE CATALOGS, LITERATURE AND WEBSITES IT PROVIDES ACCURATELY ILLUSTRATE AND DESCRIBE PRODUCTS.

Cupilo reserves all the right for final interpretation of these Terms of Warranty and Return Policy above and the aright to change, modify, add or remove portions of these terms at any time without prior notification.

Extend Warranty for Free

- 1) Visit <https://support.mycupilo.com> or scan the QR code with your purchase proof to extend warranty from 1 year to 3 years within 60 days of purchase.



- 2) Alternatively, email us at service@mycupilo.com or like our CUPILO Facebook page at <http://www.facebook.com/icupilo> for any concerns.

Your application for a free warranty extension must be completed within 60 days of purchase.

FCC ID STATEMENT

Caution: The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.

Know more about Cupilo



Address: 573 BELLEVUE RD NEWARK, DE 19713 USA

Tel: (248) 819-2623 (Monday-Friday 9:00AM-4:30PM)

Face book: <https://www.facebook.com/icupilo>

Email: service@mycupilo.com

Web: www.mycupilo.com

*Please provide your order number before contacting customer support