




## Layout Instruction (Front)

1. Swappable Large Shutter Button
2. Xenon Flash
3. 25mmx20mm Large Optical Viewfinder
4. Flash ON/OFF
5. 43mm Filter Thread
6. 35mm Fixed Lens

## Layout Instruction (Back)

1. Indication Light
2. Cold Shoe
3. Mechanical Winder
4. In Camera/Film Modes Switch
5. Filter Switch
6. 1" OLED Monochrome Screen
7. WIFI ON/OFF



# QUICK START

---

- **Charging:** Charge with USB cable until indication light turns green and battery status show full on screen.
- **Power On:** Wind the winder to turn camera on.
- **Power Off:** No power off button, camera stand by time = 3 min.
- **Flash:** Use the switch on the front of the camera to turn on/off. When turned on, the indication light will turn red.
- **Take Photos:** Wind the winder and press shutter, wind again for next shot, just like film cameras.
- **Switch Mode:** Press mode switch button (bottom right) and the white dot in screen will indicate the selected shooting mode (Film mode or In camera mode).
- **WIFI ON/OFF:** Long press "WIFI" button (bottom left) to turn on/off WIFI when need to connect with filter app.
- **Filter Slider:** Slide up and down to switch filters (3 filters: apply to both in camera mode and film mode).

---

**For detailed instruction, help to check on [Rewindpix.com](http://Rewindpix.com)**

## FCC Warning:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC warning:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

## IC Warning:

- English:

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s).

Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

- French:

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- 1) L'appareil ne doit pas produire de brouillage;
- 2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

L'appareil a été évalué pour répondre aux exigences générales d'exposition aux RF. L'appareil peut être utilisé sans restriction dans des conditions d'exposition portables.

## **Warning**

When using the battery, please ensure the following matters :

- replacement of a battery with an incorrect type that can defeat a safeguard;
- disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion;
- leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas; and
- a battery subjected to extremely low air pressure that can result in an explosion or the leakage of flammable liquid or gas.

## **CAUTION**

Risk of fire or explosion if the battery is replaced by an incorrect type.