



ITM./ART. XXXXXXX
Model # NTL152RD-UL-3

IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.

Thank you for purchasing this Dawnrise 9 in 1 Multi Use LED Light. Please read all instructions before using your new LED Lights.

IMPORTANT: FOR INDOOR AND DRY LOCATION USE ONLY.

PACKAGE CONTENTS




3 LED Lights



3 Charging Bases

SPECIFICATIONS

Finish Color: Silver
Dimensions: 14 x 4.5 x 4.9 cm / 5.51 x 1.77 x 1.92 in
Charging time: ~10 hours
Battery type: Built-in rechargeable 3.7V 500 mAh Li-ion battery
Runtime for power failure light:
Rating: 120VAC, 60Hz, max 1.5W



HOW TO CHARGE

Plug the LED light into a wall socket (up right [FIG.1] or down facing [FIG.2])
Charge for 24 hours before first use.

FIG.1





FIG.2



OPERATION

When the light is attached to charging base:

1.The panel light will turn on for 10 seconds to detect ambient light and turn off. The light will automatically turn on when it detects human presence within its sensor range if there is lack of ambient light, it will stay on continuously as long as presence continues. And will automatically turn off after 30 seconds of no human presence is detected or when there is sufficient ambient light.

2. Short press  : Adjusts brightness cycles through 3 levels: roughly 100%→ 50%→10% .

3. Short press  : Cycle through 2700K warm white and 12 RGB colors.

4. Long press  : Activate RGB gradient cycle mode. Short press again to select and lock the current color.

5.Charging base built-in night light function:

When the charging base is plugged into wall socket, the light will automatically turn on when there is lack of ambient light, and will automatically turn off when there is sufficient ambient light.

OPERATION

When the light is separated from charging base or AC power outage:

1.The flashlight will turn on for 60 seconds to detect ambient light and turn off. The light will automatically turn on when it detects human presence within its sensor range if there is lack of ambient light, it will stay on continuously as long as presence continues. And will automatically turn off after 30 seconds of no human presence is detected or when there is sufficient ambient light.

2.Short press  : cycle through 4 modes:

Panel light → Flashlight → UV light → Panel Red light SOS Emergency Flash → Off

3.Mode Button  Functions , function varies by current light mode:

(1).Panel Light Mode

Short press : Cycle through 2700K warm white and 12 RGB colors.

Long press: Activate RGB gradient cycle mode. Short press again to select and lock the current color.

(2).Flashlight / UV Light / Red SOS Flash Mode

Mode Button has no response when these modes are active.

SAVE THESE INSTRUCTIONS

MAINTENANCE INSTRUCTIONS

To clean, disconnect from the outlet and turn off the product.
Wipe with a soft dry cloth. Do not use any cleaner with chemicals, solvents, or harsh abrasives.
Recharge every 3 months if stored long-term to preserve battery life.

IMPORTANT SAFETY INSTRUCTIONS

This device complies with Part 18 of the FCC Rules.

FCC Radiation Exposure Statement:
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This Device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING

When using this product, basic precautions should always be followed, including the following:

- Changes or modifications to this unit for compliance could void the user's authority to operate the equipment.
- Do not contact hot parts.
- To reduce the risk of injury, close supervision is necessary when the product is used near children.
- Only use attachments recommended or sold by the manufacturer.
- Do not use in the rain.
- To reduce the risk of electrical shock, do not put light in water or other liquid. Do not place or store product when it can fall or be pulled into a tub or sink.
- To reduce the risk of injury, do not stare at operating lamp. Serious eye injury could occur.
- Non-rechargeable batteries are not to be recharged.
- Do not dispose of batteries in fire. Batteries may explode or leak.

CAUTIONS

- Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- Do not modify, disassemble, open, drop, crush, puncture, or shred battery.
- Do not expose the product to rain or water.
- Products are for indoor and dry location use only.
- Avoid exposure to high temperature and direct sunlight.
- Risk of fires and burns. Do not open, crush, heat, or incinerate.
- Keep product away from open flames to prevent heat build-up.
- This product is not a toy, keep away from children.
- Do not short-circuit the battery.
- In the event of a battery leaking, do not allow the liquid to come in contact with the skin or eyes
- Extreme cold and hot weather conditions will reduce the battery performance.
- Charging time may vary depending on remaining charge, battery age and ambient temperature.
- Product should not be left discharged for an extended period.
- Product should not be charged while in contact with flammable material like textiles.

BATTERY DISPOSAL

The product contains a rechargeable battery which must be recycled or disposed of separately from household waste. Dispose of batteries according to your local environmental laws and guidelines. Do not incinerate the battery. Call a local poison control center for treatment information in case of accidental battery ingestion.

TROUBLESHOOTING

Problem	Possible Cause	Solution
The light will not turn on.	The light needs recharging.	Charge the light.
	Light is damaged.	Return the light for a replacement if it's still within the warranty period.
The light cannot be charged.	USB connection is poor.	Properly reconnect the USB-C charging cable.
	The Li-battery is damaged.	Charge the light every three months. Not charging it for a long time will damage the Li-battery.
The button is not working.	The press button is damaged.	Use Remote to control the light or return the light for a replacement if it's still within the warranty period.

LIMITED WARRANTY

1 Year Limited Warranty:

DDAWNRISE INC warrants the enclosed product (excluding batteries) to be free from defects in material and workmanship under normal use for a period of 1 year from the original date of consumer purchase. This warranty is limited to the repair or replacement of this product only and does not extend to consequential or incidental damage to other products that may be used with this unit. To make a claim, please contact customer_service@dawnrise.com, after-sales services if any, or return the complete product to the place of purchase.

Customer Service:

Contact us at 1-888-778-0082 between 8:30AM-5:00PM PST Monday- Friday,
or contact us @ customer_service@dawnrise.com. English-only support is available.



Distributed by:
Costco Wholesale Corporation
P.O. Box 34535
Seattle, WA 98124-1535
USA
1-800-774-2678
www.costco.com

Dawnrise Inc.
6215 Regency Parkway NW
Suite 910
Norcross, GA 30071 U.S.A.
Made in Thailand