

A white, futuristic, egg-shaped device with a small screen displaying a landscape image. The device has a rounded, pill-like shape with a small screen on the front showing a scenic view of mountains and a lake. The top of the device is open, revealing two large, white, earbud-like components inside. The overall design is sleek and modern, suggesting a high-tech or futuristic theme.

PRODUCT FEATURES

- Bluetooth version : 6.0
- Voice assistant compatible: siri
- Touch control : music play/pause, next/last track,
- Volume +/-, accept/end/reject call, voice assistant,
- music-game mode/ANC Mode
- Charging port : Type-C
- Support ANC technology
- With touch LCD screen / Hall switch on/off

Bluetooth version	6.0
Support	A2DP,AVRCP,HSP,HFP
Bluetooth Frequency	20HZ-20KHZ
Bluetooth range	10m
Earbuds battery	30mAh
Charging case battery	400mAh
Charging time	1.5-2hrs

The product contains the following contents
If any of the following items are missing,
please contact us immediately

S/N	Items	Qty
1	True Wireless Earbuds Unit	1
2	Type-C Charging Cable	1
3	User Manual	1
4	L Size Eartip	2
5	S Size Eartip	2

Special power storage mode:
please charge the case with
the charging cable, the screen
will light up after 2s to exit the
storage mode.



Power OFF: Put both earbuds into the charging case, and close the charging case, both earbuds will power off automatically

1. Open the charging case, earbuds will TWS pair automatically.
2. Turn on Bluetooth on your device, then you can search "RS3304492" and click it to connect.

Tips: Earbuds will automatically power off if don't connect with any device within 5mins.

Tips: Earbuds will automatically power off if don't connect with any device within 5mins.

Play/Pause, Previous Song / Next Song, Volume+/-, ANC Mode, Equalizer Setting, Alarm Setup, Time Setup, Adjust Light Level, Language Switch, Screen Lock , Find My Earphone, Camera Control

Note: Control functions may vary as per the device connected.

Click four times MFB on L/R earbud

Triple click MFB on L earbud

Triple click MFB on R earbud

Long press MFB for 2 seconds
on L earbud

Long press MFB for 2 seconds on R earbud to change Normal Mode- ANC On -Transparency Mode

6 times click MFB on L and R earbud at the same time

Note: Control functions may vary as per the device connected.

Single click MFB on L/R earbud

Single click MFB on L/R earbud

Double click MFB on L/R earbud

Long press MFB for 2 seconds
on L/R earbud

Double click MFB on R earbud

Double click MFB on L earbud

1. Earbuds should be stored in a dry and ventilated environment to avoid contact with oil, steam, moisture, dust, etc., to avoid affecting product performance.
2. Avoid using irritating organic solvents or items containing these ingredients to clean earbuds.
3. Earbuds should be used correctly and in a standardized manner as required, and attention to the impact of the use environment as well. To ensure smooth connection, the distance between the phone and earbuds should be within 10 meters.
4. If earbuds has other problems such as poor connection or communication, please do not disassemble the earbuds body and accessories without permission, otherwise the warranty will not be granted.
5. Please choose a standard car charger or a qualified charger designated by our company to charge the earbuds.
6. To ensure your normal use of earbuds, please ensure that the earbuds has sufficient power.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

(1) this device may not cause harmful interference

(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses,

and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does

cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on,

the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.