

< Light Stick Manual >

EN ver

Battery Insertion and Replacement Instructions

1. Turn the cap at the bottom of the handle and remove the socket inside.
2. Insert 3 AAA batteries into the battery socket.
(Be sure to check the + and – terminals when inserting the batteries.)
3. Insert the battery socket in the direction indicated by the arrow and turn the cap to close it.
(If the battery socket is inserted upside down, the product will not operate and may be damaged, so please be careful.)

C-Type Power Port

1. Connecting a cable to the C-Type port on the side of the light stick will supply power to the device.
2. It is recommended to use a C-Type cable with a ferrite core (a material that surrounds the wire to form a constant magnetic field).
3. Use a power source rated at 5V / 2A or lower; fast chargers are not allowed.
4. This light stick does not contain a built-in battery and does not support charging.

User Manual

1. **Button Operation:** You can change the LED modes using the power button.
 - **Normal Mode:** 1 Press 1×POWER ON → White → 2 presses → Yellow → 3 presses → Deep Blue → 4 presses → Pink → 5 presses → Red → 6 presses → Aqua Blue → 7 presses → Green → 8 presses → Purple → 9 presses → OFF
 - **APP Connection Mode:** Press the power button twice consecutively (blue blinking light).
 - **Central Control Mode:** The mode automatically changes during concerts.
(Before the performance, please disconnect from your smartphone.)
2. **Connect your smartphone to the light stick to use software updates and mood lighting features.**

2-1. APP Download

1. **QR Code:** Scan the QR code at the bottom to download the app.
2. **Direct Link:** Visit the app download page.
3. **App Usage:** Detailed instructions are available in the FAQ section within the app.

2-2. APP Connection and Software Update

4. Turn on the Bluetooth function on your smartphone. (For Android users, allow location permission if prompted.)
5. With the light stick turned on, press the power button twice consecutively. The blue light will blink, indicating it is ready for Bluetooth connection.
6. Open the app and tap the “Connect Light Stick” button. The connection will proceed automatically.
 - **Note:** When connecting, the app will check the software version of the light stick. If it is not the latest version, follow the on-screen instructions to update.

2-3. Mood Light Mode: You can freely change the mood light colors through the app.

3. Central Control Mode

0. **In the Concert Venue:** When the light stick is turned on, it operates in sync with the central control system of the concert without any additional connection.

FCC Notice

“This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.”

b. Rule Part 15.21: The user manual or instruction manual for an intentional or unintentional radiator shall caution the user that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help