



NOVOO Smart Tag

USER MANUAL

NATS-101C



Works with

Apple Find My

HOW TO ADD ITEMS (iOS)

Requires: iOS or iPadOS with the latest version installed

1. Place the Smart Tag next to your iPhone or iPad.
2. Press the button and you will hear four beeps (Di-Di-Di-Di).ready to pair.
3. Turn on Bluetooth on your device.
4. Open the **Find My** app on your iPhone or iPad.
5. In the **Find My** app, tap **Items > Add Item > Other Supported Item**.
6. Tap **Continue**.
7. Enter a name for your Finder, then tap **Continue**.
8. Choose an emoji.
9. Tap **Continue**, then **Finish** to complete the pairing process.
10. The device will successfully pair after two beeps.
11. Once paired, you can view the device's location and serial number, or remove it from the app if needed.

HOW TO REMOVE ITEM

To use the tag with another smartphone, you must first remove it from the currently connected iOS **"Find My"** app.

Tap the settings icon, then select **"Remove Item"** (for iOS).
A long beep will indicate the item has been successfully removed.

After removal, wait about 5 minutes for a pairing notification to appear on your phone.

Tip: If the tag is not near your smartphone, the removal may fail. In that case, the tag cannot be added to another phone. Please perform a factory reset.

FACTORY RESET

Press the button 3 times quickly, then press and hold once more until you hear a long beep.


SPECIFICATIONS

Product Name	NOVOO Smart Tag
Model Name	NATS-101C
Range	≥40m(≥131 feet) depending on environment
Temperature	-15°C to +50°C (5°F to 122°F)
Operating Frequency Band	2.4GHz
Alarm	60-80dB
Material	PC & Silicon
Dimensional Size	32*31.5*9mm
Maximum radio-frequency power transmitted	6.88 dBm

BATTERY

The unit contains a coin cell battery. The battery may need to be replaced during the life of the product. Replace only with the same type(CR2032) and rating of battery by observing the correct negative & positive connection.

How to replace a battery



Use a tool to rotate the cover 30° to open the battery compartment.

Compliance Content

FCC Compliance Statements

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.



The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. Any use of such marks by Wellmade Corporation Limited is under license. Other trademarks and trade names are those of their respective owners."

*Requires Android™ 9 phones and above

*Must be within 40 meters of any Android device.

*Google Find My Device, Android are trademarks of Google LLC.

*a) Battery type CR2032, and b) Nominal voltage 3Vdc.

WARNING:

KEEP new and used batteries OUT OF REACH of CHILDREN

Seek immediate medical attention if a battery is suspected to be swallowed or inserted inside any part of the body.



EN: The symbol on the product or its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate

collection and recycling of your waste equipment at the time of disposal will help conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste for recycling, please contact your local authority.

DE: Das Symbol auf dem Produkt oder seiner Verpackung weist darauf hin, dass dieses Produkt nicht mit dem normalen Hausmüll entsorgt werden darf. Stattdessen liegt es in Ihrer Verantwortung, Ihr Altgerät zu entsorgen, indem Sie es an einer dafür vorgesehenen Sammelstelle für das Recycling von Elektro- und Elektronik-Altgeräten abgeben. Die getrennte Sammlung und das Recycling Ihres Altgeräts zum Zeitpunkt der Entsorgung tragen zum Schutz natürlicher Ressourcen bei und stellen sicher, dass das Recycling auf eine Weise erfolgt, die die menschliche Gesundheit und die Umwelt schützt. Weitere Informationen dazu, wo Sie Ihren Abfall zum Recycling abgeben können, erhalten Sie bei Ihrer örtlichen Behörde.

FR: Le symbole présent sur le produit ou sur son emballage indique que ce produit ne doit pas être jeté avec vos autres déchets ménagers. Au lieu de cela, il est de votre responsabilité d'éliminer vos déchets d'équipements en les remettant à un point de collecte désigné pour le recyclage des déchets d'équipements électriques et électroniques. La collecte séparée et le recyclage de vos équipements usagés au moment de leur élimination contribueront à préserver les ressources naturelles et garantiront qu'ils sont recyclés d'une manière qui protège la santé humaine et l'environnement. Pour plus d'informations sur l'endroit où vous pouvez déposer vos déchets pour le recyclage, veuillez contacter votre autorité locale.

ES: El símbolo en el producto o en su embalaje indica que este producto no debe desecharse junto con otros residuos domésticos. En cambio, es su responsabilidad deshacerse de su equipo de desecho entregándolo a un punto de recolección designado para el reciclaje de equipos eléctricos y electrónicos de desecho. La recogida y el reciclaje por separado de los equipos usados en el momento de su eliminación ayudarán a conservar los recursos naturales y garantizarán que se reciclen de forma que se proteja la salud humana y el medio ambiente. Para obtener más información sobre dónde dejar sus residuos para reciclarlos, comuníquese con su autoridad local.

IT: Il simbolo sul prodotto o sulla sua confezione indica che questo prodotto non deve essere smaltito con gli altri rifiuti domestici. È invece tua responsabilità smaltire le tue apparecchiature di scarto consegnandole a un punto di raccolta designato per il riciclaggio dei rifiuti di apparecchiature elettriche ed elettroniche. La raccolta separata e il riciclaggio delle apparecchiature usate al momento dello smaltimento contribuiranno a preservare le risorse naturali e a garantire che vengano riciclate in modo da proteggere la salute umana e l'ambiente. Per ulteriori informazioni su dove depositare i rifiuti per il riciclaggio, contattare l'autorità locale.

NL: Het symbool op het product of de verpakking geeft aan dat dit product niet met ander huishoudelijk afval mag worden weggegooid. In plaats daarvan is het uw verantwoordelijkheid om uw afgedankte apparatuur weg te gooien door deze in te leveren bij een aangewezen inzamelpunt voor de recycling van afgedankte elektrische en elektronische apparatuur. Gescheiden inzameling en recycling van gebruikte apparatuur op het moment dat deze wordt weggegooid, draagt bij aan het behoud van natuurlijke hulpbronnen en zorgt ervoor dat deze wordt gerecycled op een manier die de menselijke gezondheid en het milieu beschermt. Voor meer informatie over waar u uw afval kunt inleveren voor recycling, kunt u contact opnemen met uw plaatselijke overheid.

PL: Symbol znajdujący się na produkcie lub jego opakowaniu wskazuje, że tego produktu nie wolno wyrzucać razem z innymi odpadami domowymi. Zamiast tego Twoim obowiązkiem jest utylizacja zużytego sprzętu poprzez przekazanie go do wyznaczonego punktu zbiórki w celu recyklingu zużytego sprzętu elektrycznego i elektronicznego. Selektywna zbiórka i recykling zużytego sprzętu w momencie jego utylizacji pomoże chronić zasoby naturalne i zapewni jego recykling w sposób chroniący zdrowie ludzkie i środowisko. Aby uzyskać więcej informacji na temat miejsc, w których można dostarczać odpady do recyklingu, należy skontaktować się z władzami lokalnymi.

SE: Symbolen på produkten eller dess förpackning anger att denna produkt inte får slängas med annat hushållsavfall. Istället är det ditt ansvar att kassera din förbrukade utrustning genom att lämna in den till en utsedd insamlingsplats för återvinning av avfall från elektrisk och elektronisk utrustning. Separat insamling och återvinning av använd utrustning vid tidpunkten för kassering kommer att bidra till att bevara naturresurser och säkerställa att den återvinns på ett sätt som skyddar människors hälsa och miljön. För mer information om var du kan lämna ditt avfall för återvinning, kontakta din lokala myndighet.



Hereby, Wellmade Corporation Limited declares that the Radio equipment NFT1-206G in compliance with Directive 2014/53/EU requirements, the full text of the declaration of conformity are available at the following internet address: www.novoo-online.com

This product contains a replaceable and non-rechargeable DC 3V CR2032 coin battery, please attention below warnings:

- Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.
- Even used batteries may cause severe injury or death.
- Call a local poison control center for treatment information.
- Non-rechargeable batteries are not to be recharged.
- Do not force discharge, recharge, disassemble, heat above 100°C or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.
- Ensure the batteries are installed correctly according to polarity (+ and -).
- Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.
- Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.
- Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.

Disclaimer: This is neither an anti-theft nor an anti-lost device.

This device provides the last detected location.

WARNING

- **INGESTION HAZARD:** This product contains a button cell or coin battery.
- **DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause **Internal Chemical Burns** in as little as 2 hours.
- **KEEP** new and used batteries **OUT OF REACH** of **CHILDREN**.
- **Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body.



No obvious symptoms

Unfortunately, it is not obvious when a button or coin battery is stuck in a child's oesophagus(food pipe).

There are no specific symptoms associated with this. The child might:

- cough, gag or drool a lot;
- appear to have a stomach upset or a virus;
- be sick;
- point to their throat or stomach;
- have a pain in their abdomen, chest or throat;
- be tired or lethargic;
- be quieter or more clingy than usual or otherwise "not themselves";
- lose their appetite or have a reduced appetite; and
- not want to eat solid food / be unable to eat solid food.

These sorts of symptoms vary or fluctuate, with the pain increasing and then subsiding.

A specific symptom to button and coin battery ingestion is vomiting fresh (bright red) blood. If the child does this seek immediate medical help.

The lack of clear symptoms is why it is important to be vigilant with "flat" or spare button or coin batteries in the home and the products that contain them.



WARNING

- Do not ingest battery, Chemical Burn Hazard.
- This product contains a coin / button cell battery. If the coin / button cell battery is swallowed, it can cause severe internal burns in just 2 hours and can lead to death.
- Keep new and used batteries away from children.
- If the battery compartment does not close securely, stop using the product and keep it away from children.
- If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.
- Please do not expose the product to any mechanical stress or impact.
- Do not attempt to disassemble the battery.
- This product is not a toy or edible. When using the tool, the sharp part of the specified tool should only face the gap, be careful not to hurt your fingers.
- Risk of fire or explosion if the battery is replaced by an incorrect type.
- Replacement of a battery with an incorrect type that can defeat a safeguard;
- Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion;
- Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas;
- A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.



BATTERY WARNING

KEEP OUT OF REACH OF CHILDREN

Swallowing can lead to chemical burns, perforation of soft tissue, and death. Severe burns can occur within 2 hours of ingestion. Seek medical attention immediately.



BATTERY WARNING: KEEP OUT OF REACH OF CHILDREN

If the battery compartment (if applicable) does not close securely, stop using the product and keep it away from children. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.

To use the Apple Find My app to locate this item, the latest version of iOS, iPadOS, or macOS is recommended.

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are trademarks of Apple Inc., registered in the U.S. and other countries. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.