

支架无线充电器说明书



型号: F-180

包装内容

无线充电器x1
USB数据线x1
用户手册x1

技术参数

充电方式: 近距离电磁感应
输入电源: 9.0V/1.67A; 5.0V/2.0A; 12V/2.0A
无线输出: 5.0V/1.0A; 9.0V/1.1A; 12V/1.25A
有效距离: 1mm~8mm

这是一款用于智能手机的便携式无线充电器。
为了使您更好的使用无线充电器, 请仔细阅读
本手册。

充电方式

将带有无线充电功能的手机放置于无线充电器的正中心, 当手机发出充电提示时, 即为正常工作, 如果未发出充电提示时, 请将手机重新对位无线充电器。

安全提示

携带和使用无线充电器为你的手机充电。无线充电器具有敏感元件, 不能摔、打、或剧烈震动, 不可在微波炉、烘烤机中烘烤, 否则, 内部部件和结构将受到损坏, 如果产品破损, 请不要继续使用。如果产品暴露于任何可能引起污染的污染物, 如油墨、染料、化妆品、灰尘、食物、油、洗液等, 请立即清洗, 如果清洁请去除连接到这个产品的所有电缆, 使用柔软, 轻微潮湿的绒布擦拭。不要使用窗户清洁剂, 家用清洁剂、喷雾器、溶剂、酒精、氨水或研磨剂来清洁本产品。避免放在有水或潮湿的地方。不要将产品暴露在有水或潮湿的地方使用, 小心不要在产品上洒任何食物或液体, 如果产品进水, 取下所有电缆, 然后清洁, 直到完全干了才能使用, 不要使用外部热源(如微波炉或吹风机)烘干产品。接触液体损坏超出保修范围。

警告

不要试图修理或修改产品。除包装外, 产品不包含任何由用户可修理的部件, 拆卸产品(包括外部螺丝和拆卸后盖)可能导致损坏, 超出保修范围。如果产品进水, 破损, 或严重变形, 请不要使用它。只有制造商或授权服务供应商才能修理。如果您有任何问题, 请联系您的经销商。



Stand Wireless Charger Manual



MODEL: F-180

Package contents

Wireless Charger x1
USB data cable x1
User manual x1

Technical parameter

Charging mode: short range electromagnetic induction
Input: 9.0V/1.67A; 5.0V/2.0A; 12V/2.0A
Output: 5.0V/1.0A; 9.0V/1.1A; 12V/1.25A
Effective distance: 1mm—8mm

It's a portable wireless charger for smartphones.
In order to make better use of your wireless charger,
please read this manual carefully.

Charging mode

Place the mobile phone with wireless charging function in the center of the dry wireless charger. When the mobile phone sends a charging prompt, it is considered to work normally. If it does not send a charging prompt, please reposition the mobile phone to the wireless charger.

Safety tips

Carry and use a wireless charger to charge your phone. Wireless charger has sensitive components, do not drop, beat or violent vibration, do not bake in the microwave oven, baking machine, otherwise, the internal components and structure will be damaged, if the product is damaged, please do not continue to use. If the product is exposed to any contaminants that may cause contamination, such as ink, dye, cosmetics, dust, food, oil, lotion, etc., wash immediately. If clean, remove all cables connected to the product and wipe with a soft, slightly damp flannel. Do not use window cleaners, household cleaners, sprayers, solvents, alcohol, ammonia or abrasives to clean this product. Avoid places with water or humidity. Do not use the product exposed to water or damp, be careful not to spill any food or liquid on the product, if the product has water, remove all cables, then clean the product until it is completely dry, and do not dry the product with an external heat source such as a microwave or hair dryer. Contact liquid damage beyond warranty coverage.

Warning

Do not attempt to repair or modify the product. Apart from the packaging, the product does not contain any parts that can be repaired by the user, and removing the product (including external screws and removing the back cover) may result in damage beyond the warranty. If the product is flooded, damaged, or severely deformed, do not use it. Only the manufacturer or authorized service provider can repair. If you have any questions, please contact your dealer.



FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance, could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF exposure statement:

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance between 20cm the radiator your body.