


# FIFA AI SMART BADGE



**Quick Start Guide**  
**F26E13**

## Product Specifications

Product Name: FIFA AI SMART BADGE

Model: F26E13

Version: 6.0

Range:  $\geq 10\text{m}$

Battery Capacity: 600mAh

Rated Input Voltage: 5V  300mAh

Battery Type: Li-Polymer Battery,

Standard Voltage: 3.7V

Usage time: About 6 H


Charging Time: About 2H



# What's in the box



FIFA AI SMART BADGE



Magnetic clip






Quick Start Guide



USB-C cable

# Components



# Instructions

EN

## 1.Power On:

Long press the power key for about 5 seconds to power on.

## 2.Power Off:

Long press the power key for about 2 seconds until the three icons—'Power Off', 'Restart', and 'Factory Reset'—pop up. Then, tap the 'Power Off' icon to shut down.

## 3.Restart:

Long press the power key for about 2 seconds until the three icons—'Power Off', 'Restart', and 'Factory Reset'—pop up. Then, tap the 'Restart' icon to reboot automatically.

## 4.Factory Reset:

Long press the power key for about 2 seconds until the three icons—'Power Off', 'Restart', and 'Factory Reset'—pop up. Then, tap the 'Factory Reset' icon to restore the device to its factory settings.

## 5.Voice Dialogue:

When connected to the APP, double-click the power key to enter the voice dialogue interface.Or swipe up to enter the conversation interface.

**6.When Disconnected:** Double-click the power button to access the app download QR code.

**7.Swipe down for controls:** View battery level and adjust screen brightness.

**8. Main interface wallpaper:** Swipe left or right to switch wallpaper effects.

**Note:** After restoring the device to factory settings, iOS requires manually unpairing it from Bluetooth and then re-establishing the connection.

# Installing Software



Android Download




ISO Download



Scan to Download the App

# Software Connection and Usage

1.Go to the home page in the app to connect your device. Tap on the device named "FIFA-F26E13" to connect.Or tap the scan icon in the upper right corner to scan the QR code and connect.



2.Open your phone to connect the device, search for the device named "FIFA-F26E13". Once successfully connected, return to the app interface.





# Connection Successful

EN

Access the main app interface as shown below.



You can freely choose the audio playback source: wireless device or phone speaker.



# AI Conversation


Tap "I'm Saymi" to start an AI conversation. Alternatively, double-click the device's power button for the same function.

Click the icon  to access the delete option.



# Personalized wallpaper

1. Online Wallpaper: Select your favorite themes.
2. Video: Tap "+" to choose from the album/file manager. (Up to 5 historical videos can be saved.)
3. Single Image: Tap "+" to choose from the album/file manager. Stickers are also available for image editing. (Up to 5 historical images can be saved.)
4. Multiple Images: Tap "+" to choose 1–10 images from the album/file manager. (Up to 5 multiple-image AVI files can be saved.)



# Display Screen Features

## Wallpaper Interface



Swipe left or right to change the wallpaper, and delete the current one by long-pressing the home screen for 2 seconds.

# Chat Interface

EN



In a Chat



Listening...

## Battery Level / Brightness Control



At the top - Battery level  
At the bottom - Brightness control

## Power-off screen



Factory Reset / Restart  
/ Power Off

**1. Do I need to connect Bluetooth from the phone settings first?**

No, you only need to connect via the APP. Remember to click "Pair".

**2. Is "Saymi" the only option for switching audio playback?**

Yes, the audio playback switch in the APP interface is only for the "Saymi" audio output port. Please disconnect the "Saymi" connection first if other APPs need to change the audio output port.

**3. Does "Saymi" have a memory function?**

Currently, it does not. The previous memory is not supported for storage after each restart of the conversation.

**4. What can "Saymi" do?**

At present, "Saymi" can provide mutual translation in 60 languages (you can do this by issuing the command "Enter translation mode"), knowledge Q&A (equivalent to an "encyclopedia"), and companion mode (playing games and adventures together, and it can also tell you stories)...

**5. Why didn't my wallpaper upload succeed? It shows insufficient memory.?**

Uploading videos consumes a significant amount of memory. If you have insufficient space, you can try pressing and holding an unwanted wallpaper for 2 seconds to delete it, freeing up space before re-uploading.

**6. Why can't my device connect/pair?**

Due to the Bluetooth auto-reconnection mechanism, the device failed to pair. To resolve this, clear the historical connection records in both your phone and the APP, or perform a factory reset on the device.

The development of Saymi's functions has never stopped. Feel free to use your imagination and put forward your needs—we are always here!

# Important Safety Instructions

Carefully read all the safety instructions in this document before using the product.

## General safety instructions

- Use the product with care and store it in a clean environment that is free from extreme temperature, pressure, and humidity. Make sure that the product is stored in a location where it cannot be bent or squeezed.
- Repairs and replacements should only be performed by authorized after-sales service staff. Do not attempt to disassemble or replace any part of the product yourself to prevent injuries or damage to the device. Any unauthorized modification to the product voids the warranty.
- Only use the product in environments where Bluetooth transmission is permitted.

## Personal safety instructions

- Do not use the product if it is obviously defective or exhibits abnormalities such as bulging or excessive heating.
- Do not use the product when performing high-risk tasks that require your full attention.
- For your hearing protection, do not listen at high volume for long periods.
- Keep the product and its packaging out of reach of children and pets to prevent accidents such as swallowing and choking.

## Battery safety instructions

The product has a built-in rechargeable battery. Read the following instructions to ensure safe use and disposal.

- Keep the product away from prolonged exposure to heat sources such as open fires or direct sunlight.
- Only store the product in environments with ambient temperatures of 0°C to 35°C (32°F to 95°F).
- Do not use or store the product in dust-prone, smoke-prone, high-temperature, high-pressure, or highly humid environments.
- Keep the product dry and away from liquids or moisture.
- Only use an FCC or CCC-certified charger with an output voltage of 5 V/1 A DC.
- Do not use the product while charging.
- Do not leave the product charging for longer than eight hours.
- Dispose of the product responsibly according to your local waste management guidelines.

## **FCC Caution:**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.