

ZNP

Wireless Earphones N07



Quick Start Guide
ZNP N07

Product Specifications

Model: ZNP N07

Bluetooth

Range: ≈ 10 m

Version: 6.0

Speaker

Diameter: 13 mm

Impedance: 16 Ω

Earphone power

Input: 5 V $\equiv$ 30 mA

Battery capacity: 30 mAh

Battery life: ≈ 4 hrs

Charging time: ≈ 1.5 hrs

Charging case power

Input: 5 V $\equiv$ 500 mA

Output: 5 V $\equiv$ 60 mA

Battery capacity: 500 mAh

Charging time: ≈ 1.5 hrs

Earphone recharges: 3 charges (when case is fully charged)

How to reset the earphones

If the earphones fail to pair or reconnect to each other, reset them by simultaneously tapping both touchpads five times.

Note: This will clear their Bluetooth pairing history

What's in the box



Charging case



2 Earphones



Lanyard



Quick Start Guide



USB-C cable


Components



Charging case display




Charging case speaker



How to put on the earphones



Power on and off



If you're using the earphones for the first time, remove both from the charging case. The LED on one earphone will blink white, indicating that they are in pairing mode.

Power on

Taking the earphones out of the charging case will automatically turn them on.

To manually turn on the earphones, press and hold the touchpad for three seconds.

Power off

Placing the earphones in the charging case will automatically turn them off.


To manually turn off the earphones, press and hold the touchpad for five seconds.

Note: If the earphones are not paired with a Bluetooth device within three minutes after powering on, they will automatically power off. They will also power off after three minutes if the paired Bluetooth device moves out of the effective connection range and has not reconnected.

Connect to Bluetooth device



On your device, turn on Bluetooth and choose to connect to "ZNP N07".



Speaker playback



You can use the charging case as a mini speaker. On your device, turn on Bluetooth and choose to connect to "ZNP N07C-SP".

Note: You cannot play audio on both the charging case speaker and the earphones at the same time. You must disconnect from one device to use the other.



Key functions

- **Play/Pause:** Tap either touchpad once.
- **Volume up:** Tap the right touchpad twice.
- **Volume down:** Tap the left touchpad twice.
- **Play previous track:** Tap the left touchpad three times.
- **Play next track:** Tap the right touchpad three times.
- **Answer/End call:** Tap either touchpad once.
- **Reject call:** Press and hold either touchpad for two seconds.
- **Activate voice assistant:** Press and hold the left touchpad for two seconds

Note: When using only a single earphone, press and hold its touchpad for two seconds.

- **Switch modes:** Press and hold the right touchpad for two seconds.
 - **Music mode:** High quality audio for music listening (default)
 - **Game mode:** Low latency audio for gaming

Indicator LEDs

Earphone LED	Status
Blinking white	Unpaired
Solid white	Charging
Off	Paired or fully charged

Basic operations: Case display



Initialization

If you're using the display for the first time, make sure that the case is charged then press and hold the multifunction button for three seconds.

Turn on the display

Do any of the following:

- Tap the display twice. ("Tap to wake" must be on.)
- Press the multifunction button once.

Turn off the display

The display automatically turns off after 30 seconds of inactivity. To manually turn it off, press the multifunction button once.

Basic operations: Multifunction button

Multifunction button



- Press once: Turn the screen on/off
- Press three times (earphones inside case and lid open): Link the earphones to the charging case
- Press and hold for ten seconds: Restart the case display
- Press and hold for two seconds: Open the System menu
The system menu contains the following options: About, Factory reset, Restart, and Power off.



Navigation

- Swipe left/right: View the Menu options/AI translation interface.

Status icons

	Status
Solid red	The charging case is disconnected from your phone.
Solid blue	The charging case is connected to your phone.
	Status
Solid red	Earphones are disconnected from your phone
Solid white	Earphones are disconnected from the case and your phone
Solid blue	Earphones are connected to the case and paired with your phone
 	Status
Solid green	Earphones are charging in case
Solid white	Earphones are fully charged
	Status
Green lightning icon	The case is charging

Case display feature overview



Home screen

Swipe to unlock the screen.




AI Translation

Displays translated content synchronized with the connected app.




Menu

Swipe up or down to view the items and tap to access its options.



Headphone control mode

Switch between Music Mode and Douyin Mode, and customize each touch control function in the app.




Music

◀◀ ▶▶ ⏸ ⏮ ⏭
Previous Play/Pause Next Volume down Volume up




Equalizer

Tap any of the equalizer presets to use it.




AI Translation

Displays translated content synchronized with the connected app.




Sleep timer

set an idle screen sleep timer.




Find my earphones

Tap **L** or **R** to make the earphone beep.
Once you've found it, tap the button again to stop the beeping.




Brightness

Adjust the screen brightness by swiping up or down.



Voice assistant

Tap  to activate your phone's voice assistant.




Game

Tap to start playing.



System menu

Check your device details, perform a factory reset, restart, or power off your device.



Time

Set the time, date, and format to use for the display.




Lock screen wallpaper

Choose the wallpaper to use for the lock screen.




Language

Choose the language to use for the display.



Menu style

Choose a menu style.



Tap to wake

Enable this option so you can turn on the display by tapping it.




Background wallpaper 🎨

Choose a background image.



System settings ⚙️

Configure your charging case settings.




TikTok ❤️

If you're browsing TikTok while your earphones are connected to your phone, you can use your earphones to scroll through and like videos.

Notes:

- To use this feature on iOS, users must turn on AssistiveTouch in Settings > Accessibility > Touch > AssistiveTouch.
- This feature may not be compatible with all phone models.



Camera 📷

While your earphones are connected to your phone, you can use your charging case to take photos with your phone's camera.

To take photos, open your phone's default camera app, and then tap 📷 on the charging case display

Notes:

- This feature only works with the pre-installed camera app.
- This feature may not be compatible with all phone models.

FCC ID: 2BTLR-N07

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Important Safety Instructions

General safety instructions

- Use the product with care and store it in a clean environment that is free from extreme temperature, pressure, and humidity.
Make sure that the product is stored in a location where it cannot be bent or squeezed.
- Only use the product in environments where Bluetooth transmission is permitted.

Personal safety instructions

- Do not use the product if it is obviously defective or exhibits abnormalities such as bulging or excessive heating.
- Do not use the product when performing high-risk tasks that require your full attention.
- For your hearing protection, do not listen at high volume for long periods.
- Keep the product and its packaging out of reach of children and pets to prevent accidents such as swallowing and choking.

Battery safety instructions

- Keep the product away from prolonged exposure to heat sources such as open fires or direct sunlight.
- Only store the product in environments with ambient temperatures of 0°C to 35°C (32°F to 95°F).
- Do not use or store the product in dust-prone, smoke-prone, high-temperature, high-pressure, or highly humid environments.
- Keep the product dry and away from liquids or moisture.
- Only use an FCC or CCC-certified charger with an output voltage of 5 V/1 A DC.
- Do not use the product while charging.
- Do not leave the product charging for longer than eight hours.
- Dispose of the product responsibly according to your local waste management guidelines.