


90mm

55mm

User Guide

Toztnix i9 Neckband Bluetooth Headphones



- 1. Power On/Off
- 2. Volume up/next song
- 3. Multi-function button/activate Siri
- 4. Volume down/previous song
- 5. LED indicator light



Type-c
charging
interface

Thank you for purchasing and using a wireless phone.
This manual will help you to use your headset.
Before using the headphones, you must know and be familiar with the function of your mobile phone or of the function of other electronic devices, such as the function of a computer.

Safety rules

1. Before using the headset, we strongly recommend you read this manual.
2. Please pay attention to sharp edges, uneven surfaces, metal parts, accessories and packaging to avoid any possible damage.
3. Please do not dismantle and repair this product. This may cause fire, electronic breakdown or complete damage to the product, which are not covered by the warranty.
4. Please do not wipe this product with oil or other active liquids. Please do not use this product in dangerous places.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

* RF warning for Portable device:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

01

02

Basic parameters:

Model	Toztnix-i9	Connection distance	>10 meters
Wireless version	V 6.0	Playback time	About 35 hours
Protocol	AZDF \ HFP \ HSP AVRCSRPP	Talking time	About 27 hours
Battery type / specification	Polymer lithium battery 3.7V 180mAh	Charging time	About 1.5 hours
Speaker impedance	16Ω	Standby time	1200 hours
Charging mode	Type-c charging interface	Working frequency	2400-2483.5MHz
Function	line control answering/hanging up/rejecting/Power on and off, phone redialing, mute, volume adjustment, listening to music, pause, play, switch songs up and down/voice recognition /intelligent voice control.		
Product application	Support any type of mobile phone with device, IPAD, tablet computer, notebook computer, desktop computer. Desktop computers without function can be used with adapters.		

Pairing and Connection

1. Keep the distance between the mobile phone and the headset within one meter, the closer the better.
2. Press "Power" button for about 2 seconds and release when the indicator light flashes red and blue alternately, the headset has entered the pairing mode.
3. Turn on the function of the mobile phone, search for devices, and select "Toztnix -i9" to pair and connect. When the connection is successful, the headset indicator light turns off.
4. After the pairing is completed, the headset and the mobile phone will remember each other, and there is no need to pair them again next time you use it. When the mobile phone is turned on, the headset will automatically connect after turning on.
5. To connect two devices simultaneously: First pair with Device A, then disable Bluetooth on Device A and pair with Device B. Finally, re-enable Bluetooth on both devices and manually connect the headphones to both.

Function and operation

Power on: Press and hold "Power" button for 2 seconds in the shutdown state (the blue indicator light flashes slowly, and there is a power-on prompt sound).

Enter matching mode: After powering on, it will automatically enter the code matching mode (At this time, the indicator light flashes alternately in red and blue. After the matching is successful, the voice prompt pairing successful will be issued, and the red indicator light stops flashing).

Pairing: Use the function of a mobile phone or electronic device with function to match (refer to the following pairing chapter for details).

Play/Pause: Press the "Multi-function" button to pause the music while playing, and press the "Multi-function" button to continue playing.

Volume up: Click "+" button to turn up the volume.

Volume down: Click "-" button to turn down the volume.

Previous song: Long press "-" button to play previous song.

Next song: Long press "+" button to play next song.

Power off: Press and hold "Power" button for 3 seconds in standby or working mode (voice prompts, power off and the red indicator light flashes 2 times), if it flashes once, it may be overshadowed by the pairing light.

Auto Shutdown: The device is turned on without any connection and automatically shuts down after 5 minutes. Manually disconnect the Bluetooth device, and it will automatically shut down after 5 minutes.

Low battery alarm: The red indicator light flashes slowly, and there is a low battery warning sound "The battery is low, please charge".

Charge: Plug the charger into the headset charging port (the red indicator light is on); after the headset is fully charged, the blue indicator light will stay on.

Answer the call: Click "Multi-function" button.

End the call: Click "Multi-function" button 1 second.

Reject the call: Long press "Multi-function" button for about 1 seconds, it will announce "Call Rejected".

Hang up the call: During a call, briefly press the "M" button to hang up the call.

During a call, a short press on the "Multi-function" button can answer the new incoming call and hang up the current call.

During a call, if a new call comes in, double-clicking the "Multi-function" button can answer the new call and hold the current call.

When a call comes in during a call, you can press and hold the "Multi-function" button for 2 seconds to maintain the current call and reject the new incoming call.

During a three-party call, double-clicking the "Multi-function" button allows you to switch between the current call and the hold call.

During a three-party call, short press the "Multi-function" button to hang up the current call and resume the waiting call.

Restore factory settings: In the powered-on state, simultaneously press and hold the "Multi-function" button and the "Volume Down" button for 5 seconds. The red and blue lights will illuminate simultaneously for 2 seconds to clear the pairing history.

Start the voice assistant: Press "Multi-function" button for 2 seconds to start Siri or Google voice assistant, and then voice input the content or help you want to query.

For example:

How is the weather today
Open Whatsapp

Simple questions and answers

1. Why can't my headset turn on normally?
Answer: For the first use, please make sure that the headset has power.
2. There is no sound when playing music?
Answer: Check whether the playback device is effectively connected to the headset. If the audio device fails to connect normally, please reconnect and adjust the phone or volume to a suitable level.
3. The mobile phone cannot search for headsets?
Answer: Please confirm whether the headset is turned on and ready to be connected (the red and blue indicators flash alternately). If the pairing is not performed for a long time, the headset will automatically turn off; you need to turn on the headset again to the standby state. If the headset program fails, please restart the headset, if the phone program goes wrong, please restart the phone;
4. Why is speech recognition inaccurate?
Answer: First of all, please confirm whether the recognition of Siri or Google Voice Assistant of The mobile phone is accurate when is not connected. If it is not accurate, check whether the language setting of Siri or Google Voice Assistant is correct at this time. Set it in Siri or Google Voice Assistant. Inside, just set the language you use; if the setting is English, it will be recognized in English, and you should use English input when you use it.

Safety rules

1. Do not dismantle or modify the headsets for any reason, otherwise it may cause the headsets to malfunction or burn out, which is not covered by the warranty;
2. Please pay attention to waterproof, otherwise it will cause serious damage to the headsets. The manufacturer will not guarantee the damage caused by water;
3. Do not use headsets during thunderstorms. Thunderstorms can cause the headsets to work abnormally and increase the risk of electric shock.

04

05

三折页说明书制作规格
单页尺寸：55x90mm 材质：128克铜版纸