


Smart Projector



HY350Max-G

※Quick Installation Guide※


Attention

Please read this manual carefully before use and keep it for future reference.

- 1.The projector is non dustproof or waterproof.
- 2.In order to reduce the risk of fire and electric shock, do not expose the projector to rain and fog.
- 3.Please use the original power cord. The projector should work under specified rated power supply.
- 4.When projector is working, please do not look directly into the lens, the strong light will flash your eyes and cause slight pain. Children should use the projector under the supervision of adults.
- 5.Do not cover the vents of projector. Heating will reduce the life of projector and cause danger.
- 6.Regularly clean projector vents, or dust may cause cooling malfunction.
- 7.Do not use the projector in greasy, damp, dusty or smoky environment. Oil or chemicals will cause malfunction.
- 8.Please handle with care during daily use.
- 9.Please cut off the power if the projector is out of use for long time.
- 10.Non-professionals are forbidden to disassemble the projector for testing and maintenance.

Personalized Main Interface:


Based on differences in regions, countries, and accounts, Google will provide a customized main interface tailored to personal preferences. The settings will remain unchanged.



The best projection method: Front projection





Projection method




Structure description

This manual is for reference only. It is subject to change without prior notice. This company reserves the right of final interpretation.




Input: 100-240VAC 50/60Hz 2A USB-A Output: 5VDC, 0.6A
Operating temperature: 25°C Altitude: 2000m

Remote Component and Functions




Bluetooth remote controller pairing




1. Pair manually according to the instructions.
2. Press the power button on the remote control to turn on the device. It will automatically pair, eliminating the need for manual pairing.

Select a language - Select a country - To choose the network and type the password that you want to connect to - Log in to Google - Accept Google services.




Play Store

Apps - Open Store, In the Store, applications can be installed with one click, and they can be used directly after installation.




Settings

Pressing the Settings key allows quick access to the settings for Screensaver, Wi-Fi, Accessibility, and Bluetooth.




Settings

Pressing the Settings key allows quick access to the settings for Screensaver, Wi-Fi, Accessibility, and Bluetooth.




Networking Settings

Dongle Settings, WIFI "ON", select objective WIFI ID and input password to connect internet.




Settings

Press the Settings key and confirm by pressing "OK" to access the main settings interface.




Display & Sound Settings

Dongle Settings - Display & Sound, Enter to set HDMI-CEC, Advanced display settings, Advanced sound settings. You can set the resolution by entering Advanced display settings.




Accessibility Settings

Dongle Settings - System - Accessibility Setting, enter to Captions, High-contrast text, Text to speech, Accessibility shortcut.




About

Dongle Settings - System - About, Enter to system update and Reset Settings(Factory reset).View device information.




⚙️ Date & Time Settings

Dongle Settings - System - Date & Time Setting, enter to Set time zone and Use 24-hour format.




⚙️ Language Settings

Dongle Settings - System - Language Setting, enter to setup language and select input method.




⚙️ Power & Energy Settings

Dongle Settings - System - Power & Energy Setting, Screen saver time setting (The projector will enter the screen saver mode after the set time elapses when there is no operation or playback). When the projector enters the screen saver mode, you can exit it by pressing any key.




≡ Projector Settings

Press "Projector Settings" on the remote control, Enter to Settings. Enter to Picture, Sound, Display, Input, System settings.




≡ Picture Settings

Projector Settings - Picture , Enter Picture Mode、 Color Temperature and Brightness Mode(ECO、 Standard) for setting.




≡ Sound Settings

Projector Settings - Sound , Enter Sound Mode and Bluetooth Speaker for setting.




≡ Display Settings

Projector Settings - Display , Enter Projection Mode, Auto Four-Corner Correction, Manual Keystone, Keystone Reset, Auto Focus, Scale Mode, Screen Zoom, Advanced Settings.




≡ Advanced Settings

Projector Settings - Display, Enter Advanced Settings , Settings Obstacle Avoidance, Screen Recognition, First-Time Boot Auto Focus.




📺 HDMI™ Signal

Press "Source" on the remote control, Enter to HDMI. After connecting projector to other output device, enter HDMI or Audio/Video.



How to read a USB flash drive

You need to access the Google Play Store to download "File Manager". Only after opening the app and granting permissions can you read the content stored on your USB flash drive.



FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Safety instructions

Please pay attention to important information related to the operation and maintenance of the projector. You should read this information carefully to avoid problems. Following safety instructions will increase the life of projector.

Please consult the qualified personnel for installation and repair services, and do not use damaged wires, accessories and other peripherals.

Projector should be kept away from flammable, explosive, strong electromagnetic interference (large radar stations, power stations, substations) ,etc. Strong ambient light (avoid direct sunlight), etc.

- Do not cover projector vents.
- Please use the original power cord.
- Keep adequate ventilation and make sure vents are not covered to avoid projector overheating.

When projector is working, please do not look directly into the lens, the strong light will flash your eyes and cause slight pain.

- Do not bend or drag the power cord.
- Do not put power cord under projector or any heavy objects.
- Do not cover other soft materials on power cord.
- Do not heat the power cord.
- Avoid touching power cord with wet hands.

Disclaim

This manual is general instructions, The pictures and functions in this manual should subject to the actual product. Our company is devoting to improve product performance, we reserve the right to modify product functions and interface described in this manual without notice.

Please keep your device properly. We are not responsible for any loss caused by wrong operation of software/hardware or repairing or any other reasons. We are not responsible for any loss of any third party claims.

This manual has been carefully checked by professional engineer, please understand for any inevitable omissions.

HDMI™

The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI trade dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.



Attention:

Please do not look directly into the lens when projecting to prevent the strong light doing harm to your eyes. Kids should use the projector under the supervision of adults.