


AIR PURIFIER OPERATION MANUAL


Basic Parameters

Product Name	Air purifier	Rated voltage	DC5V
Product Model	SAP2507-1(A)/ SAP2507-1S(A)/SAP2507-1G(A)/ AKJ-HH-057/MB-057	Rated power	10W
Product dimensions	176*127*246mm	Net weight	0.83kg

Product Introduction



Key Function Description



- Power:** Short press to turn on, short press again to turn off.
- Bluetooth:** Long press for 3 seconds to connect Bluetooth, Bluetooth name: SheerAire; There is a prompt sound when the Bluetooth connection is successful. Short pressing the Bluetooth button during playback will increase the volume, and the corresponding "+" in the upper right corner is the function of this button. Press and hold for 3 seconds to exit Bluetooth connection mode.
- Timer:** Short press to turn on, short press to adjust the timer, the adjustment sequence is as follows: 1-2-4-8H - shutdown changes sequentially.
- Negative ion:** Short press to turn on, short press to turn off.
- Sleep:** Short press to turn on, press any key to exit sleep mode.
- White noise:** Long press for 3 seconds to enter white noise mode. During playback, short press the white noise button to reduce volume, corresponding to the function of the "-" button in the upper right corner. Double click the white noise button to enter the white noise audio switching mode, and long press the white noise button for 3 seconds to exit the white noise mode.
- Night light:** Short press to enter the night light mode, with four brightness levels. Short press to adjust the brightness, with the brightness level adjustment sequence being 1-2-3-4 levels. Short press to exit the night light mode, with the brightness level remaining the same each time this function is turned on and off.
- Vibe:** Short press to turn on the atmosphere light, short press to adjust the brightness, there are a total of 4 brightness levels: 1-2-3-4-3-2-1-0, long press for 2 seconds to enter the color adjustment mode, the color adjustment order is blue, purple, red, yellow green, green, ambient lighting mode. The light has a memory function, and each time this function is turned on, the color and brightness of the light remain the same as when it was turned off the previous time.

Cautions

1. When the product is to be discontinued for a long time, please put it back in the packaging box and store it in a safe and cool place, avoiding direct sunlight.
 2. Do not put any accessories that do not belong to this machine into the body. If you encounter any malfunction, please contact our company and do not repair it yourself. This will affect your warranty rights and may even cause permanent product failure.
 3. This product cannot replace ventilation fans, vacuum cleaners, or kitchen range hoods.
 4. When used together with household gas appliances (such as gas stoves, gas water heaters, etc.), please ventilate to avoid carbon monoxide poisoning.
 5. Do not pour liquids or throw powders or small substances into the product through the air outlet.
 6. Do not bring hair, fabrics, etc. close to the product to avoid getting caught up or blocking the air inlet and outlet holes.
 7. Do not sit or tilt the product.
 8. Regularly cleaning the dust, hair, and impurities on the surface of the filter is beneficial for reducing bacterial growth.
- This product is not suitable for children, people with disabilities, individuals with mental illnesses, or those lacking relevant experience or knowledge to operate. Unless they are under supervision and ensure their safety, please ensure that children do not use the product as a toy.

⊗ Prohibited matters

1. Users are prohibited from disassembling the machine for maintenance without authorization. If necessary, please contact the manufacturer for repair and replacement.
2. It is prohibited to use gasoline, alcohol, or other flammable cleaning agents for product cleaning to avoid causing fires.
3. It is prohibited to use in environments where flammable and explosive materials are stored. During use, do not approach hot or high-temperature objects to avoid causing explosions.
4. It is prohibited to insert any part of the body or other objects into the air outlet of the machine to avoid personal injury or damage to the machine.
5. It is prohibited to use wet hands to switch power or move products. Hands should be kept dry to avoid electric shock.
6. It is forbidden to block the air inlet and outlet holes during use to avoid damage caused by overheating of the machine.
7. Do not approach soft objects such as curtains, and ensure that there is a 30cm space distance near the machine.
8. It is prohibited to disassemble or modify the product without authorization.
9. It is prohibited to use it outdoors or on damp ground to reduce the risk of electric shock.

⚠ Warning Notice

1. Before cleaning or maintaining this product, it must be disconnected from the power supply to avoid unnecessary danger.
2. When the product is temporarily suspended, repaired, or personnel leave, please disconnect the power supply in a timely manner.
3. When the product has an odor or abnormal noise, please immediately disconnect the power and contact the after-sales point.
4. When disconnecting the power supply, please do not drag the power cord. Instead, grip the power plug and pull it off with force.
5. If the power cord is damaged, it must be replaced by a professional or sent to a designated repair point for repair.
6. Do not use accessories or parts that are not provided by the original factory. If the use of non original accessories or parts causes damage to the product, the product will no longer enjoy after-sales policy.

Common faults and their solutions

When encountering the following general faults, users can troubleshoot on their own.

- ⚠ Attention: If any malfunction is found, please shut down immediately to prevent damage to the machine and other hazards.

Fault	Reason	Treatment method
Unable to power on	Is the power cord plug energized	Turn on the power
	Is the power cord plug loose	Connect the plug properly
Low wind output	Is there a cover on the air outlet or inlet	Turn off the air purifier and remove the cover

- ⚠ Attention: If the above inspection still cannot eliminate the fault, please contact the seller or designated after-sales service. Do not disassemble and repair it yourself to avoid danger and damage to the air purifier.

Maintenance and upkeep instructions

- Do not spray water on the body.
- Do not put any debris into the air outlet.
- Do not use on wet ground or in damp environments.
- During maintenance or cleaning, it is necessary to turn off the power first.
- External: The body can only be cleaned with a soft cloth and water. Do not use strong solvents or detergents, as this may cause damage to the surface coating.
- Internal: Clean the metal inner wall with ethanol (reagent grade) and a soft towel.
- Please strictly follow the above requirements for maintenance.
- Any operation that would obviously damage the product is not allowed.
- Please read the operating instructions before using this product.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

For inquiries and commissions related to maintenance, usage methods, and upkeep, please contact us through the following methods.

Contact

SheerAIRE
TEL: 86-0512-57790301

KUNSHAN HUNG HSING ELECTRIC CO.,LTD
78,Yuanfeng Rd.,Yushan Town,Kunshan City,
Jiangsu