

Human Being DIBO



Edibao Sports Goods (Shenzhen) Co., Ltd.


Address: 3rd Floor, Building 2, Huishengda Factory, Qinghu Industrial City, Qinghu Community, Longhua Street, Longhua District, Shenzhen



know more ab-
out

Edibao Smart Pickle Ball Serving Machine

P700 (Bluetooth Single-User Version) Manual



The final interpretation rights of this manual belong to the Company. Please read this manual carefully before using the product.

1. Schematic Diagram of P700 Smart Pickleball Serving Machine



II. Packing List

Name	Quantity	Unit
P700 Pikball server	1	Individual
Ball frame	1	Individual
Charger	1	Individual
Certificate	1	Zhang
Instruction Manual and Warranty Card	1	Box, or card, photo

III. INSTALLATION INSTRUCTIONS UNPACKING AND INSPECTION

Open the packaging and verify all components against the packing list to ensure no damage. Remove the Peak ball-serving machine and its matching ball-loading frame.

Install the ball frame:

Align the small opening of the ball-loading frame with the top of the tennis ball machine and press it firmly. Ensure the frame is securely mounted on the machine to guarantee smooth ball delivery.

Set the baller:

Locate the 'mouth' shaped ball deflector at the top of the pickleball server. Lift it centrally to the proper position. Then tighten the 'with a small wrench. □ internal screw

Locate and start the server:

Position the tennis ball serving machine beneath the return net, ensuring the equipment is securely mounted and the ball outlet is unobstructed. Press the power switch to activate the machine.

4. Download and Install the Application

Scan the QR code below or on the device to download and install the AidiBao Smart Serving Machine app.

You can also enter the ADIB0 official website www.adibo.com to download the operation application of the ADIB0 intelligent server



V. Brief Description of Operating Procedures

1、 Place the assembled smart ball-serving machine in the designated spot on the court (refer to the ball path settings in the app).



2、 When the smart pickleball serving machine is powered on, its power indicator light illuminates, and the machine automatically rotates left and right to perform a self-check.

3、 Open the Edibao Smart Serving Machine app, select the Smart Pickle Ball Serving Machine, and click "☆". Once activated, the machine will light up simultaneously: power, network, and indicator lights.




4、 Go to the 'Operation' section in the Edibao Smart Serving Machine app.



5、 Customized Training: Choose from various pickleball training modes including fixed-point drills, combination drills, random drills, star challenges, and high school entrance exam prep. Simply click 'Start' to begin.



6、 Custom: The graphical interface displays the pickleball court opposite the smart pickleball server. Place the machine on the baseline or center line, then long-press 2 seconds on the desired landing point diagram. After selection, click Start below.




7、 The Diagram of Customizing the Ball Path Parameter Adjustment Is Shown Below:

8、Parameter Adjustment Button Explanation:



9、My Training Paths: After selecting your preferred training path, click Save to save it as a training archive. You can then start training directly from My Training Paths by clicking Start.



VI. Troubleshooting

Hitch	Failure cause	Elimination method
The server is not powered on.	① Check if the battery has power. ② Poor contact between the power cable interface and the battery	① Check the power supply circuit and interfaces
The baller is not working.	① The device is not connected to Bluetooth ② The ball is stuck in the wheel.	① Check if the network indicator light behind the server head is on. If not, power off and restart the device, then wait one minute. If the issue persists, contact the official after-sales service. ② Check if the ball is stuck in the serving wheel during power-off inspection
The server cannot connect via Bluetooth when powered on	① The phone's Bluetooth is not turned on ② Location services are not enabled	① Turn on Bluetooth on your phone to find this device ② Enable phone location
The tablet cannot control the machine	① machine signal interrupt	① Power off and restart the machine
The ball won't go down.	① The ball release mechanism is not engaged. ② The lower orifice is blocked.	① Pull up the ball puller. ② Check if the ball port is jammed

VII. Frequently Asked Questions

- 1、Do not touch the rotating parts of the server during operation.
- 2、When the ball-serving machine is paused or adjusted, avoid direct contact with the ball outlet and ensure all personnel in the adjacent court area are notified of safety precautions before commencing operation.
- 3、Minors must be supervised by adults when operating the device.
- 4、When used outdoors, avoid rain and snow weather;
- 5、If the server emits abnormal odors or smoke during operation, immediately press the emergency switch and cut off the power supply.
- 6、After use, complete the training in the mobile app and then turn off the power.
- 7、Clean the server regularly.



Warranty Card

Dear user:

shalom !

Thank you for purchasing the ADIBO brand products. Please read the product manual carefully before use to ensure proper operation. If any malfunction occurs, refer to the troubleshooting section in the manual first. If the issue cannot be resolved, please contact our after-sales department promptly. We will provide you with high-quality after-sales service.

Please feel free to call our service hotline at 4000-009-773 for assistance.

Warranty terms:

1. The Edibao smart baller offers a full one-year warranty on the unit, while the baller wheel (a consumable part) comes with a six-month warranty.
2. During the warranty period, any malfunction caused by normal operation (as determined by our authorized personnel) will be repaired free of charge.
3. During the warranty period, if any of the following situations occurs, it must be repaired at a charge:
 - Cannot provide this guarantee and valid purchase voucher.
 - Faults and damages caused by improper use and unauthorized repairs.
 - fault or damage caused by transportation, handling, or drop after purchase.
 - Other unavoidable external factors cause the failure and damage.
 - Damage caused by improper use, such as water ingress or exposure to other solutions.
 - Damage caused by voltage from a power source other than the specified one.
- 4 The Company makes the above warranties only and makes no other express or implied warranties (including implied warranties of merchantability, fitness for a particular purpose, or applicability), whether in the contract, in respect of civil negligence, or otherwise. The Company shall not be liable for any special, incidental, or consequential damages.
5. Please pack and transport the repaired products properly. We will not be liable for any damage during transportation.

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum 20cm distance between the radiator and your body: Use only the supplied antenna.

Product Warranty Card			
Product name			
Serving machine number		Date of purchase	
Customer name		Contact number	
Customer address			