

CONTENTS AND GETTING STARTED

Contents

- 1 Toyota Tacoma TRD Pro 1:16
- 1 Transmitter
- 1 USB-C to USB-A Charging Cable
- 2 AA batteries

Getting Started

The transmitter requires 2 AA 1.5V batteries (included) and the vehicle features a non-replaceable rechargeable battery (included).

Vehicle






1. Make sure the power switch on the bottom of the vehicle is in the off position.
2. Carefully remove the plug from the of the USB-C power input.
3. Plug the USB-C end of the charging cable into the charging port on the bottom of the vehicle.
4. Plug the USB-A end of the charging cable into a powered USB-A port or a USB-A power adapter (not included). The charging light will be on while the vehicle is charging and will turn off when the vehicle is fully charged.
5. Wait for the vehicle to fully charge and then unplug the charging cable.
6. Carefully replace the plug into the USB-C power input.

Transmitter

1. Use a Phillips-head screwdriver to loosen the screw in the battery cover on the back of the transmitter.
2. Insert 2 AA 1.5V batteries into the battery compartment according to the battery diagram.
3. Replace battery cover and secure the screw.

Left Stick

Right Stick



HOW TO PLAY

Power and Pairing

1. Flip the switch on the bottom of the vehicle to the on position to power on the vehicle. The pairing light on the vehicle will glow, fading on and off, to indicate the vehicle is in pairing mode. It will automatically begin pairing with the transmitter.
 2. If pairing is unsuccessful within 60 seconds, power off the vehicle and then repeat step 1.
 3. Start driving!
 4. If pairing is interrupted or out of range, the transmitter and vehicle will both enter pairing mode and attempt to reconnect. Move the transmitter and vehicle closer together. If pairing is unsuccessful within 60 seconds, power off the vehicle and then repeat step 1.
 5. When finished driving, flip the switch on the bottom of the vehicle to the off position to power off the vehicle.
- Note: To save battery life, the transmitter and vehicle automatically enter sleep mode after 5 minutes of inactivity. To wake from sleep mode, power off and then power on the vehicle, immediately press and hold the left stick on the transmitter, keep holding until wheels move (up to 30 sec.). The status lights will flash when the battery level is low. Recharge the vehicle and restart to continue driving.

Multiple Drivers


The transmitter connects to the vehicle using 2.4GHz digital channel selection that allows up to 16 drivers to race side by side in the same wireless range without interference. Pair each vehicle and transmitter separately.




6+

HOW TO PLAY


Forward




Reverse



Left Turn



Right Turn



SAFETY PRECAUTIONS

- Adult supervision is recommended when operating the vehicle.
- Always drive responsibly and make sure driving paths are clear. Never drive towards or in close proximity to people or animals. Never drive on streets or roadways to avoid traffic hazards.
- Keep fingers, hair, and loose clothing away from tires and all moving parts while the vehicle is in motion.
- Avoid exposing the vehicle and transmitter to water. Avoid driving through water. Never drive outdoors in rain or snow. Never leave the vehicle or transmitter outdoors overnight.
- Do not expose the vehicle or transmitter to extreme temperatures.
- Do not leave the vehicle or transmitter near sources of heat or under direct sunlight for extended periods.
- Do not sit, step, stand, or place objects on the vehicle. It is not designed to support extra weight.
- Do not disassemble or modify the vehicle or transmitter.
- Thoroughly inspect the vehicle and transmitter before every use. If the vehicle or transmitter appears worn, frayed, splintered, cracked, or broken in any manner, discontinue use and discard immediately.

RECHARGEABLE BATTERY WARNINGS

- This product contains batteries that are non-replaceable.
- There is a risk of fire and personal injury if battery is punctured, damaged, or misused.
- Do not dismantle, crush, incinerate or short-circuit battery.
- Never expose battery to extreme temperatures or moisture.
- Keep away from flammable materials and direct sunlight.
- Only charge using the provided charger, cable, and/or adapters.
- Rechargeable battery is only to be charged by an adult.
- Adult supervision is required while charging the battery.
- Allow battery to cool to room temperature before charging.
- Charge on a non-flammable surface and keep away from flammable products.
- Discontinue charging if battery becomes hot, swells, smokes, or gives off a strong odor.
- Battery chargers used with the product are to be regularly examined for damage to the cord, plug, enclosure, and other parts. In the event of such damage, chargers must not be used until the damage has been repaired.
- Recycle or dispose of battery according to federal, state, and local laws.
- Keep these instructions for future reference.



ALKALINE BATTERY WARNINGS

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.
- Alkaline batteries are recommended. Use only the specified voltage.
- Insert batteries using the correct polarity. Always use, replace, and recharge (if applicable) batteries under adult supervision.
- Do not attempt to charge non-rechargeable batteries.
- Do not short-circuit the battery supply terminals.
- Do not dispose of batteries in fire: batteries may explode or leak.
- Remove batteries before storing.
- Recycle or dispose of batteries according to federal, state, and local laws.
- Keep these instructions for future reference.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

© 2026 Toyota Motor North America. All rights reserved. Vehicles have been modified from their original form. Designs of Toyota cars and all other associated marks, emblems and designs are intellectual property rights of Toyota Motor Corporation and used with permission.

Distributed by and © 2026 MerchSource, LLC. Irvine, CA 92618. All rights reserved.

Model No.: 1020627



WARNING:

CHOKING HAZARD - Small Parts.
Not for Children under 3 years of age.

BC

Printed in China

For customer support, please visit
www.msccustomercaare.com or call

1-800-374-2744