



XTEINK

XTEINK X3


Ultra-thin Magnetic Back E-Reader

Quick Start Guide




⑪ Magnetic Attachment Point

⑫ Magnetic Charging Port



⑥ Lanyard Hole



Package includes:

- ① 1× X4 E-Reader
- ② 1× Quick Start Guide
- ③ 1× MicroSD Card
- ④ 1× Screen Protector1
- ⑤ 2× Magnetic Ring Stickers
- ⑥ 1× USB cable

Product model :X4

Input Voltage : 5V

Frequency:2402MHz~2480MHz



Battery Capacity: 650mAh

Set Up Your XTEINK eReader

1. Charge the reader for 30 minutes before first use.
2. Press the power button and hold until your eReader turns on.
3. Connect to Wi-Fi, perform a system update to the latest version, and your eReader is ready to use.



If update fails or device is unresponsive, press the RESET button, then long press the Power button to restart. If it still doesn't work, try again closer to the router or on another Wi-Fi/ hotspot.



Transfer Files

Computer:

Remove the microSD card, insert it into a card reader on your computer to access files, and organize or edit folders as needed.

Other Transfer Options:

On Other Transfer Options, the reader hotspot will turn on. Connect your phone or computer to the Wi-Fi network E-Paper. Enter the password 12345678. Then open a browser and go to 192.168.3.3 to transfer files.

Supported formats:

Books/Files - EPUB,TXT;

Images - BMP, JPG

(Recommended 528x792 px)



Scan QR code to access full instructions, including features and FAQs.

Support Email:

Global: support@xteink.com

JP: support.jp@xteink.com

CN: support@xteink.cn

FCC Compliance Information

Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference
2. This device must accept any interference received, including interference that may cause undesired operation

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio or television technician for help

Additional Information

NOTE: This device and its antenna or antennas must not be co located or operated in conjunction with any other antenna or transmitter.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.