



Operation (Touch)



Dropdown Menu




Two-device image sharing

1. Press and hold to share the image.
2. The other person double-taps to receive it.



APP Bluetooth Image Transfer




Step 1: Short press the Bluetooth button to open the Bluetooth screen and keep it open.

If not connected to the app, a download prompt will appear.

Step 2: Open the app to connect automatically. When 'Connected' is shown in green, image transfer is ready.

Step 3: Upload images and content as needed.

Image Sharing



Step 1: On Device A, press and hold the Bluetooth button for 3 seconds to share the current image.

Step 2: On Device B, double tap the Bluetooth button to receive the image.

Note: Only one image can be shared at a time, one-to-one.
GIFs and slideshows are not supported.

Common Questions:

Screen Not Displaying?

- ① Check if the device is powered on.
- ② Check if the battery is drained; charge the device .
- ③ Check the screen appearance for collision damage.

BT Not Connecting?

- ① Ensure the phone BT is turn on
- ② Short press the 【BT】 key to enter Bluetooth mode.
- ③ Reopen the APP again .

How to Use the MONO Light?

Swipe down and tap the Flashlight icon to activate.
Swipe up/down to select color. Tap to change flashing mode.
Swipe from left to right edge to exit.

Unable to Delete Images?

Swipe down to open the menu.
Tap the Trash icon to delete.

Unable to Share Images?

- ① Ensure you long press the 【BT】 key to sharing mode.
- ② Check if the receiving device short presses the 【BT】 key twice to enter receiving mode.
- ③ Ensure both devices are within 10 meters of each other.

Unable to Charge?

- ① Confirm cable is properly inserted.
- ② If the device is fully charged, it will not continue charging.

Battery Life



Level 1 Brightness: Up to 18 hours



Level 2 Brightness: Up to 12 hours



Level 3 Brightness: Up to 7 hours



Level 4 (Ultra Bright): About 4 hours
(Not recommended for long use unless necessary)

This data is from a third-party laboratory and is for reference only. Actual usage time may vary depending on the user's environment and habits.



Using Sleep Power-Saving Mode can extend battery life.

When the device remains idle for 10 minutes, it will enter Sleep Mode to save power. It will automatically wake up when picked up or shaken.

Product Specifications

Screen Size: **1.85-inch touch screen**

Resolution: **360×360**

Screen Type: **IPS + Touch**

Connection: **Bluetooth**

Storage Capacity: **~50 photos / ~10 GIFs or ~3videos**

Battery: **500mAh**

Weight: **~32g**

Dimensions : **58×58×10 (mm)**

Brightness Modes: **Night Mode (18 hrs)/Indoor Mode (12 hrs)**

Standard Mode (7 hrs)/Ultra-Bright Mode (4 hrs)

Display Modes: **Single image/Multi-image slideshow**

(max 9)/GIF/Video (max 3s)

Power Saving: **Auto sleep after 10 minutes**

Mono Light: **7 options (Purple, Blue, Yellow, Green, Red, White, Cyan)**

Sharing Function: **Dedicated sharing button (wireless)**

App: **Transfer**

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.


NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

そうさせつめいしょ




ドロップダウンメニュー

2 台の機器間で画像
を共有する


省電力モード

画像削除

- 1、画像を共有するには長押しします
- 2、相手はダブルタップで受け取ります



アプリのブルートゥース画像転送




ステップ 1: Bluetooth ボタンを短押しして Bluetooth 画面を開き、その状態を保持します。
アプリと接続されていない場合は、ダウンロードのプロンプトが表示されます

ステップ 2: アプリを開くと自動的に接続されます。「Connected (接続済み)」と緑色で表示されたら、画像転送の準備が完了です

ステップ 3: 必要に応じて画像とコンテンツをアップロードします。

画像シェア



ステップ 1: デバイス A では、Bluetooth ボタンを 3 秒間長押しして現在の画像を共有します。

ステップ 2: デバイス B では、Bluetooth ボタンをダブルタップして画像を受け取ります。

! 注: 1 回に 1 枚の画像のみを 1 対 1 で共有できます。
GIF やスライドショーはサポートされていません。

よくある質問

画面が表示されませんか？

- ① デバイスの電源が入っているか確認してください
- ② バッテリーが切れていないか確認し、切れている場合はデバイスを充電してください
- ③ 画面の外観に衝突による損傷がないか確認してください

MONO ライトの使い方

下にスワイプして懐中電灯アイコンをタップすると起動します。上 / 下にスワイプして色を選択します。タップすると点滅モードが切り替わります。画面左エッジから右にスワイプすると終了します

画像が共有できませんか？

- ① [BT] キーを長押しして共有モードにすることを確認してください。
- ② 受信デバイスが [BT] キーを 2 回短押しして受信モードに入るかどうかを確認してください。
- ③ 両方のデバイスが互いに 10 メートル以内にあることを確認してください。

ブルートゥースが接続できませんか？

- ① 携帯電話のブルートゥースがオンになっていることを確認してください。
- ② [BT] キーを短押しして、ブルートゥースモードに入ります。
- ③ アプリを再度開きます。

画像が削除できませんか？

下にスワイプしてメニューを開きます。ゴミ箱アイコンをタップして削除します。

充電できませんか？

- ① ケーブルが正しく挿入されているか確認してください
- ② デバイスが満充電状態の場合、充電は継続されません

Battery Life

- | | |
|--|---|
|  明るさレベル 1: 最長 18 時間 |  明るさレベル 3: 最長 7 時間 |
|  明るさレベル 2: 最長 12 時間 |  明るさレベル 4 (超明るい): 約 4 時間
<small>(必要がない限り、長時間の使用は推奨しません)</small> |

本データは第三者研究所によるもので、参考のみとします。
実際の使用時間はユーザーの環境及び習慣により異なる場合があります

-  スリープ/省電力モードを使用すると、バッテリーの寿命を延ばすことができます

デバイスが 10 分間放置されると、省電力のためスリープモードに入ります。持ち上げるか振った場合、自動的に起動します

製品仕様

画面サイズ(がめんサイズ):1.85 インチタッチスクリーン

解像度(かいそうど):360×360

画面種別(がめんしゅべつ):IPS + タッチ機能(たっちきのう)

接続方式(せつそくほうしき):Bluetooth

記憶容量(きおくようりょう):約(やく) 50 枚(まい)の写真(しゃしん) / 約 10 個(こ)

の GIF ファイル または (または) 約 3 本(ほん)の動画(どうが)

バッテリー:500mAh

重量(じゅうりょう):約 32g

寸法(すんぽう):58×58×10 (mm)

明るさモード(あかるさモード):ナイトモード(18 時間 / じかん) / インドアモード(12 時間) /

スタンダードモード(7 時間) / ウルトラブライモード(4 時間)

表示モード(ひょうじモード):シングルイメージ(単一画像 / たんいつがぞう) /

マルチイメージスライドショー(最大 / さいだい 9 枚) / GIF / 動画(最大 3 秒 / びょう)

省電力機能(しょうでんりょくきのう):10 分間(ふんかん) 放置(ほうち) 後(ご) 自動(じどう) スリープ

MONO ライト:7 種類(しゅるい) (紫色 / むらさきいろ、青色 / あおいろ、黄色 / きいろ、緑色 /

みどりいろ、赤色 / あかいろ、白色 / しろいろ、シアン)

共有機能(きょうゆうきのう):専用(せんよう) 共有ボタン(無線 / むせん)

アプリ:Transfer(転送用アプリ / てんそうようアプリ)



注意:

バッジスタンドを製品の背面に
接着すると、プラスチック製の円形
ケースに収納できなくなります

