


06 Important Reminder



- 1.Make sure the bottle is screwed in tight and parallel to the upper of the diffuser.Align lid port with internal port when closing.
- 2.After installation, please keep the machine vertical. Tilting or improper angle may cause oil to spill, contaminate the equipment's circuitry, affect normal use, and result in unnecessary waste.
- 3.Do not install the filter cartridge too far in.



07 Device Cleaning

Your aromatherapy diffuser should be cleaned every 1 to 2 months, or when changing scents, to ensure optimal performance.

1. Fill the empty oil bottle that came with the diffuser with 1/4-inch of purified water or distilled water.
2. Screw the filled bottle into the diffuser.
3. Run the diffuser for 15 minutes to allow the purified water or distilled water to penetrate the entire device.
4. Unplug the device from the power outlet and keep the diffuser upright. Wipe the device with a damp cloth to remove oil stains and fingerprints. Avoid using any strong or abrasive cleaning products.
5. Remove the filled bottle of purified water or distilled water and insert new aromatherapy oil. Reconnect the two halves of the diffuser and plug it back in. You're ready to begin a new round of fragrance enjoyment.


PRODUCT MANUAL

Waterless Scent Diffuser




01 Specification

- 【 Model 】 LRC-000331
- 【 Size 】 11.42*4.33*4.33 inch
- 【 Bottle 】 110ml
- 【 Input 】 5V/2A
- 【Working Power】 5W
- 【 Coverage 】 5300 ft³/10600 ft³/21000 ft³
- 【 N.W. 】 1.92 pound/0.87kg
- 【 Material 】 Aluminum




02 Installation Step



1. Take out the diffuserhead;
 2. Twist off the bottle and add a sealing ring;
 3. Fill the bottle with essential oil;
 4. Put the diffuser head back in the machine.
- Note: Do not fill the container too full with essential oil. The sealing ring should be placed at the bottom.**

03 Functional Analysis




- Model Button**
Short press to change model 1→2→3
- ON/OFF**
-Power on: long press Ⓢ to turn on the machine.
-Power off: long press Ⓢ to turn off the machine.
- Ambient Light**
-Press ☀ to turn On/off the ambient light.
Note: This can only be used when the machine is powered on.
- Timer**
-Press ⌚ once to switch to a different timer.
-When powered on, the default settings is 2-hour operation.
Note: When 2H/6H/12H are lit simultaneously, it is in 24-hour mode.

04 Safety

- 1.The diffuser should be used in an upright position always. Do not tilt the diffuser as oil can spill inside and damage the device.
- 2.Do not use the device with any other power cords. Please use the original power cord that comes with diffuser. Position the power cord to prevent tripping hazard.

05 Remote Control Functions



- ON**
Power on the diffuser
- OFF**
Power off the diffuser
- INTENSITY SETTING**
 - LOW**
Diffusing for 15 seconds and pausing for 180 seconds.
 - MED**
Diffusing for 20 seconds and pausing for 120 seconds.
 - HIGH**
Diffusing for 25 seconds and pausing for 60 seconds.
- WORKING TIME SETTING**
 - 2H**
The diffuser will shut down after operating for 2 hours.
 - 6H**
The diffuser will shut down after operating for 6 hours.
 - 12H**
The diffuser will shut down after operating for 12 hours.
 - 24H/7**
The diffuser will shut down after operating all the time.
 - ☀**
Lighting mode control
Mode 1: Always on
Mode 2: Always off
- MODE SETTINGS**
 - 1.Press once: L setting, diffuser releases fragrance for 15 seconds, then pauses for 180 seconds.
 - 2.Press again: M setting, diffuser releases fragrance for 20 seconds, then pauses for 120 seconds.
 - 3.Press again: H setting, diffuser releases fragrance for 25 seconds, then pauses for 60 seconds.
- TIMER SETTINGS**

To adjust the timer setting, please use the following instructions. This setting allows the device to cycle through the atomization mode for an extended period until the device automatically shuts off.

Default timer is 2 hours, the 2H LED will light up.

 - 1.Press once: Sets to a 6-hour timer; the 6H LED will light up.
 - 2.Press again: Sets to a 12-hour timer; the 12H LED will light up.
 - 3.Press again: Sets to a 24-hour timer; the 2H/6H/12H LEDs will light up simultaneously.
 - 4.Press twice to cancel the timer: All four small LEDs below the main indicator light will turn off.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

The devices has been evaluated to meet general RF exposure requirement, the device can be used in portable exposure condition without restriction