

说明书

使用方法：

- 1.长按电源键 3 秒开/关机，开机伴随有提示音。
- 2.打开手机蓝牙界面，在可用设备里找到蓝牙名 **yht-668** 进行点击配对，配对成功有提示音。
- 3.短按电源键暂停/播放循环
- 4.长按 “+” “-” 键调节音量大小，单击 “+” “-” 键切换上下曲。
- 5.单击灯光键，切换灯光模式。
- 6.输入端口为扬声器提供电源输入，以给电池充电；输出端口则可以给手机充电。
- 7.当蓝牙连接手机播放音乐，另一个水杯音箱双击灯光按键可以对联，同时播放相同的音乐。双击音箱灯光按键，则可以断开连接。
- 8.需要充电时轻轻揭开硅胶塞，选择 5V 输出充电器 连接上充电线即可充电。**充电指示红灯、充电时红灯慢闪、充满时红灯常亮**。充满电应及时拔下充电线，预防事故发生。

产品参数

额定充电电压:DC 5V 1A
喇叭功率：10W
电池：3.7V 5000mAh
频率范围:100Hz-20Hz
蓝牙版本：5.3
蓝牙保持距离：10m
音乐播放时间：约 17 小时（音量小到大）
充电时间：3.5 小时
输出充电时间：3.5 小时

产品使用注意事项

使用水杯音箱时，注意防水、防尘、防摔。如在使用过程中不慎渗水，应当及时关机取下音响擦干水渍，放置干燥处待完全晾干水渍再尝试开机打开音响使用。不使用时应当关机，保持电量，电池电量使用完及时充电，避免因长期亏电对电池造成损坏。

manual

Usage Methods:

1. Long-press the power button for 3 seconds to turn on/off the device; there will be a prompt tone when turning on.
2. Open the Bluetooth interface on your mobile phone, find the Bluetooth device named **yht-668** in the available devices, click to pair, and there will be a prompt tone when pairing is successful.
3. Short-press the power button to pause/play or switch the playback loop.
4. Long-press the “+” and “-” buttons to adjust the volume; click the “+” and “-” buttons to switch between the previous and next tracks.
5. Click the light button to switch the light mode.
6. The input port provides power input for the speaker to charge the battery; the output port can charge a mobile phone.
7. When one Bluetooth speaker plays music, double-click the light button of another cup-shaped speaker to pair them, and they will play the same music simultaneously. Double-click the light button again to disconnect the connection.
8. When charging is needed, gently remove the silicone plug, connect a 5V output charger and the charging cable.

- Red charging indicator light
- Red light flashes slowly during charging
- Red light stays on when fully charged

Unplug the charging cable promptly after full charge to prevent accidents.

Product Parameters:

Rated charging voltage: DC 5V 1A

Speaker power: 10W

Battery: 3.7V 5000mAh

Frequency range: 100Hz - 20Hz

Bluetooth version: 5.3

Bluetooth range: 10m

Music playing time: Approximately **17 hours** (from low to high volume)

Charging time: **3.5 hours**

Output charging time: **3.5 hours**

Product Usage Precautions:

When using the tumbler speaker, be cautious of water, dust, and drops. If water accidentally seeps in during use, turn off the device immediately, remove the speaker, dry the water stains, and place it in a dry area until completely dry before attempting to turn it on again. When not in use, turn off the device to preserve battery life. Charge the battery promptly when it runs out to avoid damage from long-term undercharge.

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.