


使用说明书

S6

夹耳式 蓝牙耳机

产品结构图



像戴耳夹一样将夹耳式耳机夹在耳廓上，佩戴好后调整耳机的位置直至调整到音效最为清晰的位置。

包装清单

耳机x1对
充电仓x1pcs
Type-C充电线x1pcs
说明书x1pcs

产品操作介绍

功能	操作	指示灯	提示音
配对名	S6		
开机	耳机在充电仓内打开充电仓盖,耳机自动开机.耳机开机状态长按触摸键3秒关机	冰蓝灯闪烁3次	提示音 "power on"
关机	耳机放回充电仓内合盖,耳机自动关机	红灯长亮1S熄灭	提示音 "power off"
设备配对	耳机开机,左右耳机自动互连后进入设备配对状态	主耳冰蓝灯交替闪烁,副耳熄灭	提示音 "pairing"
设备连接	打开蓝牙设备,搜索"S6"进行连接,连接成功	指示灯熄灭	提示音 "connected"
断开连接	耳机超出蓝牙信号范围,耳机与设备断开进入配对模式.此时可使其他设备连接耳机并配对成功.耳机超出3分钟未连接左/右耳机自动关机.	主耳冰蓝灯交替闪烁,副耳熄灭	提示音 "disconnected"
播放/暂停	音乐播放器启动后,双击左/右耳触摸键	/	/
上下曲	音乐播放器启动后,三击左耳上一曲,三击右耳下一曲	/	/
接听来电	来电状态,双击左或右耳触摸键	/	/
拒接来电	来电状态,长按左或右耳触摸键2S拒接来电	/	/
音量+	连接状态下,单击右耳触摸键音量+,最大音量	/	提示音 "清脆"
音量-	连接状态下,单击左耳触摸键音量-,最大提示音	/	提示音 "清脆"

呼出手机语音助手	连接状态下,长按左或右耳触摸键25秒,启动/关闭语音助手.(音乐状态下除外)	/	"咚"
耳机低电量提示	耳机电量低,每1分钟播报提示音1次,5次后关机.	耳机红灯快闪	提示音 "battery low"
清除配对	未连接设备状态,双击左或右耳触摸键5次后左、右耳机关机.(清除配对和连接的所有信息)(单耳、双耳都可以操作)	红灯长亮1S熄灭	提示音 "power off"
耳机充电	耳机放入充电仓内关盖,耳机开始充电红灯长亮,耳机充满指示灯熄灭		
充电仓给耳机充电	耳机放入充电仓内关盖,充电仓白色指示灯常亮,耳机电量充满充电指示灯熄灭.		
充电仓充电	充电仓电量过低时,请给充电仓连上标准5V电源适配器进行充电.充电仓充电时红灯闪烁,充满红灯常亮.		

耳机参数

产品名称:夹耳式 蓝牙耳机 产品型号:S6 蓝牙版本:Bluetooth 5.4 支持模式:AAC/SBC 蓝牙传输距离:10m 载波频率:2.402GHz~2.480GHz 频响范围:20Hz~20KHz	喇叭灵敏度:125dB ±3dB 喇叭阻抗:16Ω ±15% 喇叭额定功率:10mW 充电接口:USB Type-C 充电仓充电时间:≈1.5小时
---	---

简单故障排查

故障	原因	解决方法
不开机	耳机电量不足	对耳机进行充电
耳机闪白灯	耳机电量不足	对耳机进行充电
充电无提示	耳机没有放好	调整耳机放置的位置
自动关机	耳机电量不足	对耳机进行充电
耳机有回音	音量太大或者环境太嘈杂	调节音量或更换环境
耳机有杂音	外界干扰严重或距离手机太远	更换地点或靠近手机
对方声音小	耳机佩戴不正确或音量太小	调整耳机佩戴或音量大小
信号断续	外界干扰严重或距离手机太远	选择无干扰的环境或靠近手机

安全指引

- 初次使用本产品前,请先充满电再使用.
- 产品不能玩弄,12岁以下儿童须在成年人监护下使用.
- 请使用通过正规厂家安全认证的5V/1A充电器,避免支持高压电的快速充电器对产品造成损坏.
- 请在安全的环境下充电,在给充电仓充电时,电量充满后请尽快将充电线拔出,避免长时间充电对电池造成损坏.充电仓的充电方式为Type-C接口.
- 本产品内置不可拆卸的可重复充电电池,重复对耳机进行充电和放电会随时间推移而导致电池性能下降,这对于所有可以重复充电电池来说均属于正常现象.
- 本产品带有锂电池,如长时间未使用,请至少一个月充电一次.
- 因个体差异原因,如佩戴时感到皮肤不适,请停止佩戴并咨询医生.
- 在蓝牙耳机本产品使用时,请将耳机声音调至合适音量大小,以免长期在大音量状态下对听力造成损伤.
- 如果您在从事需要集中注意力的活动时使用本产品,应注意自身和他人的安全,例如驾车或骑自行车时,在道路、施工现场、铁路或徒步行走时,应取下耳机或调整音量以确保可以听到周围的声音,包括警报和警告信号.
- 请遵守所在地区或国家的相关规定,驾车时按照要求使用本产品.
- 本产品含有磁性材料,使用或安放产品时,请远离具有强磁场或强电场的电器,如微波炉、电冰箱等.

- 建议在温度-0℃~45℃的环境中使用本产品.当环境温度低于+5℃时,电池性能会受到限制.
- 有明文规定禁止使用无线设备的场所,请勿使用本产品,否则会干扰其它电子设备或导致其它危险.
- 靠近医疗及工业设备或登机之前,请咨询当地工作人员能否使用.
- 对本产品清洁和维护前,请停止使用本产品,关闭所有应用,并断开与其它设备的所有连接或线缆.
- 请根据本地法令,正确处理废弃电子产品,不可将电子电气设备、部件、电池与其它生活垃圾一起丢弃.

警告


- 请通读本说明书的内容后再行使用,避免产品因错误操作损坏.
- 本产品请远离儿童、火源、热源、冷冻源、水源及化学品.
- 请勿长时间使用大量收听,以免对听力造成不良影响.
- 请勿将产品及附件浸入任何液体或用水冲洗产品,否则导致火灾或触电危险.
- 请勿将产品放置在太阳晒射或者温度高的地方,高温会缩短电子部件的使用寿命、损坏电池、使某些塑料部件变形.
- 请勿将本产品放在尘土多、温度和湿度过高或过低的地方保存.
- 请勿将磁条卡(例如银行卡、公交卡等)长期接触本产品,否则可能导致磁条卡被磁场损坏.
- 请勿在本产品上施加较大的压力,或拆卸、摔打、震动本产品,以防产品损坏.
- 请勿在靠近热源处使用本产品,如散热器、热风调节器、炉灶或其他产生热量的仪器.
- 请勿堵塞基本产品的开口处,如充电口、指示灯、麦克风等.
- 请勿在暴雨天气下使用设备,雷暴可能导致设备出现故障,增大电击的风险.
- 请避免本产品及其配件雨淋或受潮,且剧烈运动或出汗较多时使用本产品,防止液体渗透到产品内部损坏本产品.
- 本产品属于内置聚合物锂电池,不可更换,请勿丢弃或置以火中,以免爆炸、起火等危险发生.
- 如因消费者违反上述警示而不恰当地使用所造成的人身及财产损失将自行承担一切后果本公司将不承担任何法律责任.

INSTRUCTION MANUAL

S6

clip-in-ear Bluetooth headphones

PRODUCT STRUCTURE DIAGRAM



The earphones are centered on the corridor as if you were wearing an ear clip. After wearing it, adjust the position of the headphones until they are adjusted to the clearest sound position.

PACKING LIST

Headphones x1 pair
Charging compartment x1pcs
Type-C charging cable x1pcs
Instruction manual x1pcs

PRODUCT OPERATION INTRODUCTION

Pairing Name	S6		
Power on	When the headset is in the charging compartment, open the charging compartment cover and the headset will automatically turn on. When the headset is turned off, press and hold the touch button for 3 seconds to turn it on.	Ice blue light flashes 3 times	Prompt sound "power on"
Shutdown	Put the earphones back into the charging case and close the lid, the earphones will automatically shut down.	The red light stays on for 1S and then goes off	Prompt sound "power off"
Device pairing	Turn on the headset, and the left and right headsets will automatically connect to each other and enter	The main ear flashes in blue, red and ice alternately, and the secondary ear is off	Prompt sound "pairing"
Device Connection	Open the Bluetooth device, search for "S6" to connect,Connect successfully	Light off	Prompt sound "connected"
Disconnect	When the headset is out of the Bluetooth signal range, the headset and the device are disconnected and enter pairing mode. At this time, the headset pairing name can be retrieved by other devices. The headset will automatically shut down if the left/right headset is not connected for more than 3 minutes.	The main ear flashes in blue, red and ice alternately, and the secondary ear is off	Prompt sound "disconnected"
Play/Pause	After the music player is started, double-click the left/right ear touch button	/	/
Up and down	After the music player is started, triple-click the left ear to play the previous song, and triple-click the right ear to play the next song.	/	/
Answering a call	Incoming call status, double-click the left or right ear touch key for 2S to reject the call	/	/
Reject call	Incoming call status, long press the left or right ear touch key for 2S to reject the call	/	/
Volume+	When connected, click the volume + button on the right earphone to adjust the volume to the maximum	/	Prompt sound "dong dong"
volume-	When connected, click the left ear touch button volume -, maximum	/	Prompt sound "dong dong"

Call out the mobile phone voice assistant	In connected state, press and hold the left or right ear touch button for 2 seconds to start/stop the voice assistant (except in music state)	/	"dong"
Headphones low battery reminder	The headset battery is low, and a warning tone will be played once every minute. After 5 times, the headset will shut down.	Headphones flash red light quickly	Prompt tone "battery low"
Clear Pairing	When not connected to a device, tap the left or right ear touch button 5 times to turn off the left or right earphone (Clear all pairing and connection information) (can be operated on one or both ears)	The red light stays on for 1S and then goes off	Prompt sound "power off"
Headphones charging	Put the earphones into the charging case and close the cover. The earphones start charging and the red light stays on. When the earphones are fully charged, the indicator light goes out.		
The charging case charges the earphones	Put the earphones into the charging case and close the cover. The white indicator of the charging case will be on. When the earphones are fully charged, the indicator of the charging case will go out. When the battery of the charging case is low, the white light will flash.		
Charging in the charging case	When the battery level of the charging case is too low, please connect the charging case to a standard 5V power adapter for charging. The red light flashes when the charging case is charging, and the red light stays on when it is fully charged.		

HEADPHONE PARAMETERS

Product name: clip-in-ear Bluetooth headphones Product Model: S6 Bluetooth version: Bluetooth 5.4 Support mode: AAC/SBC Bluetooth transfer distance: 10m Carrier frequency: 2.402GHz~2.480GHz Frequency response range: 20Hz~20KHz	Horn sensitivity: 125dB ±3dB Horn impedance: 16Ω ±15% Horn rated power: 10mW Charging interface: USB Type-C Charging time of charging bin: ≈1.5 hours
--	---

SIMPLE TROUBLESHOOTING

Fault	Reason	Solutions
Not On	The headset is low on power	Charge the headphones
Headphones flash white	The headset is low on power	Charge the headphones
Charging no prompt	The headphones are not in place	Adjust the position of the headphones
Automatic shutdown	The headset is low on power	Charge the headphones
The headphones are echoing	The volume is too loud or the environment is too noisy	Adjust the volume or change the environment
There is a noise in the headphones	Serious external interference or too far from the phone	Change location or close to the mobile phone
The other side is quiet	The headphones are improperly worn or the volume is too low	Adjust the wearing or volume of the headphones
The signal is intermittent	Serious external interference or too far from the phone	Choose a non-interference environment or close to the mobile phone

SAFETY GUIDELINES

- Please fully charge before first using this product.
- The product is not a toy, and children under the age of 12 must be used under adult supervision.
- Please use a 5V/1A charger certified by a formal manufacturer to avoid damage to the product caused by fast charging chargers that support high voltage.
- Please charge in a safe environment. When charging the charging compartment, please unplug the charging cable as soon as possible after the charge is full to avoid damage to the battery caused by long-term charging. The charging case is charged by Type-C interface.
- This product has a built-in non-removable rechargeable battery. Repeated charging and discharging headphones will reduce battery performance over time, which is normal for all rechargeable batteries.
- This product comes with a reasonable battery. If it has not been used for a long time, please charge it at least once a month.
- For individual differences, if you feel uncomfortable when wearing it, please stop wearing it and consult your doctor.
- When Bluetooth is connected to this product, please adjust the sound of the headphones to the appropriate volume to avoid damage to hearing in a high volume for a long time.
- If you use this product when engaging in activities that require concentration, you should pay attention to your own safety and that of others, such as driving or cycling, on roads, construction sites, railways, or walking on foot. You should remove the headphones or adjust the volume to ensure that the surrounding sounds, including alarms and warning signals, can be heard.
- Please abide by the relevant regulations of your region or country and use this product as required when driving.
- This product contains magnetic materials. When using or placing the product, please stay away from electrical appliances with strong magnetic or electric fields, such as microwave ovens, refrigerators, etc.
- It is recommended to use this product in an environment with a temperature of

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.