


KOUOS1

Smart Wireless Stereo Bluetooth Headphones



User Manual

Please read before use

Thank you for choosing our smart product.
To fully understand the device's features, we recommend that you read this manual carefully. This smartwatch offers a range of new practical features and services designed to enhance your user experience. Please note: The smart earbuds primarily connect to your device via Bluetooth.
We reserve the right to update the contents of this manual at any time without prior notice. We will not provide free warranty service for damage resulting from failure to follow the instructions provided. We remind you that if the headphones are damaged due to improper use, we will not provide free warranty service.


Basic Specifications

Name: Bluetooth Wireless Headphones
Model: KOUOS1

Headphone Case Specifications			
chip	AB	Touch	COF
Memory	16MB	Hall	Support
BT	BT5.4	button	
Screen size	1.83	Battery	40mAh+400mAh
Resolution	240*284	Charging Methods	TYPE-C

Headphone Specifications			
chip	AB	Noise reduction	Support
BT	BT5.4	In-ear testing	Not supported

Product Overview



App Connection Guide

Scan the QR code below or search for it in the app store to download and install the "zwsiv be" app, then register and log in.




Headphone User Manual

Automatic startup	Power on	The earbuds turn on automatically when removed from the charging case
	Pairing	1. Place the earbuds in the charging case and turn on the screen. After about 15 seconds, the screen will turn on and the earbuds will pair automatically. 2. Place the earbuds in the charging case, turn on the screen, and press and hold the power button on the case for about 5 seconds to pair manually.
	Return to Pair	Remove the phone that was previously connected and take it out of the charging case. It will automatically reconnect to the last phone it was connected to.
Automatic shutdown	Shut down	If the headphones are not connected to a phone for 3 minutes, they will automatically turn off.
	Automatically reconnect on startup	After turning on the device, pair the earbuds first, then reconnect to your phone. (This will only work if the device has been connected to your phone before.)
	Disconnect	The headphones are connected to the phone; the phone's Bluetooth is turned off, or the headphones are out of range of the phone.
MFB Multifunction button	Shut down	Place it in the charging case; closing the lid will automatically turn it off.
	Play	While in standby mode, press the left or right earbud once. Launch the music player to start playing music.
	Pause	While music is playing, press the left or right earbud once to pause the music.
	Previous Track	While music is playing, double-tap the left earbud to skip to the previous track.
	Next Song	While music is playing, double-tap the right earbud to skip to the next track.
	Turn down the volume	While music is playing, tap the left earbud three times to lower the volume.
	Turn up the volume	While music is playing, tap the right earbud three times to increase the volume.
	Voice Assistant	While in standby or music mode, press and hold the left or right earbud for 2 seconds to switch voice assistants.


Note: The MFB button can be configured in the earbud case under Menu > Button Settings or on the app's home screen under Button Settings.

Headphone Case Features


1. First-time startup
Press and hold the Power button for 5 seconds to turn on the device, select a language, then scan the QR code or search for it in the app store to download and install the "zwsiv be" app to connect.




2. Dial Settings
Press and hold the watch face for 3 seconds to switch to more watch faces.



3. Phone
Includes call history, contacts, dial pad, and SOS




4. Headphone Button Settings
(1) Normal: Supports synchronized or independent operation for the left and right ears. Available gestures include single tap, double tap, and long press. Configurable functions include voice assistant, previous track, next track, volume up, volume down, pause/play, and low-latency mode.
(2) Incoming Call: Call Control mode: single tap, double tap, and long press. Available functions include hang up and answer. (3) During Call: Control methods include single tap, double tap, and long press. Available functions include hang up.



4. Headphone Button Settings
(1) System Menu:
About: View Bluetooth name, version, Bluetooth address, and headset Bluetooth name.
Factory Reset: Confirm/Cancel factory reset.
Restart: Swipe right to restart.
Power Off: Swipe right to power off.




(2) Display
Adjustable brightness: swipe left to set the screen-on time.




(3) Themes
Switchable theme styles




(4) Time Settings:
You can set the date, time, and time format.



(5) Languages:
Up to 18 languages available




(6) Password:
Password toggle: allows you to change the password




(7) Audio Alerts:
When enabled, audio alerts will sound when the lid is opened or the screen is operated; the volume of the audio alerts can be adjusted.




6. AI Translation
Connect your phone and open the app to view translations in real time.



7. Music
Supports scrolling lyrics at the top of the screen; left-click to skip to the previous track, right-click to skip to the next track; double-click the left button to pause playback.



8. Sound Effects
Six sound effects are available: Normal, Pop, Rock, Jazz, Classical, and Folk. Simply tap the corresponding icon to enable it.



9. Mode Selection:
You can switch between Music Mode and Game Mode.



10. Voice Assistant
You can ask about the weather, play music, and more




11. Locate Headphones
Tap the record button to enter flashing search mode; you can locate both the left and right earbuds at the same time.



12. GPS
View your current location




13. Find My Headphones
Tap the icon to enter Find My mode




14. Stopwatch
Right-click to start the timer; left-click to start timing; you can view the timing history.




15. Calendar
Displays the current date; swipe up or down to view the calendar



16. Business Cards and Payment QR Codes
You can set up various business cards and payment QR codes in the app.




17. Weather
Displays the current weather and the forecast for the next three days:




18. Camera
Tap to take a photo when connected to the app



19. Messages
You can receive messages in the app. Tap a message to view its details, and swipe to the bottom to delete it with a single tap.




20. Alarms
You can add multiple alarms, and each alarm can be edited individually.



21. Counter
Right-click to view the count; left-click to reset the count



22. Game
Bird: Tap the screen to make the bird fly up, and move forward without touching the pillars.



App Features


1. Home
From left to right:
Left earbud battery level;
Charging case battery level;
Right earbud battery level




(1) AI Exploration:
Features include intelligent voice dialogue and AI chat functionality




(2) Translation and Communication:
Options include simultaneous interpretation, translation device mode, free-form speaking, and the smartphone + headphones mode




a. Simultaneous Interpretation: The language on the right is the one being recorded on the phone; the language on the left is the one being played through the headphones. Phone recording (Chinese) Headphone output (English). The translation will be synchronized to the earbud case. Under normal circumstances, the recording function will remain active at all times.




b. Translation Mode: This mode uses your phone to record audio, which is then played back through the earbuds. Tap the record button on the right to record Chinese on your phone and hear the English translation through the earbuds; tap the record button on the left to record English on your phone and hear the Chinese translation through the earbuds. The translation results are synced to the earbud case. Under normal circumstances, the recording function will automatically turn off after you finish recording a clip.




c. Free Speech Mode: Once recording is started, you can speak in both languages without switching modes; the AI will automatically recognize your speech. Both the recording and the translation output are played through the headphones. The translation results are synced to the earbud case. Under normal circumstances, the recording function remains active.



d. Phone + Headphones Mode: Currently, all recordings are made on the phone. Tap the record button on the right to have the phone record Chinese and play the English translation through the headphones; tap the record button on the left to have the phone record English and play the Chinese translation through the headphones. The translation results will be synced to the headphone case. Under normal circumstances, the recording function will automatically turn off after one recording is completed.



(3) Audio Mode:
Choose between Music Mode and Game Mode.



(4) EQ Settings:
Options include Default, Pop, Rock, Jazz, Classical, Folk, and Custom.



(5) Button Settings:
You can configure the functions for single-tap, double-tap, triple-tap, and long-press on the left and right earbuds.

2. Discover
See more short videos

3. Equipment
View the status of the device

(1) The connection status of the device's earbud case; to disconnect, tap the "Unpair" button at the bottom of the page.

(2) Watch Face Center:
a. Select the watch face you want and tap "Save"; the earbud case screen will display the same image.

b. For custom watch faces, you can set the background, font color, and text orientation. Once you're done, click "Save" to sync the changes.

C. Text-to-image tools can generate images based on your description.

(3) Find Charging Case:
When you tap the "Find Charging Case" feature, the charging case's screen will light up.

(4) Remote Photo Capture:
Tap "Remote Photo Capture" in the app, and the charging case will simultaneously activate the camera function; tapping the screen on the charging case will trigger the app to take a photo.

(5) Contact Sync:
You can sync your phone's contacts to the charging case

(6) Message Notifications:
When the corresponding app's notification switch is turned on, the charging case will display a pop-up notification when your phone receives a message; when turned off, the opposite applies

(7) Do Not Disturb Mode:
When Do Not Disturb mode is enabled, your phone will not display pop-up notifications for incoming messages; when disabled, the opposite applies

4. My
View your personal information

(1) Personal Information: Edit your personal information

(2) Payment Code: Add a QR code from the corresponding app to sync it to the earbud case

(3) Payment Code: Add a QR code from the corresponding app to sync it to the earbud case

(4) Account Security: Change your login password and deactivate your account

(5) More Settings: Includes temperature units and time format

(6) More Settings: Includes temperature units and time format

(7) More Settings: Includes temperature units and time format

(8) More Settings: Includes temperature units and time format

(9) More Settings: Includes temperature units and time format

(10) More Settings: Includes temperature units and time format

(11) More Settings: Includes temperature units and time format

(12) More Settings: Includes temperature units and time format

(13) More Settings: Includes temperature units and time format

(14) More Settings: Includes temperature units and time format

(15) More Settings: Includes temperature units and time format

(16) More Settings: Includes temperature units and time format

(17) More Settings: Includes temperature units and time format

(18) More Settings: Includes temperature units and time format

(19) More Settings: Includes temperature units and time format

(20) More Settings: Includes temperature units and time format

(21) More Settings: Includes temperature units and time format

(22) More Settings: Includes temperature units and time format

(23) More Settings: Includes temperature units and time format

(24) More Settings: Includes temperature units and time format

(25) More Settings: Includes temperature units and time format

(26) More Settings: Includes temperature units and time format

(27) More Settings: Includes temperature units and time format

(28) More Settings: Includes temperature units and time format

(29) More Settings: Includes temperature units and time format

(30) More Settings: Includes temperature units and time format

(31) More Settings: Includes temperature units and time format

(32) More Settings: Includes temperature units and time format

(33) More Settings: Includes temperature units and time format

(34) More Settings: Includes temperature units and time format

(35) More Settings: Includes temperature units and time format

(36) More Settings: Includes temperature units and time format

(37) More Settings: Includes temperature units and time format

(38) More Settings: Includes temperature units and time format

(39) More Settings: Includes temperature units and time format

(40) More Settings: Includes temperature units and time format

(41) More Settings: Includes temperature units and time format

(42) More Settings: Includes temperature units and time format

(43) More Settings: Includes temperature units and time format

(44) More Settings: Includes temperature units and time format

(45) More Settings: Includes temperature units and time format

(46) More Settings: Includes temperature units and time format

(47) More Settings: Includes temperature units and time format

(48) More Settings: Includes temperature units and time format

(49) More Settings: Includes temperature units and time format

(50) More Settings: Includes temperature units and time format

(51) More Settings: Includes temperature units and time format

(52) More Settings: Includes temperature units and time format

(53) More Settings: Includes temperature units and time format

(54) More Settings: Includes temperature units and time format

(55) More Settings: Includes temperature units and time format

(56) More Settings: Includes temperature units and time format

(57) More Settings: Includes temperature units and time format

(58) More Settings: Includes temperature units and time format

(59) More Settings: Includes temperature units and time format

(60) More Settings: Includes temperature units and time format

(61) More Settings: Includes temperature units and time format

(62) More Settings: Includes temperature units and time format

(63) More Settings: Includes temperature units and time format

(64) More Settings: Includes temperature units and time format

(65) More Settings: Includes temperature units and time format

(66) More Settings: Includes temperature units and time format

(67) More Settings: Includes temperature units and time format

(68) More Settings: Includes temperature units and time format

(69) More Settings: Includes temperature units and time format

(70) More Settings: Includes temperature units and time format

(71) More Settings: Includes temperature units and time format

(72) More Settings: Includes temperature units and time format

(73) More Settings: Includes temperature units and time format

(74) More Settings: Includes temperature units and time format

(75) More Settings: Includes temperature units and time format

(76) More Settings: Includes temperature units and time format

(77) More Settings: Includes temperature units and time format

(78) More Settings: Includes temperature units and time format

(79) More Settings: Includes temperature units and time format

(80) More Settings: Includes temperature units and time format

(81) More Settings: Includes temperature units and time format

(82) More Settings: Includes temperature units and time format

(83) More Settings: Includes temperature units and time format

(84) More Settings: Includes temperature units and time format

(85) More Settings: Includes temperature units and time format

(86) More Settings: Includes temperature units and time format

(87) More Settings: Includes temperature units and time format

(88) More Settings: Includes temperature units and time format

(89) More Settings: Includes temperature units and time format

(90) More Settings: Includes temperature units and time format

(91) More Settings: Includes temperature units and time format

(92) More Settings: Includes temperature units and time format

(93) More Settings: Includes temperature units and time format

(94) More Settings: Includes temperature units and time format

(95) More Settings: Includes temperature units and time format

(96) More Settings: Includes temperature units and time format

(97) More Settings: Includes temperature units and time format

(98) More Settings: Includes temperature units and time format

(99) More Settings: Includes temperature units and time format

(100) More Settings: Includes temperature units and time format

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.