

chirpful

SMART BIRD CAMERA & SOLAR PANEL COMBO PACKAGE

USER MANUAL



Online Instructions



birds
CHOICE

Hello & Welcome

Thank you for choosing Chirpful.

The Chirpful bird-watching camera offers 4K video recording and 1080P live streaming in a compact design, equipped with a solar panel. Its lightweight build allows it to be mounted anywhere and adjusted in any direction using the included clamp and flexible bracket.

Powered by AI technology, the camera can accurately identify over 10,000 bird species.


Additionally, it features an intelligent bird conversational encyclopedia, enhancing your bird-watching experience with detailed insights. With exceptional image quality and innovative features, Chirpful ensures a delightful and rewarding experience every time.

Content

1. Quick Start	03
2. Discover Features	13
3. Product Scenarios	16
4. Specification Form	18
5. Troubleshooting & FAQs	20
6. Warranty	22


1.Quick Start

Inside the Package (Camera)



Camera x1

Inside the Package (Solar Panel)



Solar Panel x1

Inside the Package (Accessories)



Metal Flexible Bracket
x2



Hose Clamp
x4



Thumb Screw
x2



Washer
x2




Screw
x6



Anchor
x6



Bracket Base
x2



Locator Sticker
x2



USB-C Cable
x1



Solar Panel Cable
x1



THE ABOVE ACCESSORIES ARE USED FOR THE CAMERA AND THE SOLAR PANEL INSTALLATION AND CHARGING

Get the Camera & Solar Panel Ready

1 Take Out the Camera

Take the camera out of the box, and hold down the power button to turn on the camera. The status indicator light (green) will illuminate, indicating that the camera has started up normally (The indicator light will flash in green, indicating that you need to configure Wi-Fi network for the first time).




Indicator Light Status

 Green light on	The camera is powered on and operating (To save power, the light will turn off after 30 seconds, but the camera remains operational and is not shut down).
 Green light flashing	The camera is in App configuration mode (it can be discovered by the App during this time).
 Yellow light on	The camera is charging.
 Yellow light flashing	The camera is connected to a transfer device and has entered USB drive mode, allowing data to be read from the camera.
 Red light on	Camera error.
 Red-yellow-green flashing alternately	Firmware is updating. The camera will restart once the update is complete.


2 Using the App

Download Chirpfal App




Add the Camera to Your Account

Click Add Your Camera on the App (Home page or Camera page) and follow the steps on the App page to add the camera.




Set up the Camera

Through the App, you can view the operating status of the camera, including basic information such as current battery power, signal strength, storage space, etc. You can modify the operating specifications of the camera in the settings.



Collect Images & Live Streaming

When the camera is functioning properly and the network connection is stable, you can view live video captured by the camera directly through the App and stream it seamlessly in real-time.



Other Features of the App

Sharing with Others: The camera owner can share the camera feed and cloud album with family, friends, or others through the App, making it easy to share bird sightings.

AI-Powered Features: The App supports AI-powered bird identification, recognizing up to 10,000+ species. It can also filter out non-bird images for a cleaner experience.

More features coming soon...



Sharing
with Others



10000+
Species Bird
Identification



Smart Tagging
& Filters



More...

FREE PLAN

0.5G/3 Days
Cloud Storage

Recording Duration
10s/20s

4K Video Recording
on SD card

20x/month 4k video
download

Share photos & videos
on social media

Pairs with 1 camera

STANDARD PLAN

5G/60 Days Cloud
Storage

10s/20s/30s
Recording Duration

4K Video Recording
on SD card

Unlimited 4K Video
Download

Unlimited AI Bird
Recognition (10000+)

AI Bird Species Album

AI Smart Alerts: Notify
only or specific bird
species or no alerts for
selected species.

50 /month
conversations with
Dr. Bird

Share with up to
10 friends

Can be used with two
cameras under the
same account

PREMIUM PLAN

15G/90 Days Cloud
Storage

10s/20s/30s/60s
Recording Duration

4K Video Recording
on SD card

Unlimited 4K Video
Download

Unlimited AI Bird
Recognition (10000+)

AI Bird Species Album

AI Smart Alerts: Notify
only or specific bird
species or no alerts for
selected species.

100 /month
conversations with
Dr. Bird


Share with up to
10 friends

Can be used with 10
cameras under the
same account


3 Installation

Camera

You can mount the camera anywhere using the Metal Flexible Bracket. Adjust its angle and tighten it with the thumbscrew to secure it in place. Use the Bracket Base and Hose Clamp to attach the bracket to a pole and point the camera at the bird feeding tray. This is just one way to install it—you can set it up however you prefer.




Adjust the camera to the desired direction, then tighten the thumbscrews in the opposite direction to lock it in place and prevent movement.



Solar Panel

The installation steps for the solar panel are the same as the previous steps. Aim the solar panel towards the sunlight and connect it to the camera using the charging cable to ensure long-term battery life.




THE BRACKET IS ADJUSTABLE. FIX THE SOLAR PANEL SECURELY AND POINT FACING TRUE SOUTH TO MAXIMIZE YEAR-ROUND EXPOSURE TO SUNLIGHT.


Connect the camera to the solar panel using the included cable, then position the camera 4-12 inches from the bird feeder. Adjust the solar panel to face the sun for optimal charging. Once everything is set up, ensure the camera is placed in an area with a stable Wi-Fi signal. Now, relax and enjoy watching the birds visit your feeder!



You can also mount the camera and solar panel by drilling holes into a wall or tree and securing the bracket base with screws. (The location sticker for accurate positioning is included in the accessory package.)



Use stickers to locate the drilling position, drill holes



Insert anchors

Tighten with screws



Install the bracket

2. Discover Features


Quick Trigger to Capture Bird Moments

The sensitive and fast camera trigger (trigger speed is less than 0.5s) will not miss any bird that comes to visit. You can clearly know which little cuties are moving around your house.




Ultra-Clear 4k Video (Standard & Premium Plan)

It supports up to 4K video recording, clearly showing the details and colors of each bird, presenting you with excellent and high-quality videos.




High-Definition 1080P Live-Streaming

Support 1080P live-streaming, presenting you with high-definition real-time streaming video.




Accurate AI Bird Identification (Standard & Premium Plan)

Supports AI bird Identification, which can identify more than 10,000 species of birds with high accuracy, allowing you to not only photograph the bird, but also know its name.



Intelligent Chat-Style Bird Encyclopedia

Dr. Bird, an Intelligent Chat-Style bird encyclopedia, supports asking questions about birds through conversations, helping you better understand birds (standard & premium plan).



All-in-One Easy-to-Use App

The feature-rich and easy-to-use App allows you to check camera status, set up the camera, watch live-streaming, view images, play with AI functions, and more, giving you a new and exciting experience.

3. Product Scenarios

A Fun-Filled Birdwatching Journey with Unexpected Visitors to Your Yard or Balcony

Do you often hear birds around your yard or home but never get the chance to see them up close? This camera allows you to observe their true beauty, identify which visitors stop by, and capture high-quality photos and videos. You might even witness unexpected guests, like large birds or small mammals you've never seen before, appearing right in front of your camera. It's an exciting way to bring unique and joyful moments to your day.



A Great Way to Get Kids to Love Nature

This camera is a wonderful tool for sparking children's interest in nature. They can observe various species of birds and other small animals in their daily activities, cultivating a deeper appreciation for wildlife. It not only expands their knowledge, but also encourages curiosity and a love for the natural world.



An Ideal Gift for the Holidays

Looking for the perfect gift for birthdays or holidays? This camera is a great choice for family and friends. It's more than just a fun and innovative device – it features a camera-sharing function that allows you to connect with others, share captured bird moments, and enjoy the experience together. It's a thoughtful way to strengthen relationships and create shared memories with loved ones.



4K Video



32 MP Photo



6x Slow-Motion
Photography



Smart Tagging &
Filters



Keep Your Camera
Running 24/7



AI Bird Expert



Lightweight &
Portable



Recognizes
10,000+
Bird Species



2.4G/5G Wi-Fi



Real-time
Notification



IP66 Waterproof



3000 mAh
Battery

4. Specification Form

Camera

Item	Specification
Dimension	2.32" x 2.32" x 2.47"
Net weight	140g
Bird detection range	0.98 ~ 6.56 ft, 80°
Image quality	Photo: up to 32MP Video: up to 4K
Live streaming	Supported in App
Battery	3,000 mAh
Input	5V, 1 ~ 2A
Memory	Built-in 32GB
Connection	2.4G/5G Wi-Fi
Working temperature	-4 °F ~ 131 °F
Working humidity	5% ~ 90%
Waterproof	IP66

Time zone	Based on Your Location
Material	Plastic (ABS, PC), metal

Solar Panel

Output	DC (4.4x1.6mm) 5V/ 1A
Max Output Power	5W (±5%)
Dimensions	9.29" x 5.35" x 0.98"
Weight	8.71 oz
Waterproof	IP66

WARNING:

- Risk of fire or explosion if the battery is replaced with an incorrect type.
- Do not dispose of the battery in fire, hot ovens, or attempt to crush or cut the battery, as this can cause an explosion.
- Avoid exposing the battery to extremely high temperatures, which may result in an explosion or leakage of flammable liquid or gas.
- Do not subject the battery to extremely low air pressure, as this may cause an explosion or leakage of flammable liquid or gas.

5. Troubleshooting & FAQs

Pairing and adding camera problems

Before using the camera, please use the App to add the camera to your account. Please follow the instructions on the App.

If the App notifies that the device has already been paired, please contact our support team for assistance.

Wi-Fi network connecting problems

To work properly, the camera must be connected to a Wi-Fi network and be within its coverage area. Otherwise, the App will not receive photos or videos.

It is recommended to configure the Wi-Fi network during the camera setup process. If skipped, you can configure the Wi-Fi in Camera » Set » Configure the Wi-Fi network.

If the network setup fails, double-click the Power button to put the camera into "Network Configuration Mode" and try again.

How to change the Wi-Fi network for the camera

If you want to switch the current camera's Wi-Fi network, double-click the Power button on the back of the camera to enter "Network Configuration Mode", then select the new Wi-Fi you want to use for the camera in App » Settings » Network and configure it.

The indicator light goes out after powering on

After powering on, the camera indicator light (green light) will turn on and go out after 5 minutes. This is a power-saving feature and does not mean the camera has stopped working. Rest assured, the camera is functioning normally.

How to upgrade the camera firmware

To upgrade the camera firmware:

- 1) Go to App » Settings » Device Information » Firmware.
- 2) Click "Check Upgrade" to see if a new firmware version is available.
- 3) If available, update the firmware through the App. Ensure the camera has sufficient battery and available storage space before upgrading.

How to set up the camera

Once the camera is turned on, go to App » Settings. Here, you can configure operating settings, image quality, and view device details.

The camera is triggered too frequently

If the camera triggers too often or experiences false triggers, try the following steps:

- 1) Avoid pointing the camera directly at the sun, as the heat can activate the PIR sensor.
- 2) Do not place the camera near flowers, plants, or trees that sway in the wind, as movement can trigger the camera.
- 3) Ensure the camera is placed on a stable surface. A shaking camera may cause false triggers.
- 4) Lower the Detect Sensitivity in the App settings to reduce the sensor's sensitivity and minimize false triggers.

The camera does not trigger shooting

If the camera doesn't send images to the App, follow these steps:

- 1) Check if the camera is working by reviewing the last synchronization time in the App or testing live streaming.
- 2) Verify the Wi-Fi network status. Poor Wi-Fi signals may prevent images from being sent to the App.
- 3) Adjust the Detect Sensitivity in the App settings. (Setting it to 0 disables the trigger function.)
- 4) Connect the camera to a computer using a USB-C cable to check for local images. If images are present locally but not sent, the camera is functioning, but connectivity needs to be resolved.

Can I replace the camera's SD card?

The camera's SD card cannot be replaced. It features a built-in 32GB memory card. To access the stored data, connect the camera to a computer using a USB-C cable.

AI recognition is inaccurate

AI recognition may fail if the bird's posture in the image is poor, such as when the bird is facing away from the camera or partially obscured. This can lead to recognition errors.

How long can the battery last? Can I use solar panels?

Battery life depends on the number of triggers the camera records. To extend battery life, you can connect the camera to an external solar panel.

6. Warranty

Birds Choice products are warranted to be free from defects in material or workmanship for the life of the product, except as described below. Birds Choice's responsibility under this warranty is limited solely to the repair or replacement of a defective or damaged product or parts, in Birds Choice's discretion.

This warranty applies only when the product has been used in accordance with Birds Choice instructions.

This warranty does not cover damage resulting from attempted or unauthorized repairs, cosmetic scratches from squirrels or other animals, sun fading, weather-related damage, accidents, dropped or fallen feeders, improper handling, shipping damage, misuse, abuse, or neglect. No other warranties, expressed or implied, are provided and all implied warranties are disclaimed.

Birds Choice is not liable for any incidental or consequential damages, and all implied warranties are disclaimed.

Proof of purchase and prepaid return of the part or product may be required.

All warranty claims must be submitted by emailing birdlovers@birdschoice.com.

Manufacturers' warranties may vary depending on factors such as product use, place of purchase, or seller. Please review your warranty documentation carefully and contact the manufacturer with any questions.

In addition to the Birds Choice warranty, all recycled plastic HDPE components are covered by a 10-year manufacturer's warranty, guaranteeing the material will not fade, split, or crack.

Recycled plastic HDPE components are warranted to be free from material or manufacturing defects that cause fading, cracking or splitting, for a period of 10 years from the date of purchase.

Birds Choice is not liable for incidental or consequential damages arising out of breach of this warranty or defects in the products

Replacement Parts

If Birds Choice replaces a part under this warranty, and the replacement part fails within 12 months of the replacement, Birds Choice will replace such part at no charge.

Replacement parts are covered under the same warranty terms stated above. For replacement parts, customers must provide proof of purchase within the past 12 months. Requests outside of the 12-month warranty period may be fulfilled at wholesale pricing to wholesale store customers.

WARNING:

FCC regulation

Federal Communications Commission - Part 15



This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the Federal Communications Commission rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Radiation Exposure Statement To comply with FCC RF exposure compliance requirements, this grant is applicable to The antennas used for this transmitter must be installed to or operating in conjunction with any other antenna or transmitter. only mobile configurations. provide a separation distance of at least 20cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

Download Chirpful App

