

刀模线不印刷

杯子音响说明书

尺寸：88.9x101.6mm

材质：80g书写纸,黑白单色双面印刷,按照页码顺序骑马钉装订



Tumbler Speaker

ENGLISH MANUAL



CHARGE DIRECTIONS AND USE:

- Fully charge the speakers before using them for the first time.
- Plug the included USB charging cable into the speakers.
- The LED light will light up Red when the speakers are charging. When the speakers are fully charged the LED light will turn completely shut off (to save battery).



Attention: Please use the original included charging cable to connect the speakers to your computer or compatible USB charging device.



Power On: Press & hold power button until LED Lights goes on.

Power Off: Press & hold power button Until LED Light goes flashes and the device powers off.



BLUETOOTH® PAIRING:

Turn on the speaker holding the power button for about 2 sec until LED lights begin to blink.

be ready to pair to your mobile device.

From your smart phone or tablet, find a list of nearby devices and choose “RT-TBS20C” or “Cup”, the speaker will tell you when pairing is completed.

 Attention:

Your speaker will work best if it is within 30ft of your smart device. You may experience sound briefly cutting off if you are out of range or if your wireless connection is weak. If the speakers are not paired with a device after 5 minutes, they will turn off automatically. Make sure the option Bluetooth® is enabled on your smart phone or tablet before starting the pairing process.

MUSIC CONTROL

Play / Pause: Tap the power button

Vol +: Press and hold the + Button

Vol -: Press and hold the — Button

Next Track: Tap the + Button

Previous Track: Tap the — Button

Change Mode: Double press the power button

FCC Disclaimer

Note: This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does Cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: Changes or modifications not expressly approved by Pom Gear could void the user's authority to operate this equipment.

FCC Radiation Exposure Statement

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. The device can be used in portable exposure condition without restriction.