

[illegible]

YX66




YX66

wireless bluetooth earphones

PRODUCT PARAMETERS

Product Name:	wireless bluetooth earphones
Bluetooth version:	V6.0
Pairing name:	YX66
Supporting protocols:	A2DP/AVRCP/HFP/HID/AVCTP/AVDTP SPP
Working frequency:	2.402-2.480GHz
Charging current:	Earphones 30mA/DC 5V Charging case 300mA/DC 5V
Battery capacity:	Earbuds:25mAh Charging case:230mAh
Charging time:	Earbuds:1h Charging case:2h
Listening time:	about 4.5 hours
Bluetooth receiving distance:	<10 meters (barrier free)

TOUCH AREA DIAGRAM



INSTRUCTIONS FOR USE


- Bluetooth Name: YX66;
- Usage Notes: After opening the package, take the earphones out of the charging case;
- Pairing Connection: Open the charging case, wait 3-5 seconds for both earphones to automatically pair, then search for the Bluetooth name "YX66" in your phone's Bluetooth settings and tap to connect;
- Power On: Open the charging case, and the earphones will power on automatically to connect to the previously paired device;
- Power-off: Place the earphones back into the charging case and close the lid; the earphones will automatically start charging;
- Volume Down: Long-press to touch the left earphone;
- Volume Up: Long-press to touch the right earphone;
- Previous Song: In playing status, triple-tap to touch the left earphone;
- Next Song: In playing status, triple-tap to touch the right earphone;
- Pause/Play: Single-tap any key on the left or right earphone;
- Answer Call/Hang Up: Single-tap any key on the left or right earphone;
- Voice Assistant: Double-tap any key on the left or right earphone;
- Reject Call: In incoming call status, double-tap any key on the left or right earphone.

CHARGING INDICATOR LIGHT

- When the charging case charges the earphones, the digital display marquee light flashes, and the light turns off after full charging;
- When the charging case is charged with a cable, the digital display font flashes, and the digital display font of 99% stays on after full charging.

(Please be sure to use 5V/1A charging cable or attached charging cable when you purchasing products)

PRODUCT DIAGRAM



MATTERS NEEDING ATTENTION

- Please put the headset in correct position for charging;
- The battery (battery pack or combination battery) shall not be exposed to such conditions as sun, fire or similar overheating;
- Listening to music at a high volume for a long time will cause hearing damage. Please adjust the volume appropriately when using this device;
- Do not use the device during thunderstorms, because thunderstorms may cause abnormal operation of the device and increase the risk of electric shock;
- Do not dismantle or modify the headset for any reason, otherwise, it may cause malfunction or burning out, which is not under warranty.

*If the consumer violates the above warning and uses it improperly, resulting in personal and property damage, the company will bear all consequences and will not bear any legal responsibility.

FCC Warning Statement

FCC COMPLIANCE STATEMENT:
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.
Warning: Changes or modifications to this unit not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.
FCC Radiation Exposure Statement
The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.

