

3. Paste it on the wall and press firmly

Diagram illustrating the components of the battery-powered sprayer:

- Nozzle
- Power Cord
- Power Plug (Note: Plug-in version is a plug, battery version is not plug)
- User Manual
- Control Panel

1. Clean the pasting position, the pasting surface should be a flat surface. It can also be placed on the table without hanging
2. Tear off the protective film on the back plate

4. Hold the spray nozzle, pull it upwards to take out the spray nozzle body with the spray bottle

5. Rotate and install the bottle containing essential oil into the atomization module as shown in the diagram

6. Install the spray nozzle into the main unit and press firmly into place

-

Battery installation diagram (for battery version only)

3x1.5V
180 battery

- ① Press and slide down the battery cover firmly to see 3 size AA battery slots

Name	Intelligent fragrance machine	Product Model	cos
Power Supply	DC5V/1A	Rated power	2W

① When installing essential oil and after installing essential oil, do not tilt/invert/put the fumigator sideways. Ⓢ

- 
- No tilting or inversion.

⚠ This appliance is not intended for use by individuals with physical, sensory or mental disabilities, or those lacking experience and knowledge, including children, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

【Single machine mode】

1. Connect the power supply (or install batteries);
2. Press the power button , and the power light will turn on at the same time
3. Press the M button to switch between 5 standalone gears: Max, High, Middle, Low, Min, and the corresponding gear light will turn on.

Max: Work 50S, Stop 50S
High: Work 35S, Stop 50S
Middle: Work 25S, Stop 120S
Low: Work 15S, Stop 50S
Min: Work 10S, Stop 50S

【APP mode】

1. Connect the power supply (or install batteries);
2. Press the power button , and the power light will turn on at the same time
3. Scan the QR code on the side of the machine with your mobile phone, download the APP, and enter the Bluetooth APP mode (at this time, the APP will automatically connect to the machine)

1. Open the dedicated APP that has been downloaded on your phone and you can switch to the Bluetooth APP mode.
2. Enter the APP and click on the Bluetooth mode. Click on the refresh icon Click dev.... Enter the original password 8888 to connect to the machine , as shown in Figure 1, Figure 2 below.

Figure 1
continued

Figure 2

Figure 3

Figure 4

Figure 5

Figure 6

4. Click on any time slot, as shown in Figure 7

① In week mode, you can choose whether the week icon is lit or not. For example, if the icons on Thursday and Saturday are not lit, they will not work on Thursday and Saturday (if they are lit, they will work; if they are not lit, they will not work);

② Time period setting, sliding up and down into the time setting, starting at 08:00 and ending at 20:30 in Table 7;

③ Set the fragrance spraying time by sliding up and down. The fragrance spraying time is adjustable from 5s to 60s, and the interval time is adjustable from 60s to 90s. Click confirm after setting to complete the

The screenshot shows a 'Modify Model 1' interface. At the top, there's a 'www.bosch' logo and a 'Model 1' label. Below is a weekly schedule grid with days of the week and time slots. The 'Time period setting' section shows a sliding bar from 08:00 to 20:30. The 'Fragrance spraying time' section shows a sliding bar from 5s to 60s. At the bottom, there are 'Cancel' and 'Confirm' buttons.

Figure 1

1. Be sure to unplug the power plug before cleaning the product. Product appearance stains can be wiped clean with a soft and clean rag. When it is necessary to remove stubborn stains, be sure to use a mild and neutral cleaner.
2. Do not immerse the main unit in water, and keep the outside of the main unit dry.
3. When the product is not used for a long time, it is recommended to clean the internal atomizing head. The specific operation is as follows: add alcohol to the empty bottle, run for 5 minutes, then turn off the equipment and clean the alcohol in the bottle.
4. Clean and maintain the atomizing head with alcohol every 1-2

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates use and can radiate radio frequency energy

There are no known safety hazards or uses in accordance with the Instructions, and no known safety hazards or uses in accordance with the Instructions, and there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

*RF warning for Mobile device:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Malfunction	Possible causes	Solutions
No Display	Whether the power adapter is plugged in properly Damaged power adapter	Self-inspection Replace power supply
Low Information Volume	Dead battery (battery version only)	Replace battery
Oil Leakage	Clogged atomizer or damaged air pump Is assembly on bottle not rotated in place or machine tilted	Replace parts or repair Self-inspection

1. If you have a non-human fault or can't work normally when using this product, please contact the sales point of this product to replace the qualified products. Because of different fault situations, sometimes it is not a product quality problem. Please read this manual carefully before returning this product to the point of sale.

2. We hereby declare that this product has passed the inspection and attach the product manual. If you operate this product normally according to this manual and the product itself fails, this product enjoys a one-year free

- ③ If this product breaks down during the quality guarantee period, please bring the product manual and accessories to the sales department for maintenance. However, if any of the following situations occur, even during the warranty period, we can't repair it for free:
- ① It has been more than one year since the product was purchased when the product failed and requested maintenance.
 - ② Product failure caused by war, earthquake, fire, typhoon, flood and other irresistible natural disasters.
 - ③ The product is scratched, stained and damaged in appearance during use.
 - ④ Failure due to unauthorized disassembly, assembly and maintenance.
 - ⑤ Failure caused by falling, improper operation or illegal use.
 - ⑥ Failure caused by using the product as other products.