


Uzko



DY21

Open Ear clip Wireless Headphones

User Manual


Please read the instructions for use

Function Introduction



- 1 Indicator light
- 2 Charging contact
- 4 Physical key
- 3 Touch key
- 5 Charging port

Headphones Connection Guide



Steps to connect headphones to your device:

1. Open the charging case or press and hold the physical button on the earbuds for 3 seconds while they are powered off to turn them on.
2. Enable pairing on your device and select the earbud model displayed on the screen.

Headphone Function Control

Headset Physical Button Functions		
	Power On	Open the charging case or press the physical button for three seconds to turn on.
	Power Off	Place the earbuds in the charging case and close the lid.
	Spatial Audio	Double-click the L ear physical button to activate / Double-click again to exit.
	Game Mode/ Music Mode	Double-click the R ear physical button to switch between Game / Music mode.
	Voice Assistant	Press any three times on the L/R physical buttons to activate; press once to exit.
	Headset Reset (Initialize)	Press and hold the physical button for 5 seconds to reset the headphones.


Headphone Function Control

Headphone Touch Button Function	
 Play/Pause	Single-tap either earbud's touch control
 Answer/End Call	Single-tap either earbud's touch control
 Reject Call	Double-tap either earbud's touch control
 Volume Control	Press and hold the L/R earbud touch control: Volume Down / Volume Up
 Skip Track	Double-tap the L/R earbud touch control: Previous track / Next track
 CN-US Voice Switch	When no device is connected, double-tap either earbud's touch control button

One-to-two mode:


1. After connecting to the first device, turn off the headphones' pairing function. The headphones will disconnect and enter pairing mode.
2. On the second device, enable pairing and connect to the headphones, Once connected.
3. Re-enable pairing on the first device, select the headphone model, and reconnect.

Product Parameters



Headphone Specifications

- Chip Version : V 6.0
- Effective Range : 10m (obstacle-free)
- Usage Duration : About 10 hours
- Charging Duration : About 1.5 hours



Charging Dock Specifications

- Charging port : USB Type-C
- Number of discharges : 3 times
- Battery capacity : 400 mAh
- Charging duration : About 2 hours

Common Problems

Will my headset work with laptops, desktop computers and PDAs?	Your headset can be used with devices that support the Bluetooth version and features of that headset.
Why do I hear static or interference during a call?	Wireless telephones and wireless network devices such as these devices may cause interference, which typically sounds like static noise. Please do not place headphones near other devices that use or emit radio waves.
Do headphones interfere with electronic devices, radios or computers in the car?	Headphones produce far less interference than regular cell phones, so don't worry about the
Can other Bluetooth cell hone users hear my calls?	When the headset is docked to a Bluetooth cell phone, an encrypted link is established between the two devices, making it difficult for devices other than the headset to listen in.
Why do I hear an echo during a call?	Adjust the headphone volume, or move to another area and try again.
How do I clean my headphones?	Wipe with a dry, soft cloth.
Headphones won't fully charge?	The headset and travel charger may not be connected, reconnect and charge the headset.
I am unable to use some of the features described in.	Available functions may vary depending on the connected device.

Please Notes

Storage and maintenance

This product should be stored in a cool and dry place. The operating temperature is 0-38°C. Please use a soft dry cloth for daily cleaning. Never disassemble your headphones at any time, as doing so may damage the headphones or cause the battery to self-ignite. Keep the product away from heat sources or other corrosive liquids, and avoid using or placing it in any high-temperature places. If any part of this product is damaged or hot, please stop using this product immediately. Avoid exposing the headphones to rain or immersion in liquids. If not used for a long time, please charge them again before use.

Instructions for wearing and use

A small number of people will have special reactions to specific materials. When in certain environments, long-term contact with potentially irritating substances to the skin such as soap, sweat, and UV protection products may cause skin allergic reactions. To reduce the risk of skin irritation, please do not wear the product on parts of the body with skin injuries. If your skin becomes red, swollen, itchy, or has any other irritation, please stop wearing it immediately and consult a doctor!

Electromagnetic Interference Tips

Do not use this product in places where wireless devices are prohibited or inappropriate (for example, airports in some areas, medical facilities, etc.). Otherwise, it may interfere with other electronic devices or cause other dangers. Some electronic devices may malfunction due to radio interference from this product (for example, some automotive electronic devices). Please contact the manufacturer of the electronic device for details.

Hearing Damage

Listening to music at too high a volume may damage your hearing and the sound may be distorted.

Charging Safety Tips

It is recommended that the power provided by the charger must be between the minimum [2.5] watts and the maximum [5.5] watts required by the radio device to achieve maximum charging speed.



FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.