

PORSCHE SMARTPHONE CHARGING PAD

MAX. 15W

.....



INSTRUCTION MANUAL

Model: WWCA20251002

SAFETY PRECAUTIONS (EN)

To reduce the risk of burns, fire, electric shock or injury to people, read all instructions before use to ensure safe and proper use.

1. Before using the wireless charging pad, make sure it is compatible with your device.
2. To protect against fire, electrical shock and injury to people, do not immerse the unit in water or spray it with liquids. Doing so may cause electric shock.
3. This appliance is intended for indoor use only and not for outdoor use or use in vehicles.
4. Place the device on dry surfaces only. Keep it away from humidity and dust. Do not use or store the unit where it can fall or be pulled into a tub or sink.
5. Do not touch the unit with wet hands.
6. Do not store the unit in very hot or very cold areas. It is recommended to use it at temperatures from 5 °C to 50 °C.
7. Do not leave the unit in a location near heat sources, or in a place subject to direct sunlight, sand, excessive dust, or mechanical shock.
8. This appliance is not a toy. Do not allow children or animals to chew or suck the device. Children should be supervised to ensure that they do not play with the appliance.
9. Do not place metal objects or aluminum stickers, such as coins or paper clips on the charging surface. They can lead to overheating, product damage, or fire. Magnetic stripe cards, including credit cards, phone cards, passbooks, and boarding passes, may be damaged by magnetic fields.
10. Do not place heavy objects on the unit. Do not drop or cause an impact to the charger. Do not drop or knock it off an elevated surface.
11. Prevent the charger port from contact with conductive materials, such as liquids, dust, metal powders, and pencil leads.
12. Do not leave the unit covered with fabric when charging.
13. Never operate the unit if it is not working normally or has been damaged in any way. Do not attempt to repair, disassemble or modify the appliance. There are no user-serviceable parts inside. All service can only be performed by qualified service personnel.

WARNING

We shall not be liable for any damage caused by force majeure or customer's intentional negligence, misuse or use under other abnormal conditions.

SAVE THESE INSTRUCTIONS

OVERVIEW OF WIRELESS CHARGING PAD



OPERATION OF WIRELESS CHARGING PAD

1. Connect the Wireless Charging Pad to a power supply through USB-A to C cable (supplied) or USB-C to USB-C cable (not included). If the wireless charging pad is connected correctly, the indicator light will illuminate white and it is ready for use.

Note: Charging speed depends on power supply used (adaptor not included). DC 5V 1A adaptor is not recommended. This charger requires a fast charging adaptor that supports QC 3.0 or PD 3.0, with a minimum output power of 18W. Please use the appropriate adaptor for correct charging and maximum charging efficiency.

2. Place Wireless Charging Pad on a safe and even surface.

3. Center your Qi-enabled device/smartphone onto the charging surface by simply laying it down (straight or crosswise depending on specific design of your device). If the device is placed correctly, charging will start automatically. The indicator light indicates whether your device is charging or not.

Note: Use your phone directly without protective case or with a phone case thickness is less than 2 mm and remove all metal cases and metal or magnetic objects from the back of your phone prior to wireless charging. Otherwise, it may prohibit the device from charging and/or cause overheating or other anomalies during charging.

4. The indicator lights alert you to the wireless charger's status.
 - When the charging pad is connected to power: the LED light remains solid white.
 - When a phone is charging on the pad: the LED light remains solid blue.
 - The indicator light will blink white and blue alternately when it isn't charging properly due to foreign object or error warning occurs.
5. Remove the device after fully charged to protect the device and wireless charger.
6. When the appliance is not used for prolonged periods of time, disconnect it from the power supply.

Tips for use:

- The wireless charger is compatible with most Qi-enabled devices. Always align your phone centrally for charging. You may need to position the phone
- Keep charging surface dry and away from moisture and corrosive materials.
- If your battery is completely discharged, it may take a few minutes before it starts charging. This is entirely normal. You can see that the battery has begun charging when the battery symbol appears on your phone.
- Charging time may vary based on the device's battery capacity, charge level, the age of the battery and the temperature in the surrounding area.
- If an error is detected, check and ensure your device supports wireless charging, disconnect the charging pad and try it again.

Warnings:

- Please do not place any metal or magnetic object between your phone and charging pad, otherwise, the charger will not work.

- Please remove all metal cases and metal or magnetic objects from the back of your phone prior to wireless charging, as these may overheat and damage your device.

CARE AND CLEANING

- Always switch off the appliance and unplug from the power supply before cleaning.
- Do not clean the unit with strong chemical agents or abrasive cleaners. Do not use a coarse cloth, abrasive materials, or chemical cleaners such as alcohol, benzene, etc.
- Do not clean charging area with harsh chemicals, soaps or detergents. Just wipe it with a soft, water-dampened cloth.
- **CAUTION:** Never allow any water or other liquids to get inside the unit while cleaning. If the product is no longer suitable for use, dispose of it in an environmentally friendly manner in accordance with your local council.

LEGAL INFORMATION

This device was tested for operations. To comply with RF exposure requirements, a minimum separation distance of 20cm must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.

This device in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. All essential radio test suites have been carried out. This restriction will be applied to all Member States of European Union. The device complies with RF specifications when the device used at least at 20 cm from your body.

Declaration of Conformity

Hereby, Porsche Dr. Ing. h. c. F. Porsche AG declares that the product type WWCA20251002 is in compliance with Directives 2014/53/EU & 2011/65/EU.

This device was tested for operations. To comply with RF exposure requirements, a minimum separation distance of 20cm must be maintained between the user's body and the wireless charger, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these

requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.

This device in compliance with the essential requirements and other relevant provisions of UK Radio Equipment Regulations (SI 2017/1206); UK Electrical Equipment (Safety) Regulations (SI 2016/1101); and UK Electromagnetic Compatibility Regulations (SI 2016/1091). All essential radio test suites have been carried out. The device complies with RF specifications when the device used at least at 20 cm from your body.

UK Declaration of Conformity

Hereby, Porsche Dr. Ing. h. c. F. Porsche AG declares that the product type WWCA20251002 is in compliance with following Directives: Radio Equipment Regulations 2017, Electrical Equipment (Safety) Regulations 2016 and The Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: (1) Reorient or relocate the receiving antenna. (2) Increase the separation between the equipment and receiver. (3) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. (4) Consult the dealer or an experienced radio / TV technician for help.

Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated at a minimum distance of 20 cm between the radiator & your body.

Product Name: Porsche Wireless Charging Pad
Model: WWCA20251002

The following importer is the responsible party:
Company Name: Porsche Cars North America, Inc.
Address: One Porsche Drive, Atlanta, GA 30354 USA
Telephone: +1 800 767 7243

SPECIFICATIONS

Input 	Min 5V-3A / 9V-2A
Output 	Max 15W / 10W / 7.5W / 5W
Size 	115 x 80 x 12 mm
Weight 	50 g
RF output max	≤ 40.54 dBuA/m
RF frequency	115 kHz - 205 kHz

Porsche Dr. Ing. h. c. F. Porsche AG
Porscheplatz 1
70435 Stuttgart, Germany
PROS.Articles@porsche.de
WEEE-Reg.-Nr. DE 60904775



Note: As result of continual improvements, appearances and specifications are subject to change without prior notice.

PORSCHE SMARTPHONE CHARGING PAD

MAX. 15W

.....



BEDIENUNGSANLEITUNG

Model: WWCA20251002

SICHERHEITSHINWEISE (DE)

Um das Risiko von Verbrennungen, Brand, elektrischem Schlag oder Verletzungen von Personen zu verringern, lesen Sie vor der Verwendung alle Anweisungen, um eine sichere und ordnungsgemäße Nutzung zu gewährleisten.

1. Vergewissern Sie sich vor der Verwendung des kabellosen Ladepads, dass es mit Ihrem Gerät kompatibel ist.
2. Zum Schutz vor Brand, elektrischem Schlag und Verletzungen tauchen Sie das Gerät nicht in Wasser und besprühen Sie es nicht mit Flüssigkeiten. Dies kann einen elektrischen Schlag verursachen.
3. Dieses Gerät ist ausschließlich für den Innenbereich bestimmt und nicht für den Außenbereich und auch nicht für die Verwendung in Fahrzeugen geeignet.
4. Stellen Sie das Gerät nur auf trockene Oberflächen. Halten Sie es von Feuchtigkeit und Staub fern. Verwenden oder lagern Sie das Gerät nicht an Orten, an denen es in eine Badewanne oder ein Waschbecken fallen oder hineingezogen werden könnte.
5. Berühren Sie das Gerät nicht mit nassen Händen.
6. Lagern Sie das Gerät nicht in sehr heißen oder sehr kalten Umgebungen. Es wird empfohlen, das Gerät bei Temperaturen von 5 °C bis 50 °C zu verwenden.
7. Lassen Sie das Gerät nicht in der Nähe von Wärmequellen oder an Orten mit direkter Sonneneinstrahlung, Sand, übermäßigem Staub oder starken mechanischen Erschütterungen.
8. Dieses Gerät ist kein Spielzeug. Erlauben Sie Kindern oder Tieren nicht, auf dem Gerät zu kauen oder es zu lutschen. Kinder sollten beaufsichtigt werden, um sicherzustellen, dass sie nicht mit dem Gerät spielen.
9. Legen Sie keine Metallgegenstände oder Aluminiumaufkleber, wie z. B. Münzen oder Büroklammern, auf die Ladefläche. Diese können zu Überhitzung, Produktschäden oder Brand führen. Magnetstreifenkarten, einschließlich Kreditkarten, Telefonkarten, Sparbücher und Bordkarten, können durch Magnetfelder beschädigt werden.
10. Stellen Sie keine schweren Gegenstände auf das Gerät. Lassen Sie das Ladegerät nicht fallen und setzen Sie es keinen Stößen aus. Lassen Sie es nicht von erhöhten Flächen herunterfallen oder stoßen Sie es nicht herunter.
11. Verhindern Sie den Kontakt des Ladeanschlusses mit leitfähigen Materialien wie Flüssigkeiten, Staub, Metallpulver und Bleistiftminen.
12. Lassen Sie das Gerät während des Ladevorgangs nicht mit Stoffen bedeckt.

13. Betreiben Sie das Gerät niemals, wenn es nicht ordnungsgemäß funktioniert oder in irgendeiner Weise beschädigt wurde. Versuchen Sie nicht, das Gerät zu reparieren, zu zerlegen oder zu verändern. Es befinden sich keine vom Benutzer wartbaren Teile im Inneren. Alle Wartungsarbeiten dürfen nur von qualifiziertem Fachpersonal durchgeführt werden.

WARNUNG

Wir übernehmen keine Haftung für Schäden, die durch höhere Gewalt oder durch vorsätzliches oder fahrlässiges Fehlverhalten des Kunden, durch Missbrauch oder durch Nutzung unter anderen abnormalen Bedingungen verursacht werden.

Bewahren Sie diese Anweisungen auf

Übersicht des kabellosen Ladepads

Kabellose
Ladefläche



USB-C Input Anschluss

Kontrollleuchte

USB-A zu USB-C Kabel

USB Kabel

BETRIEB DES DRAHTLOSEN LADEPADS

1. Verbinden Sie das kabellose Ladepad über ein USB-A zu USB-C Kabel (im Lieferumfang enthalten) oder ein USB-C zu USB-C Kabel (nicht im Lieferumfang enthalten) mit einer Stromquelle. Wenn das kabellose Ladepad korrekt angeschlossen ist, leuchtet die Anzeigeleuchte weiß und es ist betriebsbereit.

Hinweis: Die Ladegeschwindigkeit hängt von der verwendeten Stromversorgung ab (Adapter nicht im Lieferumfang enthalten). Ein DC 5V 1A-Adapter wird nicht empfohlen. Dieses Ladegerät erfordert einen Schnellladeadapter, der QC 3.0 oder PD 3.0 unterstützt und eine Mindestausgangsleistung von 18W hat. Bitte verwenden Sie den entsprechenden Adapter, um korrektes Laden zu ermöglichen und um maximale Ladeeffizienz zu erzielen.

2. Legen Sie das kabellose Ladepad auf eine sichere und ebene Fläche.
3. Zentrieren Sie Ihr Qi-fähiges Gerät/Smartphone einfach auf der Ladefläche, indem Sie es darauflegen (hochkant oder quer je nach Modell und Bauart des Geräts). Wenn das Gerät korrekt positioniert ist, beginnt der Ladevorgang automatisch. Die Kontrollleuchte zeigt an, ob Ihr Gerät geladen wird oder nicht.

Hinweis: Verwenden Sie Ihr Telefon direkt ohne Schutzhülle oder mit einer Schutzhülle, die weniger als 2 mm dick ist, und entfernen Sie alle Metallhüllen und metallischen oder magnetischen Gegenstände von der Rückseite Ihres Telefons, bevor Sie es kabellos aufladen. Andernfalls kann dies das Aufladen des Geräts verhindern und/oder zu Überhitzung oder anderen Anomalien während des Ladevorgangs führen.

4. Die Anzeigeleuchten informieren Sie über den Status des kabellosen Ladegeräts.
 - Wenn das Ladepad an die Stromversorgung angeschlossen ist: Die LED-Leuchte leuchtet dauerhaft weiß.
 - Wenn ein Telefon auf dem Pad aufgeladen wird: Die LED-Leuchte leuchtet dauerhaft blau.
 - Die Anzeigeleuchte blinkt abwechselnd weiß und blau, wenn der Ladevorgang aufgrund eines Fremdkörpers oder einer Fehlerwarnung nicht ordnungsgemäß funktioniert.

5. Entfernen Sie das Gerät nach vollständiger Aufladung, um das Gerät und das kabellose Ladegerät zu schützen.
6. Wenn das Gerät über einen längeren Zeitraum nicht verwendet wird, trennen Sie es von der Stromversorgung.

Tipps zur Verwendung:

- Das kabellose Ladegerät ist mit den meisten Qi-fähigen Geräten kompatibel. Richten Sie Ihr Telefon zum Laden immer mittig aus.
- Halten Sie die Ladefläche trocken und fern von Feuchtigkeit und korrosiven Materialien
- Wenn Ihr Akku vollständig entladen ist, kann es einige Minuten dauern, bis der Ladevorgang beginnt. Dies ist völlig normal. Sie können sehen, dass der Akku mit dem Laden begonnen hat, wenn das Akkusymbol auf Ihrem Telefon angezeigt wird.
- Die Ladezeit kann je nach Akkukapazität des Geräts, Ladezustand, Alter des Akkus und Umgebungstemperatur variieren.
- Wenn ein Fehler erkannt wird, überprüfen Sie, ob Ihr Gerät kabelloses Laden unterstützt, trennen Sie das Ladepad und versuchen Sie es erneut.

Warnungen:

- Bitte legen Sie keine metallischen oder magnetischen Gegenstände zwischen Ihr Telefon und das Ladepad, da das Ladegerät sonst nicht funktioniert.
- Bitte entfernen Sie vor dem kabellosen Laden alle Metallhüllen und metallischen oder magnetischen Gegenstände von der Rückseite Ihres Telefons, da diese überhitzen und Ihr Gerät beschädigen können.

PFLEGE UND REINIGUNG

- Schalten Sie das Gerät vor der Reinigung immer aus und ziehen Sie den Netzstecker.
- Reinigen Sie das Gerät nicht mit starken chemischen Mitteln oder Scheuermitteln. Verwenden Sie keine groben Tücher, scheuernden Materialien oder chemischen Reinigungsmittel wie Alkohol, Benzol usw.
- Reinigen Sie den Ladebereich nicht mit aggressiven Chemikalien, Seifen oder Reinigungsmitteln. Wischen Sie ihn einfach mit einem weichen, mit Wasser angefeuchteten Tuch ab.

- **VORSICHT:** Achten Sie darauf, dass während der Reinigung kein Wasser oder andere Flüssigkeiten in das Gerät gelangen. Wenn das Produkt nicht mehr gebrauchsfähig ist, entsorgen Sie es auf umweltfreundliche Weise gemäß den Vorschriften Ihrer Gemeinde.

RECHTLICHE HINWEISE

Dieses Gerät wurde auf seine Funktionsfähigkeit geprüft. Um die Anforderungen hinsichtlich der HF-Exposition zu erfüllen, muss ein Mindestabstand von 20 cm zwischen dem Körper des Benutzers und dem Mobilteil, einschließlich der Antenne, eingehalten werden. Von Drittanbietern stammende Gürtelclips, Holster und ähnliche Zubehörteile, die mit diesem Gerät verwendet werden, dürfen keine metallischen Bestandteile enthalten. Am Körper getragene Zubehörteile, die diese Anforderungen nicht erfüllen, entsprechen möglicherweise nicht den Anforderungen hinsichtlich der HF-Exposition und sollten vermieden werden. Verwenden Sie nur die mitgelieferte oder eine zugelassene Antenne.

Dieses Gerät entspricht den grundlegenden Anforderungen und anderen relevanten Bestimmungen der Richtlinie 2014/53/EU. Alle grundlegenden Funkprüfungen wurden durchgeführt. Diese Einschränkung gilt für alle Mitgliedstaaten der Europäischen Union.

Das Gerät entspricht den HF-Spezifikationen, wenn es in einem Abstand von mindestens 20 cm zum Körper verwendet wird.

Konformitätserklärung

Hiermit erklärt die Porsche Dr. Ing. h. c. F. Porsche AG, dass das Produkt WWCA20251002 den Richtlinien 2014/53/EU und 2011/65/EU entspricht. Dieses Gerät wurde auf seine Funktionsfähigkeit geprüft. Um die Anforderungen hinsichtlich der HF-Exposition zu erfüllen, muss ein Mindestabstand von 20 cm zwischen dem Körper des Benutzers und dem kabellosen Ladegerät, einschließlich der Antenne, eingehalten werden. Von Drittanbietern stammende Gürtelclips, Holster und ähnliche Zubehörteile, die mit diesem Gerät verwendet werden, dürfen keine metallischen Komponenten enthalten. Am Körper getragene Zubehörteile, die diese Anforderungen nicht erfüllen, entsprechen möglicherweise nicht den Anforderungen hinsichtlich der HF-Exposition und sollten vermieden werden. Verwenden Sie nur die mitgelieferte oder eine zugelassene Antenne. Dieses Gerät entspricht den grundlegenden Anforderungen und anderen relevanten Bestimmungen der britischen Funkgeräteverordnung (SI 2017/1206), der britischen Verordnung über elektrische Geräte (Sicherheit) (SI 2016/1101) und der britischen Verordnung über elektromagnetische Verträglichkeit (SI 2016/1091). Alle wesentlichen Funkprüfungen wurden durchgeführt.

Das Gerät entspricht den HF-Spezifikationen, wenn es in einem Abstand von mindestens 20 cm zu Ihrem Körper verwendet wird.

SPEZIFIKATIONEN

Input 	Min 5V-3A / 9V-2A
Output 	Max 15W / 10W / 7.5W / 5W
Size 	115 x 80 x 12 mm
Weight 	50 g
RF output max	≤ 40,54 dBuA/m
RF frequency	115 kHz - 205 kHz

Porsche Dr. Ing. h. c. F. Porsche AG
Porscheplatz 1
70435 Stuttgart, Germany
PROS.Articles@porsche.de
WEEE-Reg.-Nr. DE 60904775



Hinweis: Aufgrund kontinuierlicher Verbesserungen können sich das Aussehen und die technischen Daten ohne vorherige Ankündigung ändern.