



Panel Button Operation



Power On: Short-press the power button for 1 second to activate the lighting



Power Off: Short-press the power button for 1 second to switch off

Mode Switch: Short-press the mode button for 1 second to switch mode



Red



Green



Blue



White



Orange



Lime



Purple



Yellow



Cyan



Pink



Flash



Strobe




Fade



Smooth

Remote Control Function Introduction



- 01 Increase Brightness
- 02 Decrease Brightness
- 03 Power OFF
- 04 Power ON
- 05 Red Light
- 06 Green Light
- 07 Blue Light
- 08 White Light
- 09 Orange Light
- 10 Lime Light
- 11 Purple Light
- 12 Flash Mode
- 13 Yellow Light
- 14 Cyan Light
- 15 Pink Light
- 16 Strobe Mode
- 17 Brightness at 20%
- 18 Brightness at 50%
- 19 Brightness at 100%
- 20 Fade Mode
- 21 1 hour timer
- 22 2 hour timer
- 23 3 hour timer
- 24 Smooth Mode

Note:

- ① For the first-time use, please remove the remote control's battery insulating strip.
- ② Before using the remote control for the first time, you need to press and hold the button of the solar panel button for 1 second and light up the light before you can use the remote control.
- ③ The maximum remote control range is 98 feet.

FCC statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC warning:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.