




Function Description

Please ensure the travel lock is turned off before first use.

1. Long press the Power Button for 2 seconds to turn on, entering standby mode.
2. In standby mode, single click Vibration Button 1 to start the first frequency insertion vibration mode; single click again to switch to the next frequency (10 frequencies in total, cycling sequentially); long press to turn off the insertion vibration function.
3. In standby mode, single click the Power Button to start the first frequency stroking vibration mode; single click again to switch to the next frequency (10 frequencies in total, cycling sequentially).
4. In standby mode, single click Vibration Button 2 to start the first frequency grinding vibration mode; single click again to switch to the next frequency (10 frequencies in total, cycling sequentially); long press to turn off the grinding vibration function.
5. Long press the Power Button for 2 seconds to turn off.
6. Click the Power Button within a short time after turning off to manually reset.
7. Long press Vibration Button 1 and the Power Button simultaneously for 3 seconds to open/close the travel lock. When opening, the light flashes once and the motor vibrates once; when closing, the light flashes twice and the motor vibrates twice. After the travel lock is opened, any operation is invalid, and the light flashes twice with each operation. The travel lock will automatically turn off during charging.

Remote Control

1. Long press the Power Button for 2 seconds to turn on.
2. In product standby mode, single click Vibration Button 1 to start the first frequency insertion vibration mode; single click again to switch to the next frequency (10 frequencies in total, cycling sequentially); long press to turn off the insertion vibration function.
3. In product standby mode, single click the Power Button to start the first frequency stroking vibration mode; single click again to switch to the next frequency (10 frequencies in total, cycling sequentially).
4. In product standby mode, single click Vibration Button 2 to start the first frequency grinding

vibration mode; single click again to switch to the next frequency (10 frequencies in total, cycling sequentially); long press to turn off the grinding vibration function.

5. Long press the Power Button to turn off all functions and power off the remote control.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.