


Smart WiFi Battery Camera

—— User Manual ——

2.4 Ghz



Keep an Eye on What Matters

Contents


1. Packing List	01
2. Product Appearance	01
3. Quick Start	03
4. Light Indicators	07
5. Install the Camera	08
6. Camera's Specification	12
7. Firmware Upgrade	12
8. FCC Statement	13
9. Cautions	15
10. FAQ	16


Packing List

Camera	× ①	Type-C Charging Cable	× ①
Bracket for Camera	× ①	User Manual	× ①
Screws Bag	× ①	Warning Sticker	× ①

Product Appearance

Camera





Quick Start

The wireless smart battery camera operates on the built-in internal batteries and can also be powered using AC-Power supply.

1. Download and install the App

Search the app store for 'Yoosee' app or use your browser to scan the QR code below to download, register and use. (by email, agree to the user agreement and obtain a verification code)

Scan the QR code to go to the link:




CAUTION

DO NOT use 3rd party QR code scanning tool or app to avoid scam or malware! Use QR code scanning app provided by your mobile phone system, e.g. the system camera app.

2.Add Camera


After pressing the camera power button for 3 seconds, the camera will turn on. The camera will emit the scanning sound "Ding Dong Ding Dong" after it is turned on for seconds (if you do not hear it, please Press the "P Hole" for 6 seconds to reset).





Support 2.4Ghz WiFi only

(1)Add device by Bluetooth


- ①Click on the "+" button
- ②Turn on "Location" and "Bluetooth" permission
- ③After turning on Bluetooth, the device ID will be automatically recognized
- ④Click on the device ID to attempt to connect to the device
- ⑤Enter the Wifi name and password
- ⑥Waiting for connecting
- ⑦Set device name, connection successful




Step 1





Step 2




Step 3




Step 4



Step 5



Step 6



Step 7

Light Indicators



Flashing red light

The device is ready to connect



Light up for 10 seconds and then turn off

The device is connected and finishing setup



Solid orange light


The device is charging

Install the Camera

The camera can be placed on surfaces such as a shelf, ledge, or table. You can also mount the camera to the wall with the included mounting hardware.

(1) Select a good spot for your camera

Select a good spot for your camera, please install the camera in a position where its view is not blocked and ensure that it is within the coverage of the Wi-Fi network. The PIR infrared sensor is more sensitive to movements across the camera's field of view than movements toward or away from the camera.



(2) Install the bracket


1) Screw fixing:

Use the drilling tool to punch holes on the wall according to the hole distance of the base. It is recommended to mark the holes on the wall with a pencil before drilling. Screw the expansion nut into the holes on the wall, and then connect the bracket to the expansion nut with screws to complete the fixing.



2) Fixing the camera


Align the bracket screw with the screw hole on the back of the camera, and then rotate it to the tightened state.



3) Adjust the angle

Adjust the camera to an appropriate angle, the best angle is about 15 degrees downward, and then tighten the base by rotating it in clockwise direction to fix the angle.

About 15 ° downward



Sharing methods


You can provide access to the camera live stream as well as previously recorded footage to family and friends using the camera share function. (Only the administrator account that initially set up the camera can invite other users to share.)

①Select the menu bar in the upper right corner

②Select the "share" button

③Click share


(Please note: Sharing only works for accounts registered in the same country)



Step 1



Step 2



Step 3

Camera's Specification

Item	Specification
Camera lens	Field of view: 117°
Image resolution	2560*1440
Video bit rate	Adaptive
Storage media	Micro SD card (Up to 256GB)
Battery capacity	5000mAh
Adapter requirement	5V/1.5A
Waterproof rating	IP65

Firmware Upgrade

When you connect your camera through the App, it will prompt you if the latest firmware is available. You can also manually check the firmware upgrade in the settings of the App.

- ❗ Please make sure that your camera is fully charged or connected to the power adapter before upgrading the firmware, please do not cut off the power supply during the upgrading.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party. Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices). This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

The equipment complies with FCC Radiation exposure limits set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

Cautions

- Please disconnect the power supply and insert the card, otherwise the card may be damaged.
- The camera supports up to 256G SD card with FAT32/exFAT.
- The device uses loop recording technology, when the SD card is full, the camera will automatically overwrite the earliest video.
- Please do not install the product in high temperature, high humidity or a lot of dust, smoke and other harsh environments, or may cause equipment damage.
- Yoosee App and device firmware will be updated from time to time, if you are prompted to upgrade, please upgrade online.
- please do not cutoff the power supply during the upgrading.

FAQ

Q: Camera permission management: How do I invite family and friends to use my camera together?

A: Open the app and select your camera on the homepage. Tap the "Share" button on the homepage or the "Share" option in the camera settings to access the sharing page. Then, click "Invite" to generate a QR code. Your friends can now scan the QR code from your phone to gain limited access permissions.

Alternatively: Open the app, select your camera on the homepage. Tap the "..." menu in the top-right corner or the "Device Sharing" option in the camera settings to enter the sharing interface. Then, select "Account Sharing" or "QR Code Sharing." You can either enter the other person's account or have them scan your QR code to obtain access permissions.

Q: Why doesn't the Wi-Fi name appear when I try to connect to Wi-Fi?

A: For Apple devices running iOS 13 or later, you need to enable "Location Permission" for the app in the system settings and set it to "Allow While Using the App."

Q: Does the camera show red lights when night vision is activated?

A: The built-in infrared LEDs cause the camera to emit only a faint red glow when night vision is activated. However, the image quality remains clear even in complete darkness.

Q: What are the Wi-Fi requirements?

A: Please use a 2.4GHz wireless network. The device supports WPA3 and other lower-security authentication methods.

Q: How far should the camera be placed from the router?

A: Tests show that the Wi-Fi connection distance can typically reach up to 110 meters in open areas. However, the actual range depends on the Wi-Fi signal strength and environmental factors (thick walls, electromagnetic devices, and large metal objects can interfere with the Wi-Fi signal). If the camera connection is weak or unstable, try placing the camera closer to the router.

Q: How can I quickly filter videos by category?

A: Tap the labels below the live stream interface to quickly filter events by category. To save a video, tap "Download" below the event, and it will be saved to your photo album.

Q: What is the maximum recording duration?

A: If you set the mode to "High Performance," the camera will record continuously, but you will need to keep the device charged. In "Energy Saving" mode, each event is recorded for up to 1 minute. If the battery is low or "Sleep Mode" is enabled, events will not be recorded, and you can only watch the live stream via the app.

Q: What should I do if the device malfunctions?

A: Press and hold the power button for more than 3 seconds until you hear a shutdown sound, then restart the device. If it still doesn't connect after restarting, press and hold the "P" or "Reset" button until you hear a beep, then reconfigure the Wi-Fi connection. If the issue persists, go to "My" → "Help & Feedback" in the app to contact us.

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.