

THUMB CAMERA

Operating Manual



Before using this product, please read the user manual carefully.

The manual is for reference only.

The actual operation should be based on the product itself.

1. Product Appearance

English



1. Power button/recording/confirmation 2. Microphone
3. Camera 4. TF card slot
5. Charging port

2. Button and Interface Functions

1. Power button/recording/taking photos

Power button: 1: Long press to perform power on/off
. 2: Short press once to take a photo. 3: Press and hold twice in a row to start/end recording.

Reset button: Press to shut down in case of abnormal crashes or other situations

Note: It is prohibited to insert or remove cards during video/photo/recording/playback mode operation!

TYPE-C interface: 1) Interface type: Type-C; 2) Used for connecting external power sources to charge batteries or provide working power; 3) Used to connect to PC for 'memory/PC camera' operation.

TYPE-C interface: 1. Interface type: C type. 2. Used to connect an external power source to charge the battery or provide working power; 3. Used to connect to the PC end for 'memory/PC camera' operation.

USB mode

The device is connected to the computer using USB data, and the machine comes with a memory card to boot the device. After booting up, the device enters the memory: in this mode, it can access and view videos, photos, etc. PC camera mode

The machine does not have a memory card, and after booting up the device, it enters the PC camera: this mode can be used for the computer camera.

Indicator light function

1: Red light charging indicator light: charging continuously on, fully charged off

2: Blue light working indicator: for recording and taking photos, the blue light flashes and remains on for pause.

3: Green WIFI indicator light: The unconnected app is constantly on, while the connected app is flashing.

4: Yellow battery indicator light: Low battery, flashing slowly, about to shut down, flashing rapidly.

WiFi mode: Scan the QR code below to download the app and connect to the machine via WiFi

WiFi account: F2 *****

WiFi password: 12345678



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction