


Children's Video Intercom User Manual



1. Appearance and Function Description




- | | |
|--|----------------|
| ① Screen Switching/Voice Change Button | ③ Camera |
| ② Antenna | ⑤ Volume Up |
| ④ Display Screen | ⑦ Power Switch |
| ⑥ Volume Down | ⑨ Talk Button |
| ⑧ Microphone Pickup Hole | ⑪ Lanyard Hole |
| ⑩ USB Charging Port | |

2. Power On/Off Function


(1)The power switch is in the "OFF" position when the product is shipped from the factory.

(2)Slide the power switch to the "ON" position, and the product will power on automatically. The display area A shows the image from the built-in camera. When the other unit is powered on, the image from the other unit will appear in display area B.

(3)For first-time use, please fully charge the product.



Power On State



Power Off State

3. Charging Indicator

(1)Use the charging cable provided with the device, connect it to a charger, and insert it into the USB charging port to begin charging.

(2)Charger Specifications: 5V/1A.

4. Function Description

(1)Slide the power switch to the "ON" position, and the device will automatically power on and display the image from your own camera. When the other intercom unit is powered on, both units will automatically connect and display the image from the other unit.

(2) Press and hold the "🗨️" key to initiate voice communication. The voice transmission is one-way, meaning the other party can only speak after you release the talk button. Once you release the button, the other party can then press and hold their talk button to send their voice.

(3) Image Display Switch Key "M": The device has the following four screen display modes.




(4) Volume Adjustment

Press the "+" button briefly to increase the volume.

Press the "-" button briefly to decrease the volume.

(5)Voice Changing Function

Press and hold the "M" button for 2 seconds, then release it to switch the voice mode. After powering off, the voice changing mode will revert to the original voice mode.



(6)Power On/Off and Auto Power Off Function

Once powered on, the product enters working mode and will remain in this state regardless of use. When the battery is low, the device will automatically power off. If not in use, please slide the power switch to the "OFF" position.

To restart the product, simply slide the power switch to "OFF" and then back to "ON" to power it on normally.

(7)Product Pairing and Connection Method

This product uses a 2.4G Wi-Fi transmission and connection mode. Each package contains two intercom units, which are pre-paired and cannot be connected to other units. If multiple sets are purchased, only one-to-one connections between units within the same set are allowed. Multiple sets cannot be connected simultaneously.

(8)Caution

- a.This product is suitable for outdoor use.
- b.This device is not waterproof.
- c.The indoor range of the product is based on the condition that the image is displayed without lag.

5. Product Specifications

Display Screen	2.0 Inch IPS
CMOS Pixels	300k
Battery Capacity	3.7V 700mAh
Language	English
Charging Port	Type-C
Operating Temperature	0°C~60°C
Power Supply	5V/1.0A
Product Dimensions	124mm*54mm*23mm



Made in China

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.