





New 2
Mini Bluetooth Speaker

01	Product Overview
02	First-Time Use Guide
03	Detailed Operating Instructions
04	Product Specifications
05	Box Contents
06	Safety Precautions and Maintenance
07	Warranty Information



User Manual for 【New2】 Bluetooth Speaker

01 Product Overview





- | | | | |
|---|---------------------|---|--------------------------|
| 1 | Voice Reception | 4 | Type-C Charging Port |
| 2 | Rotary Button | 5 | Charging Indicator Light |
| 3 | Metal Speaker Grill | 6 | Press Button*2 |



Rotary Button: for playback control, power on/off
Press Button: for adapter removal and installation

Adapter Ring

(For Front/Rear Installation)





Slide & Connect




Install

Notice: When installing the adapter, align the back of the adapter with the back of the main unit. Slide the adapter sideways to attach it to the main unit.



Tear Down



Notice: Press the button on the back of the product with your fingertip, then slide the adapter to release it.

02 First-Time Use Guide

Charging

1. Before first use, please fully charge the speaker. Connect the speaker's charging port to a qualified USB power adapter or computer USB port using the provided charging cable.
2. When there is no power, there will be voice prompts; During the charging process, the indicator light changes from red to blue; After being fully charged, the indicator light goes out. Typical charging time is approximately 1.5 hours.


Power On & Off

1. **Power On:** Press and hold the Rotary Button for 3 seconds, and the speaker will emit a startup prompt sound.
2. **Power Off:** Press and hold the Rotary Button for 5 seconds while in the power on state, and release it after hearing the shutdown prompt sound.

03 Detailed Operating Instructions

Bluetooth Mode: Connection & Operation

1. Power on the speaker.
2. First power-on: Automatically enters Bluetooth pairing mode.
3. Enable Bluetooth on your device (phone/tablet/computer), search for "【New2】" (consistent device name) and connect.
4. Successful connection: A prompt tone sounds.
5. Playback control (Rotary Button):
 - Play/Pause: Short press once.
 - Previous Track: Quick upward full rotation.
 - Next Track: Quick downward full rotation.
 - Volume: Slow upward/downward toggle (1 level per toggle).



(1) spin button

Hands-free Call


Incoming call: Short press to answer; press again to hang up.(Mobile incoming call)

Multi-device connection

Multiple NEW 2 devices can connect to a mobile phone, tablet, or computer.

Operation Steps:

- 1. Connect your device to the first NEW 2 speaker via Bluetooth;
- 2. Turn on the second NEW 2 speaker and enter pairing mode;
- 3. Connect the device to the second NEW 2 speaker;
- 4.Press the rotary buttons on both speakers twice simultaneously to activate the multi-connection mode (a prompt will be given when it is activated).



(2) Side Function Button (corresponds to Product Overview Item 6)

04

Product Specifications


Model: New 2	Net Weight: 43.66 g
Output Power:5W	Bluetooth Chipset Version: 6.0
Protocol: A2DP, AVRCP, HFP/HSP	Charging Time: Approx 1.5 h
Input Ports: Type-C	Waterproof level: IP69
Size: 52 x 44 x 17 mm(Length×Width×Height)	Supported Sources: Bluetooth

05

Box Contents



Clip x1
(for attaching to clothes/bags)




Lanyard x1
(for hanging around neck)



Watch Strap x1
(for wearing on wrist)



Manual x1



USB-Type-C Cable x1



Adapter Ring x1



New2 Mini Bluetooth Speaker x1

Upon unboxing, please verify that the following tems are included:

Safety Precautions and Maintenance

Keep Away from Fire and Heat:

Keep the speaker away from fire, high-temperature heat sources (e.g., heaters, microwaves), and avoid prolonged direct sunlight exposure.

Proper Use: Please use the original charging cable and adapter for charging. Using incompatible accessories may cause fire, electric shock, or damage to the device.

Handle with Care: Avoid strong impacts, vibrations, or dropping the product from high places.

Cleaning and Maintenance: When cleaning, use a dry, soft cloth to wipe the surface. Do not use alcohol, thinners, or chemical cleaners.

Intended Users: This product is not a toy. Please keep it out of reach of children to prevent them from swallowing small parts.

Hearing Protection: Listen at a moderate volume (recommended $\leq 80\text{dB}$). Prolonged exposure to volumes above 90dB may damage hearing.

Warranty Information

This product is covered by a limited warranty of 12 months from the date of purchase. Please keep your purchase receipt as proof of warranty.

Warranty Exclusions:

- 1.Damage caused by liquid ingress exceeding IP69 standards (e.g., submersion in water for more than 30 minutes, exposure to corrosive liquids such as acid/alkali).
- 2.Damage due to human error (e.g., dropping, collision, improper charging, disassembly without authorization).
- 3.Damage caused by natural disasters, accidents, or other force majeure factors.

Product name :**Product model No :****Username:****Contact number:****Address:**

Service Type : ☐ Return ☐ Exchange ☐ Warranty

Reason for return:

Manufacturer/Service Information
Email: Yousonnra@outlook.com

FCC Statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.