



Ground Mount Directional Uplights, Wall Washers and Mini Flood Fixture Installation Sheet

FOR OUTDOOR USE ONLY WITH LOW VOLTAGE LANDSCAPE

POWER UNITS 12 Volt, Class 2 only.

WARNING: Luminaires must be installed in accordance with the National Electrical Code (NEC), Canadian Electrical Code (CEC) and local codes. Failure to do so will void the warranty and may result in serious injury and/or damage to the luminaire.

WARNING: Risk Of Fire/Injury To Persons. Keep away from combustibles. Turn off/unplug to change lamp. Do not touch lamp. Replace after Servicing.

WARNING: Risk of Electric Shock. Install all luminaires 10 feet (3.05 m) or more from a pool, spa, or fountain.

INSTRUCTIONS PERTAINING TO A RISK OF FIRE, OR INJURY TO PERSONS IMPORTANT SAFETY INSTRUCTIONS

The fixture cable shall

- a) be protected by routing in close proximity to the luminaire or fitting, or next to a building structure such as a house or deck;
- b) not be buried except for a maximum 6 inches (15.2 cm) in order to connect to the main low voltage cable; and
- c) have the length cut off so that it is connected to a connector within 6 inches (15.2 cm) from a building structure, a luminaire, or fitting.

Lighted lamp is HOT!

WARNING – To reduce the risk of FIRE OR INJURY TO PERSONS:

- Turn off/unplug and allow to cool before replacing lamp.
- Lamp gets HOT quickly! Contact only switch/plug when turning on.
- Do not touch hot lens, guard, or enclosure.
- Keep lamp away from materials that may burn.
- Do not touch the lamp at any time. Use a soft cloth. Oil from skin may damage lamp.
- Do not operate the luminaire fitted with a missing or damaged shield.
- Mount the luminaire in or on non-combustible mounting surfaces only.

SAVE THESE INSTRUCTIONS

Luminaire can become very hot depending on lamp wattage used. Lens and metal around lamp can become hot enough to blister hands. Particular care should be taken to locate luminaires where small children cannot reach them if high wattage lamps are used.

DO NOT USE EXTENSION CORDS ON POWER UNITS.

NOTE: Always use UL, cUL, and CSA recognized wire connectors for connections.


LUMINAIRE IS UL LISTED FOR ABOVE GROUND INSTALLATION ONLY.

LUMINAIRE MOUNTING (with ground stake):

1. To prevent electric shock, disconnect transformer from electrical supply before installation or service.
2. Run wire pigtail from luminaire through the mounting hole in top of ground stake.
3. Thread luminaire into threaded hole in ground stake.
4. Place stake in desired position and insert into ground until flange of stake is flush to grade.
5. Strip the (2) leads from the luminaire pigtail wire. Using the two (2) silicone filled safety connectors (by others), connect the leads from the luminaire to the main supply cable leads.

NOTE: Luminaires are supplied with 18-2 cable pigtail for secure connection to the main supply cable. The fixture supply cable is to be protected by routing in close proximity to the luminaire. The fixture supply should be buried to a maximum depth of 6 inches (15.2 cm) in order to connect to the main secondary supply cable. To purchase additional lengths of main low voltage cable for the connection of the equipment, please contact your local electrical supply distribution company. Only use Main Secondary Cable of the type specified in the National Electric Code or Canadian Electric Code for landscape lighting applications. If in doubt, check with your local electrical authority.

6. Aim luminaire to desired angle. Lock into place by tightening screw in adjustable knuckle.



Lumières directionnelles montées au sol, rondelles murales et fiche d'installation de mini projecteur d'inondation

**POUR UNE UTILISATION EXTÉRIEURE UNIQUEMENT AVEC UN PAYSAGE BASSE
TENSION UNITÉS D'ALIMENTATION 12 volts, classe 2 uniquement.**

AVERTISSEMENT: Les luminaires doivent être installés en conformité avec le National Electrical Code (NEC), Code canadien de l'électricité (CCE) et les codes locaux. Ne pas le faire annuler la garantie et peut entraîner des blessures graves et / ou des dommages à l'appareil.

ATTENTION: risque d'incendie / blessures. Tenir à l'écart des matières combustibles. Éteignez / débranchez de changer la lampe. Ne pas toucher la lampe. Remplacer après entretien.

Avertissement: le risque de choc électrique. Installer tous les luminaires de 10 mètres (3,05 m) ou plus à partir d'une piscine, Spa, ou de fontaine.

INSTRUCTIONS RELATIVES AU RISQUE D'INCENDIE OU DE BLESSURES CONSIGNES DE SÉCURITÉ IMPORTANTES

Le câble du luminaire doit

- a) être protégé par un acheminement à proximité immédiate du luminaire ou du luminaire, ou à côté d'une structure de bâtiment telle qu'une maison ou une terrasse;
- b) ne pas être enterré sauf sur un maximum de 6 pouces (15,2 cm) afin de se connecter au câble principal basse tension; et
- c) faire couper la longueur de manière à ce qu'il soit connecté à un connecteur à moins de 6 pouces (15,2 cm) d'une structure de bâtiment, d'un luminaire ou d'un luminaire.

La lampe allumée est CHAUD!

AVERTISSEMENT - Pour réduire le risque d'incendie ou de blessure:

- Couper / débranchez et laissez refroidir avant de remplacer la lampe.
- La lampe devient CHAUDE rapidement! Contactez commutateur / la fiche lorsque vous allumez.
- Ne touchez pas chaud lentille, garde, ou de l'enceinte.
- Gardez la lampe loin de matériaux qui pourraient brûler.
- Ne touchez pas la lampe à aucun moment. Utilisez un chiffon doux. Huile de la peau peut endommager la lampe.
- Ne pas faire fonctionner le luminaire équipé d'un écran manquant ou endommagé.
- **La surface de montage de l'installation d'un luminaire ou • non inflammable.**

CONSERVER CES INSTRUCTIONS

Luminaire peut devenir très chaud fonction de la puissance de la lampe utilisée. Lens et métal autour de la lampe peuvent devenir assez chaudes pour cloque hands. Particular devraient être prises pour localiser luminaires où les petits enfants ne peuvent pas les atteindre si les lampes de haute puissance sont utilisés.

NE PAS UTILISER LES RALLONGES SUR LE RELAIS DE PUISSANCE.

REMARQUE: Toujours utiliser UL, cUL et CSA reconnu connecteurs de fils pour les connexions.


Luminaire UL pour installation en surface l'installation seulement.

LUMINAIRE DE MONTAGE (avec piquet de terre):

- 1 Pour éviter un choc électrique, débranchez le transformateur de l'alimentation électrique avant l'installation ou service.
- 2 Exécuter fil tresse de luminaire à travers le mountinghole en haut de piquet. Luminaire
- 3.-fil dans le trou fileté en piquet de terre.
- 4 Lieu participation dans la position désirée et insérer dans le sol jusqu'à ce que la bride de jeu est au ras de qualité.
5. bande de la (2) conduit du fil luminaire en queue de cochon. En utilisant les deux connecteurs de sécurité (2) remplis de silicone (par d'autres), connecter les fils du luminaire aux principales pistes de câbles d'alimentation.

Nota: Les luminaires sont fournis avec 18-2 câble queue de cochon pour une connexion sécurisée sur le câble d'alimentation principal. Le câble d'alimentation de l'appareil doit être protégé par routage à proximité de l'appareil d'éclairage. L'alimentation du luminaire doit être enterré à une profondeur maximum de 6 pouces (15,2 cm) afin de connecter le câble d'alimentation secondaire principal. Pour acheter des longueurs supplémentaires de câble principal basse tension pour la connexion DELA équipement, s'il vous plaît contactez votre entreprise locale de distribution d'alimentation électrique. N'utilisez que principal câble secondaire du type spécifié dans le Code national de l'électricité, ou Code canadien de l'électricité pour l'éclairage du paysage. En cas de doute, vérifiez auprès de votre autorité locale électrique.

6. But luminaire à l'angle désiré. Verrouiller en place en serrant la vis à articulation réglable.



FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.