






1 Reference_Level_Hopping_NVNT_ANT1_1-DH1_Hopping




2 Band_Edge_(Hopping)_NVNT_ANT1_1-DH1_Hopping




1 Reference Level NVNT ANT1 2-DH1 2402_00




2 Bandedge NVNT ANT1 2-DH1 2402_00



1 Reference_Level_Hopping_NVNT_ANT1_2-DH1_Hopping



2 Band_Edge_(Hopping)_NVNT_ANT1_2-DH1_Hopping




1 Reference Level NVNT ANT1 2-DH1 2480 00




2 Bandedge NVNT ANT1 2-DH1 2480 00



1 Reference_Level_Hopping_NVNT_ANT1_2-DH1_Hopping




2 Band_Edge_(Hopping)_NVNT_ANT1_2-DH1_Hopping




1 Reference Level NVNT ANT1 3-DH1 2402 00




2 Bandedge NVNT ANT1 3-DH1 2402 00




1 Reference_Level_Hopping_NVNT_ANT1_3-DH1_Hopping



2 Band_Edge_(Hopping)_NVNT_ANT1_3-DH1_Hopping




1 Reference Level NVNT ANT1 3-DH1 2480 00




2 Bandedge NVNT ANT1 3-DH1 2480 00



1 Reference_Level_Hopping_NVNT_ANT1_3-DH1_Hopping




2 Band_Edge_(Hopping)_NVNT_ANT1_3-DH1_Hopping




7. Carrier Frequencies Separation (Hopping)

Condition	Antenna	Modulation	Frequency(MHz)	Hopping NO.0 (MHz)	Hopping NO.1 (MHz)	Carrier Frequencies Separation(MHz)	Limit(MHz)	Result
NVNT	ANT1	1-DH1	2402.00	2401.852	2402.848	1.00	0.880	Pass
NVNT	ANT1	1-DH1	2441.00	2440.867	2441.851	0.98	0.880	Pass
NVNT	ANT1	1-DH1	2480.00	2478.858	2479.848	0.99	0.879	Pass
NVNT	ANT1	2-DH1	2402.00	2401.852	2402.851	1.00	0.837	Pass
NVNT	ANT1	2-DH1	2441.00	2440.846	2441.854	1.01	0.837	Pass
NVNT	ANT1	2-DH1	2480.00	2478.849	2479.854	1.00	0.835	Pass
NVNT	ANT1	3-DH1	2402.00	2401.855	2402.857	1.00	0.832	Pass
NVNT	ANT1	3-DH1	2441.00	2440.852	2441.851	1.00	0.830	Pass
NVNT	ANT1	3-DH1	2480.00	2478.852	2479.863	1.01	0.830	Pass



Carrier_Frequencies_Separation_(Hopping)_NVNT_ANT1_1-DH1_Hopping



Carrier_Frequencies_Separation_(Hopping)_NVNT_ANT1_1-DH1_Hopping



Carrier_Frequencies_Separation_(Hopping)_NVNT_ANT1_2-DH1_Hopping



Carrier_Frequencies_Separation_(Hopping)_NVNT_ANT1_2-DH1_Hopping




Carrier_Frequencies_Separation_(Hopping)_NVNT_ANT1_2-DH1_Hopping



Carrier_Frequencies_Separation_(Hopping)_NVNT_ANT1_3-DH1_Hopping



Carrier_Frequencies_Separation_(Hopping)_NVNT_ANT1_3-DH1_Hopping



Carrier_Frequencies_Separation_(Hopping)_NVNT_ANT1_3-DH1_Hopping

