

ROROLEE


Pocket AI

Quick Start Guide
Safety & Warranty Guide


Contents

Package Contents.....	1
Product Description.....	2
Quick Guide.....	5
User Guide.....	6
Safety & Warranty Guide.....	8


01 /Package Contents



Rorolee Pocket AI Device



Keyring




USB-C Charging Cable



User Guide


02/Product Description



Power Button

Press and hold 3s to power on,
3s to power off.


Lanyard Hole



Type-C Charging Port

Conversation Button

Tap to start a conversation,
long press to start recording.



03/Quick Guide

Power On

1. Press and hold the power button for 3 seconds to turn on the device.
2. The device will display the startup animation.

App Setup

1. Scan the QR code to download the app.
2. Follow the app instructions to connect the device.
3. Once connected, the device will enter **Bluetooth mode** and operate normally.



Note:

Please fully charge the device before first use.

04/User Guide

Voice Mode

1. Tap the Voice Button to start listening.
2. Tap the Voice Button again after speaking to submit your command.
3. The device automatically returns to standby mode after the task is completed.

Recording Mode

1. Press and hold the Voice Button for 1 second to start recording.
2. Press and hold again for 1 second to stop recording.
3. Recordings are stored locally on the device and support offline recording.

Operating Modes

Bluetooth Mode

Keep the app running in the background.

Wi-Fi Mode

Works independently after network setup.

Offline Mode

Recording only; files can be viewed in the app.

Electronic User Manual

Display Indicators & Other Information

Scan the QR code for detailed instructions.



05/Safety & Warranty Guide

Product Warranty

12-Month Worry-Free Warranty

This product includes a 12-month warranty from the date of purchase. If the device experiences performance issues under normal use, free repair service will be provided.

Warranty Coverage

- A valid device serial number and proof of purchase (invoice or receipt) are required.
- The device must not be disassembled, repaired, modified, resold, or improperly maintained.
- The device must not be used outside the specified temperature or humidity range.
- Damage caused by misuse or failure to follow instructions is not covered.

- Damage caused by improper storage, impact, dropping, bending, crushing, or liquid exposure is not covered.

Please Note

- Accessories and consumables (such as cables and packaging) are not covered by the warranty.
- Damage caused by force majeure events (earthquake, fire, flood, etc.) is not covered.

Legal Restrictions

Please comply with all applicable laws and regulations. Do not use this product for any illegal purposes. The company assumes no responsibility or liability for any consequences resulting from unlawful use of this product.

Reminder

Before recording, please obtain consent from all recorded parties. Respect personal privacy and comply with local laws and regulations.

Privacy Protection

All recording data is stored locally on the device unless you choose to sync the recordings to the application. In such cases, the files will be stored on your smartphone. The company does not actively collect your recording data.

Data Security

The company is not responsible for personal data loss or damage caused by hardware or software issues, product maintenance, battery replacement, accidental deletion, formatting, virus infection, improper operation, or other non-product-quality-related causes. The company is also not liable for any indirect losses resulting from such issues. Regular backup of important data is recommended.

Product Settings & Instructions

Due to firmware upgrades, actual product functions,

settings, and operation methods may differ from those described in this manual. Firmware updates may be released periodically to improve product performance and functionality without prior notice. Please refer to the actual product experience.

Safety Instructions

- Keep the device and accessories out of reach of children to prevent choking or injury.
- Do not expose the battery or battery pack to fire or excessive heat (such as direct sunlight or heaters) to avoid explosion or leakage.

Maintenance & Care

Do not use chemicals or corrosive cleaners on the product, as they may damage or corrode the surface. Clean only with a soft, dry cloth.

Battery Use & Care

If the product will not be used for an extended period, it

is recommended to perform a full charge and discharge cycle every three months to prevent over-discharge and extend battery life.

Storage Capacity Notice

The built-in system software occupies part of the storage space. Therefore, the actual available capacity will be slightly less than the total capacity stated in the product specifications.

Statement: The built-in system software occupies part of the storage space, so the actual available capacity may be slightly less than the stated total capacity.

Notes

- The product contains strong magnets. Keep it away from magnetic cards, implanted medical devices (such as pacemakers), hard drives, RAM chips, and other sensitive equipment.
- The product is not waterproof. Do not expose it to liquids. Liquid entry may cause internal corrosion, battery ignition, or

explosion.

- Use the product within -10°C to 45°C. High temperatures may cause battery fire or explosion, while low temperatures may reduce battery performance.
- Do not place the product near heat sources, such as inside a car under direct sunlight.
- Do not store the battery for long periods after it has been fully discharged, as over-discharge may render it unusable.
- The product contains small parts. Keep it out of reach of children to prevent accidental swallowing.

Official App Download:

<https://deotaland.ai/#/rorolee>

For detailed product instructions and guidance, please consult the official electronic manual at:

<https://deotaland.ai/#/manual>

For any questions or assistance,
please contact our customer support at:
hello@deotaland.ai

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.