

How to use the remote control correctly?



Notice:

1. Before using the remote control, Please turn on the power switch(On the right side of the remote control) and extend the antenna.
2. Remote control battery: A23, 12V (not included).
3. Please use the remote control in front of the pool light first time(Within 6 Ft.)
4. If the remote control have any issue, please contact seller to replace free.

Pool Light Bulb Use Manual



180mm


正面

DIRECTORY

1. Installed in new concrete pool shell fixed lamps and lights
2. Replacement Lamp



suitable for most Pentair Hayward light Fixture



User are advised to replace the gasket with a new one, otherwise the warranty won't be offered for damages caused by water leakage.

Underwater lights operating instructions

- Important safety instructions
- Read and follow all the instructions
- Save These Instructions

DESCRIPTION WITH THE REMOTE CONTROL



1. power on by AC120V transformer which is power enough, lights on, the color mode is 7 colors scrolling(R/G/B/R+G/R+B/G+B/R+G+B), then press buttons to choose the color modes, time interval for press buttons must be 1-2seconds.
2. When using the remote control, make sure the antenna is stretch, to receive the signal well. If you use one remote for more than 2pcs lights, Make sure the current of power supply is enough for all the lights. Cause the distance between remote control and lights are different. If you want all the lights color changing Synchronously, please press the button Continuously at least 2 seconds to make sure all lights at the same color mode. or cut off the transformer power over 10 seconds, then power on to make them Synchronized.
3. Use switch on/off transformer power when batteries of remote controller run out or there's any other electromagnetism signal wish similar frequency around the lamps, changing one mode to next mode by switch on/off one time. Time interval for each switch on/off should be within 2S.
4. Do not use more than 12 watts of electric light, and do not use more than 8 hours a day. If the installation of the customer is not correct, the electric light will break or leak.

180mm

128mm

128mm

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction