

94*62mm
157g双面铜版纸

CERAMICS Ultra

CERAMICS Ultra

Brand Name: ROSELSA
Product Name: wireless headphones
Model Name: CERAMICS Ultra

Touch Functions ● Single Tap ● Long Press / No Action

Earbuds	Left Earbud (L)	Right Earbud (R)
Function		
Game/Music Mode	*****	*****
Voice Assistant	====	/
Previous Track	***	/
Next Track	/	***
Play/Pause	**	**
Answer Call	*	*
End Call	====	====
Reject Call	**	**
Noise Cancellation Mode	/	====

following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


To assure continued compliance, any changes or modifications not expressly approved by the party Responsible for compliance could void the user's authority to operate this equipment.
(Example: use only shielded interface cables when connecting to computer or peripheral devices).
This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.


Wireless Pairing

- 1.Open the charging case cover, remove the earbuds, and wear them. The earbuds will automatically enter wireless pairing mode.
- 2.Open the wireless settings interface on your device, search for the product's pairing name, and select it to connect (ROSE Ceramics U).



Wearing Instructions


- 1.Identify L/R and wear the earbuds as shown in the diagram.
- 2.Adjust the angle to ensure a secure fit and prevent imbalance or sound leakage.



ROSELINK Functions

- You can download the "ROSELINK" APP to customize the earbud functions.
- Search for "ROSELINK" APP in the app store or scan the QR code to install.

Accessories List



Restore Factory Settings

- 1.With the charging case cover open and earbuds inside, press and hold the button on the charging case for 10 seconds — the indicator light will flash red and white quickly 5 times.
- 2.After clearing the pairing record, you can search and connect the Earbud again in the new device's wireless settings interface.




Charging

*When using a power adapter, please purchase a certified adapter that has obtained CCC certification and meets the required standards.

Earbuds Charging

Place the Earbud into the charging case and close the cover to charge.



Charging Case Charging

Use a USB-C cable to charge the case.



*Battery Indicator: ● Red ≤ 30% ○ White ≤ 70% ● Green ≥ 70%

*This product is compatible with basic 5V1A charging provided by fast-charging devices, but using adapters with excessive power output or those only supporting fast charging is not recommended.

Touch Control Areas



Touch Functions ● Single Tap ● Long Press / No Action

Earbuds	Left Earbud (L)	Right Earbud (R)
Function		
Power On	====	====
Power Off	*****	*****
Volume +	*	/
Volume -	/	*

Safety Information

Please read and follow the precautions below before using or operating the device to avoid danger or illegal use.

Notes

- 1.Follow the rules and turn off the device in areas where the use of wireless equipment is prohibited.
- 2.Maintain a distance of at least 15 cm between this device and implanted medical devices (e.g., pacemakers).
- 3.When listening to music or calls, keep the volume at the minimum required level to prevent hearing damage. Prolonged exposure to high volume may also reduce attention and lead to accidents.
- 4.Use and store the device and accessories within a temperature range of -10°C to 45°C. Extreme temperatures may cause malfunctions.
- 5.Keep the device and accessories in a ventilated, cool place away from direct sunlight.
- 6.Keep the device and accessories out of reach of children. Small parts may be damaged or swallowed accidentally, leading to choking or other hazards.
- 7.This device is not a toy. Children should only use it under adult supervision.

Warnings

- 1.Comply with local laws and regulations. Do not use the device while driving, operating machinery, or performing tasks requiring environmental awareness.
- 2.Do not use the device during thunderstorms; lightning may cause malfunction or electric shock.
- 3.Do not place the device in direct sunlight, such as on a car dashboard or windshield.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the.


藍牙貼配

- 1.打開充電盒上蓋取出耳機。將耳機放入藍牙配對狀態。
- 2.進入設備的藍牙設置界面，搜索本產品的藍牙配對名稱，選擇並配對連接(ROSE Ceramics U)。




佩戴操作

- 1.區分L/R，請按照圖示佩戴耳機。
- 2.調整角度以保證良好佩戴，防止漏音、漏音。




功能使用

- 您可以使用手機下載"ROSELINK"APP，自定義耳機的操作功能。
- 在應用商店搜索"ROSELINK"APP或者掃描用戶手二維碼下載安裝。



觸控點位




觸控功能

耳機	左耳機 (L)	右耳機 (R)
功能		
遊戲/音樂模式	*****	*****
語音助手	====	/
上一首	***	/
下一首	/	***
播放/暫停	**	**
接聽來電	*	*
結束通話	====	====
拒接來電	**	**
降噪模式	/	====

觸控功能

耳機	左耳機 (L)	右耳機 (R)
功能		
遊戲/音樂模式	*****	*****
語音助手	====	/
上一首	***	/
下一首	/	***
播放/暫停	**	**
接聽來電	*	*
結束通話	====	====
拒接來電	**	**
降噪模式	/	====

附件清單



安全信息

在使用和操作設備前，請閱讀並遵守下面的注意事項，避免出現危險或非法的情況。

提示

- 1.在禁止使用無線設備的場所，請遵守該場所的規定，並關閉設備。
- 2.在使用本設備時，請與輸入式醫療設備(如起搏器等)保持至少15釐米的距離。
- 3.當您使用設備收聽音樂或通話時，建議使用音樂或通話所需的最小音量，以免損傷聽力;長時間接觸高音量可能會分散注意力，從而導致事故。
- 4.請在溫度-10°C至+45°C範圍內使用及存放設備及配件。當環境溫度過高時或過低時，可能會引起設備故障。
- 5.請將設備及配件存放在兒童接觸不到的地方。
- 6.請將設備及配件放置在兒童接觸不到的地方，兒童可能在無意之中損壞本設備及其配件，或吞下小零件導致窒息或其他危險。
- 7.本設備並非玩具，兒童應在成人監督下使用設備。

警告

- 1.請遵守所在國家或區域的相關規定，請勿在駕車、操作機器或從事需要高度注意外界聲音的工作時使用設備。
 - 2.請勿在雷雨天氣下使用設備，雷電可能導致設備不能正常工作或電擊危險。
 - 3.請勿將設備放置在陽光直射的地方，如汽車儀表盤或窗臺。
 - 4.請勿將設備靠近熱源或火源。
 - 5.請勿使用加熱工具(如電風扇、微波爐等)對設備進行乾燥處理。
 - 6.請勿擅自拆卸或改裝設備及其配件，否則該設備及配件將不在本公司保修範圍之內;設備發生故障時，請聯繫經銷商或維修中心;當地只能由經銷商或維修中心更換。
 - 7.請勿使設備及其配件受到液體的影響或腐蝕。
 - 8.使用未經認可或不兼容的電源、充電器，可能引發故障、火災、爆炸或其他危險。
 - 9.清潔、維護設備前請停止使用設備;請勿使用刺激性化學制品，清洗時或後請用清水清洗設備;請使用清潔、乾燥的軟布擦拭設備。
- 取得無線電波之低功率射頻器材，非經核准，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。
低功率射頻器材之使用不得影響為航空安全及干擾合法通信;經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。
前述合法通信，指依電信管理法規作業之無線電通信。
低功率射頻器材須符合合法通信或工業、科學及醫療用電磁輻射性電機設備之干擾。

Bluetooth Pairing

- 1.充電盒的蓋子打開後，將耳塞取出並將其放入充電盒中。耳塞將自動進入藍牙配對模式。
- 2.在您的設備的藍牙設置界面中，搜索本產品的藍牙配對名稱，並選擇並配對連接(ROSE Ceramics U)。



裝着方法

- 1.左右 (L/R) 耳塞，請按照圖示佩戴耳塞。
- 2.調整角度以確保良好佩戴，防止漏音、漏音。



功能的使用方法

-Smart Phoneに「ROSELINK」アプリをダウンロードして、イヤホンの操作機能をカスタマイズできます。
-アプリストアで「ROSELINK」を検索するか、左のQRコードをスキャンしてダウンロードしてください。

工場出荷時設定へのリセット

- 1.充電ケースの蓋を開け、イヤホンを取り出す前に充電ケースのボタンを長押しします。充電ケースのインジケータランプが赤と白に交互に5回点滅します。
- 2.ペアリング記録が消去されると、新しいデバイスのBluetoothペアリング設定画面でイヤホン機能を確認できるようになります。



充電

*電源アダプターを使用する場合は、CCC認証を取得した電源アダプターまたは信頼性の高い電源アダプターをご使用ください。

イヤホン充電

イヤホンを充電ケースに入れ、ケースの蓋を閉じて充電します。




充電ケース充電

USB-Cケーブルを使用して充電ケースを充電します。



バッテリー残量表示: ● 赤 ≤ 30% ○ 白 ≤ 70% ● 緑 ≥ 70%
*本製品は5V1Aの基本充電に対応した急速充電対応デバイスと互換性がありますが、出力が不足する充電器や急速充電器用の充電器の使用は推奨しません。

タッチポイント




タッチ操作機能 ● シングルタップ ● 長押し / 操作なし

イヤホン	左イヤホン (L)	右イヤホン (R)
機能		
電源オン	====	====
電源オフ	*****	*****
音量+	*	/
音量-	/	*

タッチ操作機能

イヤホン	左イヤホン (L)	右イヤホン (R)
機能		
ゲーム/音楽モード	*****	*****
音声アシスタント	====	/
前の曲	***	/
次の曲	/	***
再生/一時停止	**	**
電話応答	*	*
通話終了	====	====
拒絶拒否	**	**
ノイズキャンセリングモード	/	====

付属品一覧



安全情報

本機器の使用および操作を行う前に、以下の注意事項を必ずお読みいただき、遵守してください。事故や違法行為を避けるための必要な指示です。

注意事項

- 1.無線機器の使用が禁止されている場所では、現地の規則に従い、必ず本機器の電源を切ってください。
- 2.本機器を使用する際は、ペースメーカーなどの植込み型医療機器から少なくとも15cm以上離してください。
- 3.音楽を聴いたり通話したりする際は、聴覚への影響を避けるために必要最低限の音量でご使用ください。長時間の大声帯域使用は聴覚力を低下させる可能性があります。
- 4.本機器および付属品は、使用・保管ともに温度-10°C~+45°Cの範囲内で行ってください。高温または低温環境では故障の原因となることがあります。
- 5.本機器および付属品は、風通しの良い日陰で、直射日光の当たらない場所に保管してください。
- 6.本機器および付属品は、子供の手の届かない場所に保管してください。子供が誤って機器や付属品を破損したり、小さな部品を誤飲して窒息などの危険を引き起こす恐れがあります。
- 7.本機器は玩具ではありません。子供が使用する場合は、必ず大人の監督下でご使用ください。

警告

- 1.ご使用の国や地域の関連規則を必ず遵守してください。運転中、機械操作中、または周囲の音に注意を払う必要がある作業中での使用は避けてください。
- 2.雷雨時には本機器を使用しないでください。雷雨により機器が正常に動作しない、または感電の危険があります。
- 3.本機器を直射日光の当たる場所(自動車のダッシュボードや窓際など)に置かないでください。
- 4.本機器を熱源や火の近くには置かないでください。
- 5.電気ドライバーや電子レンジなどの加熱器具で本機器を乾燥させないでください。
- 6.本機器および付属品は、誤って分解・改造しないでください。改造・分解した場合は、保証対象外となります。故障時は必ず取扱説明書のアフターサービスセンターにご連絡ください。バッテリーは約4時間使用できます。
- 7.本機器および付属品に強い衝撃や振動を与えないでください。
- 8.認証されていない、または互換性のない電源や充電器を使用すると、故障・火災・爆発などの危険があります。
- 9.本機器の清掃やメンテナンスを行う際は、使用を中止してください。強い化学薬品、洗剤、または研磨性の強い洗浄剤で清掃しないでください。柔らかく乾いた布で拭いて清掃してください。



Official Website: <https://global.roselsa.com>
Discord Server: <https://discord.gg/cH6m2532U>

