

90 mm

85mm



USER MANUAL



MODEL EB-09B/EB-09P

TWS EARBUDS

HELLO

Thank you for purchasing our ESEEKGO TWS Earbuds product.

Please read through this user manual carefully to familiarize yourself with the product and maximize your user experience.

HOW TO OPERATE

POWERING ON/OFF & PAIRING

- **To Power On:** remove earphones from charging case for auto power-on, or press and hold the MFB button for 3 sec.Keep the earphones close to our mobile device when connecting. Open Bluetooth settings and connect to "EB-09B/EB-09P".
- **To Power Off:** place earphones back into the charging case for auto power-off, or press and hold the MFB button for 5 seconds.

TWS EARBUDS

MUSIC/AUDIO CONTROL

- Play/Pause: Double Clicks MFB button on either earphone.
- Previous Track: (3X)Triple Clicks on the **LEFT** earphone MFB button.
- Next Track: (3X)Triple Clicks on the **RIGHT** earphone MFB button.



L Touch Control Area R


⏮ = 2X Clicks ⏮ = 2X Clicks

⏭ = 3X Clicks L Side ⏭ = 3X Clicks R Side

TWS EARBUDS

CALL CONTROL

- Answer-Call: Double Clicks MFB button.
- End Call: Double Clicks MFB button.
- Reject Call: Press & Hold MFB for 2 sec.
- Voice Assist: Tap & hold MFB Button for 3 sec.
- Clear Pairing: Five Clicks MFB button.



L R

☎ = 2X Clicks

☎ = 2X Clicks

☎ = Press & Hold For 2 Seconds.


CHARGING

- Earbuds: Place correctly into case solid white light while charging; light off when fully charged.
- Charging case: Solid white light when charging earbuds. Blinking white when charging the case; solid white when fully charged.

TWS EARBUDS



TYPE-C CHARGING



MFB TAP ZONE (MFB:Mode/Main Function Button)

TWS EARBUDS

PRECAUCIONES

DO NOT use this product in environments with oil, moisture, steam, humidity, dust, high heat, and extreme cold.

DO NOT use non-original charging accessories, please ensure that the earphones have sufficient battery.

DO NOT exceed 60 decibels when used for a long time to avoid hearing damage.

DO NOT disassemble yourself. Do not clean with harsh chemicals.

Recycle responsibly once the product has reached the end of its life.

GENERAL SAFETY

The product contains a built-in battery and should not exposed to high temperatures. Exposure to the sun may damage wireless performance.

DO NOT immerse in liquids.Follow local rules about using our earbuds while driving.Prolonged exposure to high volume may damage your hearing.

85mm



MODELO EB-09B/EB-09P

MANUAL DE USO

AURICULARES TWS

HOLA!

Gracias por adquirir los auriculares inalámbricos TWS de ESEEKGO.

Lea atentamente este manual de usuario para familiarizarse con el producto y aprovechar al máximo su experiencia de uso.

INSTRUCCIONES DE USO

ENCENDIDO / APAGADO Y EMPAREJAMIENTO

- **Encender:** retire los auriculares del estuche de carga para que se enciendan automáticamente, o mantenga presionado el botón MFB durante 3 segundos. Mantenga los auriculares cerca de su dispositivo móvil durante la conexión. Active Bluetooth y seleccione "**EB-09B/EB-09P**".
- **Apagar:** coloque los auriculares nuevamente en el estuche de carga para que se apaguen automáticamente, o mantenga presionado el botón MFB durante 5 segundos.

AURICULARES TWS

CONTROL DE MÚSICA Y AUDIO

• Reproducir/Pausar:	Pulse dos veces el botón MFB de cualquiera de los auriculares.
• Pista anterior:	(3X) Pulse tres veces el botón MFB del auricular IZQUIERDO .
• Pista siguiente:	(3X) Pulse tres veces el botón MFB del auricular DERECHO .



⏮ = 2X Clics	⏮ = 2X Clics
⏭ = 3X Clics Lado IZQ.	⏭ = 3X Clics Lado DER.

AURICULARES TWS

CONTROL DE LLAMADAS

• Responder Llamada:	Doble clics en el botón MFB.
• Finalizar Llamada:	Doble clics en el botón MFB.
• Rechazar Llamada:	Mantener pulsado 2 seg.
• Asistente De Voz:	Mantener pulsado 3 seg.
• Eliminar Emparejamiento:	Cinco clics en el botón MFB.



CARGANDO

- **Auriculares:** Colóquelos correctamente en el estuche de carga. La luz blanca permanece fija durante la carga y se apaga cuando la carga está completa.
- **Estuche de carga:** La luz blanca permanece fija mientras carga los auriculares. Al cargar el estuche, la luz blanca parpadeará y permanecerá fija cuando la carga esté completa.

AURICULARES TWS

PRECAUTIONS

No utilice el producto en ambientes con aceite, humedad, vapor , polvo o temperaturas extremas.

No utilice accesorios de carga no originales. Mantenga los auriculares con suficiente carga.

No exceda los 60 dB durante un uso prolongado para evitar posibles daños auditivos.

No desmonte el producto ni lo limpie con productos químicos agresivos.

Recicle el producto de forma responsable al final de su vida útil.

SEGURIDAD GENERAL

El producto contiene una batería integrada y no debe exponerse a altas temperaturas. La exposición al sol puede dañar el rendimiento inalámbrico.

NO sumerja el producto en líquidos. Respete la normativa local sobre el uso de auriculares mientras conduce. La exposición prolongada a un volumen alto puede dañar su audición.



FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.